

# ARES-WH10

---

Server Board

User's Manual 4<sup>th</sup> Ed

## Copyright Notice

---

This document is copyrighted, 2022. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, AAEMON assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

AAEMON reserves the right to make changes in the product design without notice to its users.

.

## Acknowledgement

---

All other products' name or trademarks are properties of their respective owners.

- Microsoft Windows® is a registered trademark of Microsoft Corp.
- Intel®, Pentium®, Celeron®, Atom® and Xeon® are registered trademarks of Intel Corporation
- Intel® Core™ is a trademark of Intel Corporation
- ITE is a trademark of Integrated Technology Express, Inc.
- IBM, PC/AT, PS/2, and VGA are trademarks of International Business Machines Corporation.
- CentOS is a trademark of Red Hat, Inc.

All other product names or trademarks are properties of their respective owners. The publisher of this document does not assume nor imply ownership of any trademarked product not listed herein.

## Packing List

---

Before setting up your product, please make sure the following items have been shipped:

Item	Quantity
● ARES-WH10 server board	1
● CPU carrier	1
● I/O Cable	2
● I/O Shield	1

If any of these items are missing or damaged, please contact your distributor or sales representative immediately.

## About this Document

---

This User's Manual contains all the essential information, such as detailed descriptions and explanations on the product's hardware and software features (if any), its specifications, dimensions, jumper/connector settings/definitions, and driver installation instructions (if any), to facilitate users in setting up their product.

Users may refer to the product page at [AAEON.com](http://AAEON.com) for the latest version of this document.

## Safety Precautions

---

Please read the following safety instructions carefully. It is advised that you keep this manual for future references

1. All cautions and warnings on the device should be noted.
2. Make sure the power source matches the power rating of the device.
3. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
4. Always completely disconnect the power before working on the system's hardware.
5. No connections should be made when the system is powered as a sudden rush of power may damage sensitive electronic components.
6. If the device is not to be used for a long time, disconnect it from the power supply to avoid damage by transient over-voltage.
7. Always disconnect this device from any AC supply before cleaning.
8. While cleaning, use a damp cloth instead of liquid or spray detergents.
9. Make sure the device is installed near a power outlet and is easily accessible.
10. Keep this device away from humidity.
11. Place the device on a solid surface during installation to prevent falls
12. Do not cover the openings on the device to ensure optimal heat dissipation.
13. Watch out for high temperatures when the system is running.
14. Do not touch the heat sink or heat spreader when the system is running
15. Never pour any liquid into the openings. This could cause fire or electric shock.
16. As most electronic components are sensitive to static electrical charge, be sure to ground yourself to prevent static charge when installing the internal components. Use a grounding wrist strap and contain all electronic components in any static-shielded containers.

17. If any of the following situations arises, please the contact our service personnel:
  - i. Damaged power cord or plug
  - ii. Liquid intrusion to the device
  - iii. Exposure to moisture
  - iv. Device is not working as expected or in a manner as described in this manual
  - v. The device is dropped or damaged
  - vi. Any obvious signs of damage displayed on the device
18. **DO NOT LEAVE THIS DEVICE IN AN UNCONTROLLED ENVIRONMENT WITH TEMPERATURES BEYOND THE DEVICE'S PERMITTED STORAGE TEMPERATURES (SEE CHAPTER 1) TO PREVENT DAMAGE.**

### **Warning!**



This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

### **Caution:**

*There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.*

### **Attention:**

*Il y a un risque d'explosion si la batterie est remplacée de façon incorrecte. Ne la remplacer qu'avec le même modèle ou équivalent recommandé par le constructeur. Recycler les batteries usées en accord avec les instructions du fabricant et les directives gouvernementales de recyclage.*



## China RoHS Requirements (CN)

产品中有毒有害物质或元素名称及含量

AAEON Main Board/ Daughter Board/ Backplane

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板 及其电子组件	X	X	○	○	○	○
外部信号 连接器及线材	X	X	○	○	○	○
<p>○：表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。</p> <p>X：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。</p> <p>备注：此产品所标示之环保使用期限，系指在一般正常使用状况下。</p>						

## China RoHS Requirement (EN)

Poisonous or Hazardous Substances or Elements in Products  
 AAEON Main Board/ Daughter Board/ Backplane

Component	Poisonous or Hazardous Substances or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCB & Other Components	X	X	○	○	○	○
Wires & Connectors for External Connections	X	X	○	○	○	○
<p>O: The quantity of poisonous or hazardous substances or elements found in each of the component's parts is below the SJ/T 11363-2006-stipulated requirement.</p> <p>X: The quantity of poisonous or hazardous substances or elements found in at least one of the component's parts is beyond the SJ/T 11363-2006-stipulated requirement.</p> <p><b>Note:</b> The Environment Friendly Use Period as labeled on this product is applicable under normal usage only</p>						

# Table of Contents

---

<b>Chapter 1 - Product Specifications</b> .....	<b>1</b>
1.1 Specifications .....	2
<b>Chapter 2 – Hardware Information</b> .....	<b>5</b>
2.1 Dimensions .....	6
2.2 Jumpers and Connectors .....	8
2.3 List of Jumpers .....	9
2.3.1 RTC Reset (CMOS1).....	9
2.3.2 Auto PWRBTN Selection (JP1) .....	9
2.3.3 ME Recover (JP2) .....	9
2.4 List of Connectors .....	10
2.4.1 Digital I/O: 2.0mm Pin Header 2x5P (DIO1) .....	11
2.4.2 USB2.0: 2.0mm Box Header 2x10P (CN5) .....	12
2.4.3 Front Panel Pin Header (FP1) .....	12
2.4.4 Case Open (CN9).....	13
<b>Chapter 3 - AMI BIOS Setup</b> .....	<b>14</b>
3.1 System Test and Initialization .....	15
3.2 AMI BIOS Setup .....	16
3.3 Setup Submenu: Main.....	17
3.4 Setup Submenu: Advanced .....	18
3.4.1 Trusted Computing.....	19
3.4.2 Hardware Monitor .....	21
3.4.3 SIO Configuration.....	23
3.4.3.1 Serial Port Configuration.....	24
3.4.4 PCI Subsystem Settings .....	25
3.4.5 Serial Port Console Configuration.....	26
3.4.5.1 COM0 Console Redirection Settings .....	27

3.4.5.2	Legacy Console Redirection Settings .....	29
3.4.5.3	Console Redirection EMS Settings .....	30
3.4.6	NVMe Configuration .....	32
3.4.7	Power Management .....	33
3.4.8	Digital IO Port Configuration .....	34
3.4.9	Case Open Configuration .....	35
3.5	Setup Submenu: Platform Configuration .....	36
3.5.1	PCH Configuration .....	37
3.5.1.1	PCH SATA Configuration .....	38
3.5.1.2	PCH sATA Configuration .....	39
3.5.2	Server ME Configuration .....	40
3.6	Setup Submenu: Socket Configuration .....	41
3.6.1	Processor Configuration .....	42
3.6.2	Memory Configuration .....	43
3.6.2.1	Memory Topology .....	44
3.6.3	I/O Configuration .....	45
3.6.4	Intel® VT for Directed I/O (VT-d) .....	46
3.6.5	Advanced Power Management Configuration .....	47
3.6.5.1	CPU C State Control .....	48
3.7	Setup Submenu: Security .....	49
3.7.1	Secure Boot .....	50
3.7.1.1	Key Management .....	51
3.8	Setup Submenu: Boot .....	53
3.9	Setup Submenu: Save & Exit .....	54
<b>Chapter 4 – Driver Installation .....</b>		<b>55</b>
4.1	Driver Download/Installation .....	56

# Chapter 1

---

Product Specifications

## 1.1 Specifications

---

### System

Form Factor	ATX Sever Board Whitely Platform
Processor	Single Intel® Xeon® Processor Ice Lake-SP processor, supports up to 270W
System Memory	DDR4 2666MHz R-DIMM Slot x 6, supports up to 192GB (32GB per DIMM)
Chipset	Intel® C621A
Ethernet	Intel® i210 Gigabit Ethernet x 2
COM	RS-232 x 1
BIOS	AMI BIOS
Serial ATA	SATA III Port x 8, supports RAID 0, 1, 5,10
Audio and VGA	1
Expansion Interface	PCIE 1: PCIe x16 (Gen4 x16) slot x 1 PCIE 2: PCIe x8 (Gen3 x4) slot x 1 PCIE 3: PCIe x16 (Gen4 x16) slot x 1 PCIE 4: PCIe x8 (Gen4 x4) slot x 1 PCIE 5: PCIe x16 (Gen4 x16) slot x 1 PCIE 6: PCIe x8 (Gen3 x4) slot x 1 PCIE 7: PCIe x8 (Gen4 x8) slot x 1
Watchdog Timer	1~255 steps by software programming
RTC	Internal RTC
System Fan	4-Pin fan header x 5 (up to 5 fans)
Front I/O Panel	N/A

## System

Rear I/O Panel	USB 3.0 x 6 1Gb RJ45 LAN x 2 Audio In/Out x 1 VGA x 1
Color	N/A
Power Supply	ATX
Dimension	12.0" x 9.6" (305mm x 244 mm)
Power Consumption	269W (Based on Intel® Xeon® Platinum 8352S)
MTBF (Hours)	292,321

## Display

Chipset	SM750
Graphic Engine	N/A
Resolution	1920 x 1080 (WIN Server 2019) 800 x 600 (CentOS 7.3)
Connector	VGA

## I/O

Serial Port	RS-232 x 1
K/B and Mouse	N/A
USB	USB 3.0 x 6

## Environmental

Operating Temperature	32°F ~ 140°F (0°C ~ 60°C)
Storage Temperature	-4°F ~ 140°F (-20°C ~ 60°C)
Operating Humidity	10%~80% relative humidity, non-condensing
Storage Humidity	10%~80% @40°C; non-condensing




# Chapter 2

---


Hardware Information



### Solder Side



## 2.2 Jumpers and Connectors



### Note:

- For a fully configured system, we recommend that you use a power supply unit (PSU) that complies with ATX 12V Specification 2.0 (or later version) and provides a minimum power of 500W.
- We recommend that you use a PSU with a higher power output when configuring a system with more power-consuming devices. The system may become unstable or may not boot up if the power is inadequate.
- If you want to use two or more high-end PCIe x16 cards please connect ATX3, and use a PSU with 1000W power or above to ensure the system stability.

## 2.3 List of Jumpers

---


Please refer to the table below for all of the board's jumpers that you can configure for your application

Label	Function
CMOS1	RTC Reset
JP1	Auto Power Button
JP2	ME Recover


---

### 2.3.1 RTC Reset (CMOS1)

---




Normal




Clear CMOS

### 2.3.2 Auto PWRBTN Selection (JP1)

---




Normal




Auto PWRBTN

### 2.3.3 ME Recover (JP2)

---



Normal



ME Recover

## 2.4 List of Connectors

Please refer to the table below for all of the board's connectors that you can configure for your application


Label	Function
DIO1	Digital I/O
CN5	USB2.0 Port
FP1	Front Panel Pin Header
CPU_FAN1/2	CPU_FAN1
SYS_FAN3~5	CPU_FAN2
CN6	M.2 Key-M 2280
SATA1 ~ SATA8	SATA Port Connector
ATX1	24-Pin ATX Power Connector
ATX2/ATX3	8-Pin 12V Power Connector
PCIE1~PCIE7	PCIE 1: PCIe x16 (Gen4 x16) slot PCIE 2: PCIe x8 (Gen3 x4) slot PCIE 3: PCIe x16 (Gen4 x16) slot PCIE 4: PCIe x8 (Gen4 x4) slot PCIE 5: PCIe x16 (Gen4 x16) slot PCIE 6: PCIe x8 (Gen3 x4) slot PCIE 7: PCIe x8 (Gen4 x8) slot
DDR3_IPMI1 <sup>Note 2</sup>	IPMI Connector (AAEON IPMI only)
CN4	IPMI LAN only
CN14 <sup>Note 2</sup>	IPMI LAN Internal Connector.
CN2/CN3	USB3.0+LAN Connector
VGA1	VGA+COM Connector
CN15	Audio Connector
U211	LGA4189 Whitley CPU
DIMM1~8	DDR4 Slot
CN9	Case Open

**Note 1:** CN1/CN5/CN7/CN8/CN10/CN11/CN12/LPC1 are for Debug.

**Note 2:** CN14 & DDR3 are for future AAEON IPMI and only available on a project basis.


**Note 3:** PCIE2, PCIE4, PCIE6 are PCIe slots with x4 lanes. PCIE6 connects to PCH.

## 2.4.1 Digital I/O: 2.0mm Pin Header 2x5P (DIO1)




Pin	Signal	Signal Type
1	DIO0	Input / Output
2	DIO1	Input / Output
3	DIO2	Input / Output
4	DIO3	Input / Output
5	DIO4	Input / Output
6	DIO5	Input / Output
7	DIO6	Input / Output
8	DIO7	Input / Output
9	+3.3V	PWR
10	GND	GND

## 2.4.2 USB2.0: 2.0mm Box Header 2x10P (CN5)



Pin	Signal	Signal Type
1	+5V_USB	PWR
2	GND	GND
3	USBP_1N	DIFF
4	GND	GND
5	USBP_1P	DIFF
6	USBP_2P	DIFF
7	GND	GND
8	USBP_2N	DIFF
9	GND	GND
10	+5V_USB	PWR

## 2.4.3 Front Panel Pin Header (FP1)



Pin	Signal	Signal Type
1	Power On Button(+)	Input
2	Reset Switch (+)	Input
3	Power On Button(-)	GND
4	Reset Switch (-)	GND
5	HDD LED (+)	Output



6	Power LED(+)	POWER
7	HDD LED (-)	Output
8	Power LED(-)	GND

## 2.4.4 Case Open (CN9)

---



Pin	Signal	Signal Type
1	CASEOPEN#	Input
2	GND	GND

# Chapter 3

---

AMI BIOS Setup

## 3.1 System Test and Initialization

---

The board uses certain routines to perform testing and initialization. If an error, fatal or non-fatal, is encountered, a few short beeps or an error message will be outputted. The board can usually continue the boot up sequence with non-fatal errors.

The system configuration verification routines check the current system configuration against the values stored in the CMOS memory. If they do not match, an error message will be outputted, in which case you will need to run the BIOS setup program to set the configuration information in memory.

There are three situations in which you will need to change the CMOS settings:

- You are starting your system for the first time
- You have changed your system's hardware
- The CMOS memory has lost power and the configuration information is erased

The system's CMOS memory uses a backup battery for data retention, which is to be replaced once emptied.

## 3.2 AMI BIOS Setup

---

The AMI BIOS ROM has a pre-installed Setup program that allows users to modify basic system configurations, which is stored in the battery-backed CMOS RAM and BIOS NVRAM so that the information is retained when the power is turned off.

To enter BIOS Setup, press <Del> or <F2> immediately while your computer is powering up.

The function for each interface can be found below.

**Main** – Date and time can be set here. Press <Tab> to switch between date elements

**Advanced** – Enable/ Disable boot option for legacy network devices


**Chipset** – For hosting bridge parameters

**Boot** – Enable/ Disable quiet Boot Option


**Security** – The setup administrator password can be set here

**Save & Exit** – Save your changes and exit the program

### 3.3 Setup Submenu: Main



### 3.4 Setup Submenu: Advanced



### 3.4.1 Trusted Computing

Aptio Setup - AMI

Advanced		
TPM 2.0 Device Found Firmware Version: 5.63 Vendor: IFX		Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
Security Device Support [Enabled] Active PCR banks SHA-1,SHA256 Available PCR banks SHA-1,SHA256		
SHA-1 PCR Bank [Enabled] SHA256 PCR Bank [Enabled]		
Pending operation [None] Platform Hierarchy [Enabled] Storage Hierarchy [Enabled] Endorsement Hierarchy [Enabled] TPM 2.0 UEFI Spec Version [TCG_2] Physical Presence Spec Version [1.3] TPM 2.0 InterfaceType [TIS] Device Select [Auto]		++: Select Screen !1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.22.1282 Copyright (C) 2021 AMI

Options Summary		
Security Device Support	Enable	Optimal Default, Failsafe Default
	Disable	
Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.		
SHA-1 PCR Bank	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable SHA-1 PCR Bank		
SHA256 PCR Bank	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable SHA256 PCR Bank.		
Pending operation	None	Optimal Default, Failsafe Default
	TPM Clear	
Schedule an Operation for the Security Device. NOTE: Your Computer will reboot during restart in order to change State of Security Device.		
Platform Hierarchy	Enabled	Optimal Default, Failsafe Default
	Disabled	

Enable or Disable Platform Hierarchy		
Storage Hierarchy	Enabled	Optimal Default, Failsafe Default
	Disabled	
Enable or Disable Storage Hierarchy		
Endorsement Hierarchy	Enabled	Optimal Default, Failsafe Default
	Disabled	
Enable or Disable Endorsement Hierarchy		
TPM 2.0 UEFI Spec Version	TCG_2	Optimal Default, Failsafe Default
	TCG_1_2	
Select the TCH2 Spec Version Support. TCG_1_2: The Compatible mode for Win8/Win10 TCG_2: Support new TCG2 protocol and event format for Win10 or later		
Physical Presence Spec Version	1.3	Optimal Default, Failsafe Default
	1.2	
Select to Tell O.S. to support PPI Spec Version 1.2 or 1.3. Note some HCK tests might not support 1.3		
Device Select	Auto	Optimal Default, Failsafe Default
	TPM 1.2	
	TPM 2.0	
TPM 1.2 will restrict support to TPM 1.2 devices, TPM 2.0 will restrict support to TPM 2.0 devices, Auto will support both with the default set to TPM 2.0 devices if not found, TPM 1.2 devices will be enumerated.		



### 3.4.2 Hardware Monitor

Aptio Setup - AMI

Advanced

<p>CPU FAN Control [Disabled]          CPU FAN 2 Control [Disabled]          SYS FAN 3 Control [Disabled]</p> <p>CPU Temperature : +52 ℃          System Temperature : +40 ℃</p> <p>CPU FAN : 3770 RPM          CPU FAN 2 : N/A          System FAN 3 : N/A          System FAN 4 : N/A          System FAN 5 : N/A</p> <p>VDCORE : +1.812 V          VMEM : +1.236 V          +12V : +11.971 V          +5V : +4.979 V          +1.05V : +1.020 V          5VSB : +5.082 V          +3.3V : +3.297 V          3VSB : +3.288 V          VBAT : +2.976 V</p>	<p>For En/Disable CPU FAN Smart Control          Enabled: FAN is running in accordance with user settings          Disabled: FAN is always running with full speed</p> <p>⬆: Select Screen          ⬆: Select Item          Enter: Select          +/-: Change Opt.          F1: General Help          F2: Previous Values          F3: Optimized Defaults          F4: Save &amp; Exit          ESC: Exit</p>
---	--


Version 2.22.1282 Copyright (C) 2021 AMI

#### Options Summary

CPU FAN / CPU FAN 2 / SYS FAN 3 Control	Disabled	Optimal Default, Failsafe Default
	Enabled	
For En/Disable CPU FAN / CPU FAN 2 / SYS FAN 3 Smart Control Enabled: FAN is running in accordance with user settings Disabled: FAN is always running with full speed		
FAN Control Mode	Manual Mode	Optimal Default, Failsafe Default
	Automatic Mode	
Manual Mode: Depends on PWM Duty Automatic Mode: FAN Speed is depends on CPU Temperature		
PWM Duty	200	Optimal Default, Failsafe Default
Manual Mode: PWM Duty value Range:[0 - 255]		
Spin PWM	100	Optimal Default, Failsafe Default
The PWM Duty of FAN Spin Range:[0 - 255]		


Off Control Temperature	30	Optimal Default, Failsafe Default
Temperature Limit Value of Fan Off Note: Some fans have the minimum speed even if the PWM value is 0		
Start Control Temperature	50	Optimal Default, Failsafe Default
Temperature Limit Value of FAN Start Control		
Full Speed Temperature	80	Optimal Default, Failsafe Default
Temperature Limit Value of FAN Full Speed		
PWM Slope	5	Optimal Default, Failsafe Default
Slope PWM value/Degree C for FAN Speed Control Range:[1-15]		

### 3.4.3 SIO Configuration




Options Summary
Serial Port
View and Set Basic properties of the SIO Logical device. Like IO Base, IRQ Range, DMA Channel and Device Mode.

### 3.4.3.1 Serial Port Configuration




Options Summary		
Use This Device	Enabled	Optimal Default, Failsafe Default
	Disabled	
Enable or Disable this Logical Device.		
Possible	Use Automatic Settings	Optimal Default, Failsafe Default
	IO=3F8h; IRQ=4;	
	IO=2F8h; IRQ=3;	
Allows the user to change the device resource settings. New settings will be reflected on this setup page after system restarts.		

### 3.4.4 PCI Subsystem Settings



Options Summary		
Above 4G Decoding	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enables or Disables 64bit capable Devices to be Decoded in Above 4G Address Space (Only if System Supports 64-bit PCI Decoding).		

### 3.4.5 Serial Port Console Configuration



Options Summary		
Console Redirection	Enabled	Optimal Default, Failsafe Default
	Disabled	
Console Redirection Enable or Disable.		
Console Redirection Settings		
The settings specify how the host computer and the remote computer (which the user is using) will exchange data.		
Both computers should have the same or compatible settings.		
Console Redirection EMS	Enabled	
	Disabled	Optimal Default, Failsafe Default
Console Redirection Enable or Disable.		

### 3.4.5.1 COM0 Console Redirection Settings

Aptio Setup - AMI

Advanced

COM0 Console Redirection Settings		Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
Terminal Type	[VT100+]	
Bits per second	[115200]	++: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Data Bits	[8]	
Parity	[None]	
Stop Bits	[1]	
Flow Control	[None]	
VT-UTF8 Combo Key Support	[Enabled]	
Recorder Mode	[Disabled]	
Resolution 100x31	[Disabled]	
Putty KeyPad	[VT100]	

Version 2.22.1282 Copyright (C) 2021 AMI

#### Options Summary

Terminal Type	VT100	
	VT100+	Optimal Default, Failsafe Default
	VT-UTF8	
	ANSI	

Emulation :

ANSI : Extended ASCII char set.

VT100 : ASCII char set.

VT100+ : Extends VT100 to support color, function keys, etc.

VT-UTF8 : Uses UTF8 encoding to map Unicode.


Bits per second	9600	
	19200	
	38400	
	57600	
	115200	Optimal Default, Failsafe Default

Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

Data bit	7	
	8	Optimal Default, Failsafe Default
Data Bits		
Parity	None	Optimal Default, Failsafe Default
	Even	
	Odd	
	Mark	
	Space	
<p>A Parity bit can be sent with the data bits to detect some transmission errors.</p> <p>Even : parity bit is 0 if the num of 1's in the data bits is even.</p> <p>Odd : parity bit is 0 if the num of 1's in the data bits is odd.</p> <p>Mark: parity bit is always 1.</p> <p>Space: Parity bit is always 0</p> <p>Mark and Space Parity do not allow for error detection. They can be used as an additional data bit.</p>		
Stop Bits	1	Optimal Default, Failsafe Default
	2	
<p>Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may.</p>		
Flow control	None	Optimal Default, Failsafe Default
	Hardware RTS/CTS	
<p>Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.</p>		
VT-UTF8 Combo	Enabled	Optimal Default, Failsafe Default
Key Support	Disabled	
<p>Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals.</p>		
Recorder Mode	Disabled	Optimal Default, Failsafe Default
	Enabled	
<p>With this mode enabled only text will be sent. This is to capture Terminal data.</p>		
Resolution 100x31	Disabled	Optimal Default, Failsafe Default
	Enabled	
<p>Enables or disables extended terminal resolution.</p>		
Putty KeyPad	VT100	Optimal Default, Failsafe Default
	LINUX	
	XTERMR6	
	SCO	
	ESCN	
	VT400	
<p>Select FunctionKey and KeyPad on Putty.</p>		



### 3.4.5.2 Legacy Console Redirection Settings



Options Summary		
Redirection COM Port	COM0	Optimal Default, Failsafe Default
Select a COM port to display redirection of Legacy OS and Legacy OPROM Messages		
Resolution	80x24	Optimal Default, Failsafe Default
	80x25	
On Legacy OS, the Number of Rows and Columns supported redirection		
Redirect After POST	Always Enable	Optimal Default, Failsafe Default
	BootLoader	
When Bootloader is selected, then Legacy Console Redirection is disabled before booting to legacy OS. When Always Enable is selected, then Legacy Console Redirection is enabled for legacy OS. Default setting for this option is set to Always Enable.		

### 3.4.5.3 Console Redirection EMS Settings

Aptio Setup - AMI

Advanced

Out-of-Band Mgmt Port	COM0	VT-UTF8 is the preferred terminal type for out-of-band management. The next best choice is VT100+ and then VT100. See above, in Console Redirection Settings page, for more Help with Terminal Type/Emulation.
Terminal Type EMS	[VT-UTF8]	
Bits per second EMS	[115200]	
Flow Control EMS	[None]	
Data Bits EMS	8	
Parity EMS	None	
Stop Bits EMS	1	

++: Select Screen  
 ↑: Select Item  
 Enter: Select  
 +/-: Change Opt.  
 F1: General Help  
 F2: Previous Values  
 F3: Optimized Defaults  
 F4: Save & Exit  
 ESC: Exit

Version 2.22.1282 Copyright (C) 2021 AMI

Options Summary		
Terminal Type EMS	VT100	
	VT100+	
	VT-UTF8	Optimal Default, Failsafe Default
	ANSI	
VT-UTF8 is the preferred terminal type for out-of-band management. The next best choice is VT100+ and then VT100. See above, in Console Redirection Settings page, for more Help with Terminal Type/Emulation.		
Bits per second EMS	9600	
	19200	
	57600	
	115200	Optimal Default, Failsafe Default
Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.		
Flow Control EMS	None	Optimal Default, Failsafe Default
	Hardware RTS/CTS	
	Software Xon/Xoff	

Flow control can prevent data loss from buffer overflow.

When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

Data Bits EMS	8	Optimal Default, Failsafe Default
---------------	---	-----------------------------------

Data Bits

Parity EMS	None	Optimal Default, Failsafe Default
------------	------	-----------------------------------

A parity bit can be sent with the data bits to detect some transmission errors.

Even: parity bit is 0 if the num of 1's in the data bits is even.

Odd: parity bit is 0 if num of 1's in the data bits is odd.

Mark: parity bit is always 1.

Space: Parity bit is always 0.

Mark and Space Parity do not allow for error detection.


They can be used as an additional data bit.

Stop Bits EMS	1	Optimal Default, Failsafe Default
---------------	---	-----------------------------------


Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning).

The standard setting is 1 stop bit. Communication with slow devices may.

## 3.4.6 NVMe Configuration




### 3.4.7 Power Management



#### Options Summary


Power Mode	ATX Type	Optimal Default, Failsafe Default
	AT Type	
Select power supply mode.		
Restore AC Power Loss	Last State	Optimal Default, Failsafe Default
	Always On	
	Always Off	
Select power state when power is re-applied after a power failure.		
RTC wake system from S5	Disabled	Optimal Default, Failsafe Default
	Fixed Time	
	Bypass	
Fixed Time : System will wake on the hr :: min :: sec specified		
Bypass: BIOS will not control RTC wake function during system shutdown		

### 3.4.8 Digital IO Port Configuration




Options Summary		
DIO Port1~4	Output	Optimal Default, Failsafe Default
	Input	
Set DIO as Input or Output		
DIO Port1~4 Output Level	High	Optimal Default, Failsafe Default
	Low	
Set output level when DIO pin is output		
DIO Port5~8	Output	
	Input	Optimal Default, Failsafe Default
Set DIO as Input or Output		
DIO Port5~8 Output Level	High	Optimal Default, Failsafe Default
	Low	
Set output level when DIO pin is output		

### 3.4.9 Case Open Configuration




Options Summary		
Case Open	Disabled	Optimal Default, Failsafe Default
Warning	Enabled	
	Clear	
Case Open detecting function		

### 3.5 Setup Submenu: Platform Configuration






### 3.5.1 PCH Configuration




### 3.5.1.1 PCH SATA Configuration



Options Summary		
SATA Controller	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable SATA Controller		
Configure SATA as	AHCI	Optimal Default, Failsafe Default
	RAID	
Identify the SATA port is connected to Solid State Drive or Hard Disk Drive		

### 3.5.1.2 PCH sSATA Configuration




Options Summary		
sSATA Controller	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable SATA Controller		

### 3.5.2 Server ME Configuration

Aptio Setup - AMI		
Platform Configuration		
General ME Configuration		Enable/Disable sending HMRFPD_ENABLE message to ME
Oper. Firmware Version	0F:4.4.4.58	
Backup Firmware Version	N/A	
Recovery Firmware Version	0F:4.4.4.58	
ME Firmware Status #1	0x000F0255	
ME Firmware Status #2	0x89112006	
Current State	Operational	
Error Code	No Error	
Recovery Cause	N/A	
PTT Support	[Disable]	
Suppress PTT Commands	[Disable]	
HMRFPD_ENABLE Message	[Disable]	
		++: Select Screen T1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.22.1282 Copyright (C) 2021 AMI		

Options Summary		
HMRFPD_ENABLE	Disable	Optimal Default, Failsafe Default
Message	Enable	
Enable/Disable sending HMRFPD_ENABLE Message to ME		

### 3.6 Setup Submenu: Socket Configuration



### 3.6.1 Processor Configuration


Aptio Setup - AMI  
Socket Configuration

Processor Configuration		Enables Hyper Threading (Software Method to Enable/Disable Logical Processor threads.  ++: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
-----		
Processor BSP Revision	606A6 - ICX D0	
Processor Socket	Socket 0    Socket 1	
Processor ID	000606A6*      N/A	
Processor Frequency	2.200GHz      N/A	
Processor Max Ratio	16H      N/A	
Processor Min Ratio	08H      N/A	
Microcode Revision	0D0002E0      N/A	
L1 Cache RAM(Per Core)	80KB      N/A	
L2 Cache RAM(Per Core)	1280KB      N/A	
L3 Cache RAM(Per Package)	49152KB      N/A	
Processor 0 Version	Intel(R) Xeon(R) Gold 6338N CPU @ 2.20GHz	
Hyper-Threading [ALL]	[Enable]	

Version 2.22.1282 Copyright (C) 2021 AMI

Options Summary		
Hyper-Threading	Disable	
[ALL]	Enable	Optimal Default, Failsafe Default
Enables Hyper Threading (Software Method to Enable/Disable Logical Processor threads).		

## 3.6.2 Memory Configuration




### 3.6.2.1 Memory Topology






### 3.6.3 I/O Configuration




### 3.6.4 Intel® VT for Directed I/O (VT-d)




Options Summary		
Intel® VT for Directed I/O	Enable	Optimal Default, Failsafe Default
	Disable	
Enables Hyper Threading (Software Method to Enable/Disable Logical Processor threads).		
X2APIC Opt Out	Enable	
	Disable	Optimal Default, Failsafe Default
Enable/Disable X2APIC_OPT_OUT bit		

### 3.6.5 Advanced Power Management Configuration




### 3.6.5.1 CPU C State Control



Options Summary		
Enable Monitor	Disable	
MWAIT	Enable	Optimal Default, Failsafe Default
Allows Monitor and MWAIT instructions.		

## 3.7 Setup Submenu: Security



### Change User/Administrator Password


If an Administrator Password is set, it will be required during boot up, or when the user enters the Setup utility. Please Note that a User Password does not provide access to many of the features in the Setup utility.

Select the password you wish to set, press Enter to open a dialog box to enter your password (you can enter no more than six letters or numbers). Press Enter to confirm your entry, after which you will be prompted to retype your password for a final confirmation. Press Enter again after you have retyped it correctly.

### Removing the Password


Highlight this item and type in the current password. At the next dialog box press Enter to disable password protection.

### 3.7.1 Secure Boot



Options Summary		
Secure Boot	Disabled	Optimal Default, Failsafe Default
	Enabled	
Secure Boot feature is Active if Secure Boot is Enabled, Platform Key(PLK) is enrolled and the System is in User mode. The mode change requires platform reset		
Secure Boot Mode	Standard	
	Custom	Optimal Default, Failsafe Default
Secure Boot mode options: Standard or Custom. In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication		
Restore Factory Keys	Force System to User Mode. Install factory default Secure Boot key databases.	
Reset To Setup Mode	Delete all Secure Boot key databases from NVRAM	

### 3.7.1.1 Key Management



Options Summary		
Factory Key Provision	Disabled Enabled	Optimal Default, Failsafe Default
Install factory default Secure Boot keys after the platform reset and while the System is in Setup mode		
Restore Factory Keys	Force System to User Mode. Install factory default Secure Boot key databases.	
Reset To Setup Mode	Delete all Secure Boot key databases from NVRAM	
Export Secure Boot variables	Copy NVRAM content of Secure Boot variables to files in a root folder on a file system device	
Enroll Efi Image	Allow the image to run in Secure Boot mode. Enroll SHA256 Hash certificate of a PE image into Authorized Signature Database (db)	
Remove 'UEFI CA' from DB	Device Guard ready system must not list 'Microsoft UEFI CA' Certificate in Authorized Signature database (db)	
Restore DB defaults	Restore DB variable to factory defaults	

## Secure Boot Variables

Enroll Factory Defaults or load certificates from a file:


1. Public Key Certificate in:
  - a) EFI\_SIGNATURE\_LIST
  - b) EFI\_CERT\_X509 (DER encoded)
  - c) EFI\_CERT\_RSA2048 (bin)
  - d) EFI\_CERT\_SHAXXX
2. Authenticated UEFI Variable
3. EFI PE/COFF Image(SHA256)

Key Source:

Default, External, Mixed



### 3.8 Setup Submenu: Boot



Options Summary		
Quiet Boot	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable Quiet Boot option.		
Network Stack	Disabled	Optimal Default, Failsafe Default
	Enabled	
Enable/Disable UEFI Network Stack.		
CSM Support	Disabled	Optimal Default, Failsafe Default
	Enabled	
Enable/Disable CSM Support.		
FIXED BOOT ORDER Priorities		Sets the system boot order

### 3.9 Setup Submenu: Save & Exit



Options Summary	
Save Changes and Reset	Reset the system after saving the changes.
Discard Changes and Exit	Exit system setup without saving any changes.
Restore Defaults	Restore/Load Default values for all the setup options.

# Chapter 4

---

Driver Installation

## 4.1 Driver Download/Installation

---

Drivers for the ARES-WH10 can be downloaded from the product page on the AAEON website by following this link:

<https://www.aaeon.com/en/p/intel-ice-lake-xeon-server-board-ares-whi0>

Download the driver(s) you need, extract them to their respective folders and follow the steps below to install them.

### Step 1 – Install Chipset Drivers

1. Open the **Chipset-10.1.18736.8270-Public-Server-MUP** folder
2. Run the **SetupChipset.exe** in the folder
3. Follow the instructions
4. Drivers will be installed automatically

### Step 2 – Install Graphics Drivers

1. Open the **SM750 WDDM2.0 v10.00.18.00-1119-sign(MS)-60028** folder
2. Run the **setup.exe** file in the folder
3. Follow the instructions
4. Drivers will be installed automatically

### Step 3 – Install Network Driver

1. Open the **Intel LAN 26.6** folder, then open the **Wired\_driver\_26.6\_x64** subfolder
2. Run the **Wired\_driver\_26.6\_x64.exe** file in the subfolder
3. Follow the instructions
4. Drivers will be installed automatically

#### Step 4 – Install Audio Driver

1. Open the **Audio Driver V8978** folder
2. Run the **Setup.exe** file in the folder
3. Follow the instructions
4. Drivers will be installed automatically