



SRG-IMX8PL

IoT Gateway System

User's Manual 2nd Ed

Copyright Notice

This document is copyrighted, 2025. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, AAEON assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

AAEON reserves the right to make changes in the product design without notice to its users.

Acknowledgement

All other products' name or trademarks are properties of their respective owners.

- Microsoft Windows® is a registered trademark of Microsoft Corp.
- NXP is a trademark NXP B.V.
- Arm® and Cortex® are registered trademarks of Arm Limited (or its subsidiaries)
- ITE is a trademark of Integrated Technology Express, Inc.
- IBM and VGA are trademarks of International Business Machines Corporation.
- Ubuntu and Canonical are registered trademarks of Canonical Ltd.
- Debian is a registered trademark owned by Software in the Public Interest, Inc.
- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Realtek is a trademark of Realtek Semiconductor Corporation

All other product names or trademarks are properties of their respective owners.

Omission of a product name from this list does not imply any claim to ownership by the publisher of this document.

Packing List

Before setting up your product, please make sure the following items have been shipped:

Item	Quantity
● SRG-IMX8PL	1
● 2pin 3.81mm Power Terminal block w/lock	1
● 18pin 2.54mm Phoenix plug in Connector/lock	1

If any of these items are missing or damaged, please contact your distributor or sales representative immediately.

About this Document

This User's Manual contains all the essential information, such as detailed descriptions and explanations on the product's hardware and software features (if any), its specifications, dimensions, jumper/connector settings/definitions, and driver installation instructions (if any), to facilitate users in setting up their product.

Users may refer to the product page on AAEON.com for the latest version of this document.

Safety Precautions

Please read the following safety instructions carefully. It is advised that you keep this manual for future references

1. All cautions and warnings on the device should be noted.
2. Make sure the power source matches the power rating of the device.
3. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
4. Always completely disconnect the power before working on the system's hardware.
5. No connections should be made when the system is powered as a sudden rush of power may damage sensitive electronic components.
6. If the device is not to be used for a long time, disconnect it from the power supply to avoid damage by transient over-voltage.
7. Always disconnect this device from any AC supply before cleaning.
8. While cleaning, use a damp cloth instead of liquid or spray detergents.
9. Make sure the device is installed near a power outlet and is easily accessible.
10. Keep this device away from humidity.
11. Place the device on a solid surface during installation to prevent falls
12. Do not cover the openings on the device to ensure optimal heat dissipation.
13. Watch out for high temperatures when the system is running.
14. Do not touch the heat sink or heat spreader when the system is running
15. Never pour any liquid into the openings. This could cause fire or electric shock.
16. As most electronic components are sensitive to static electrical charge, be sure to ground yourself to prevent static charge when installing the internal components. Use a grounding wrist strap and contain all electronic components in any static-shielded containers.

17. If any of the following situations arises, please the contact our service personnel:
 - i. Damaged power cord or plug
 - ii. Liquid intrusion to the device
 - iii. Exposure to moisture
 - iv. Device is not working as expected or in a manner as described in this manual
 - v. The device is dropped or damaged
 - vi. Any obvious signs of damage displayed on the device
18. **DO NOT LEAVE THIS DEVICE IN AN UNCONTROLLED ENVIRONMENT WHERE THE STORAGE TEMPERATURE IS BELOW -40° C (-40°F) OR ABOVE 80°C (176°F) TO PREVENT DAMAGE.**

FCC Statement

Warning!



This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Caution:

There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.

Attention:

Il y a un risque d'explosion si la batterie est remplacée de façon incorrecte. Ne la remplacer qu'avec le même modèle ou équivalent recommandé par le constructeur. Recycler les batteries usées en accord avec les instructions du fabricant et les directives gouvernementales de recyclage.

China RoHS Requirements (CN)

产品中有毒有害物质或元素名称及含量

AAEON System

QQ4-381 Rev.A2

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板 及其电子组件	×	○	○	○	○	○
外部信号 连接器及线材	×	○	○	○	○	○
外壳	○	○	○	○	○	○
中央处理器 与内存	×	○	○	○	○	○
硬盘	×	○	○	○	○	○
液晶模块	×	○	○	○	○	○
光驱	×	○	○	○	○	○
触控模块	×	○	○	○	○	○
电源	×	○	○	○	○	○
电池	×	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。
○：表示该有毒有害物质在该部件所有均质材料中的含量均在 GB/T 26572 标准规定的限量要求以下。
×：表示该有害物质的某一均质材料超出了 GB/T 26572 的限量要求，然而该部件仍符合欧盟指令 2011/65/EU 的规范。
环保使用期限(EFUP (Environmental Friendly Use Period))：10 年
备注：
一、此产品所标示之环保使用期限，系指在一般正常使用状况下。
二、上述部件物质中央处理器、内存、硬盘、光驱、电源为选购品。
三、上述部件物质液晶模块、触控模块仅一体机产品适用。

China RoHS Requirement (EN)

Name and content of hazardous substances in product

AAEON System

QO4-381 Rev.A2

Part Name	Hazardous Substances					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
PCB Assemblies	×	○	○	○	○	○
Connector and Cable	×	○	○	○	○	○
Chassis	○	○	○	○	○	○
CPU and Memory	×	○	○	○	○	○
Hard Disk	×	○	○	○	○	○
LCD Modules	×	○	○	○	○	○
CD-ROM/DVD-ROM	×	○	○	○	○	○
Touch Modules	×	○	○	○	○	○
Power	×	○	○	○	○	○
Battery	×	○	○	○	○	○
The table is prepared in accordance with the provisions of SJ/T 11364. ○ : Indicates that said hazardous substance contained in all of the homogenous materials for this product is below the limit requirement of GB/T 26572. × : Indicates that said hazardous substance contained in at least one of the homogenous materials used for this part is above the limit requirement of GB/T 26572. But this product still be compliance with 2011/65/EU Directive (allowed with 2011/65/EU Annex III of RoHS exemption with number 6(c),7(a),7(c)-1). EFUP (Environment Friendly Use Period) value: 10 years. Notes: 1. This product defined period of use is under normal condition. 2. In above part, CPU/Memory/ Hard Disk/CD-ROM/DVD-ROM/ Power are optional. 3. In above part, LCD Modules/ Touch Modules are for all-in-one product model.						

Table of Contents

- Chapter 1 - Product Specifications..... 1**
 - 1.1 Specifications..... 2
 - 1.2 Block Diagram..... 4
- Chapter 2 – Hardware Information 5**
 - 2.1 Dimensions 6
 - 2.2 Jumpers and Connectors 8
 - 2.3 List of Connectors 10
 - 2.3.1 SPI/I2C/GPIO Connector (CN4) 11
 - 2.3.2 Full-size Mini Card Slot (CN12) 12
 - 2.3.3 Micro SD Slot (CN16) 14
 - 2.3.4 Audio Port (CN27)..... 15
 - 2.3.5 Debug Port (CN30) 16
 - 2.3.6 RTC Battery Connector (CN32) 17
 - 2.3.7 DC Power (CN38) 18
 - 2.3.8 RS-232/422/485 COM Port 1, Port 2 (CN70) 19
 - 2.3.9 UART Port 1/Port 3 Connector (CN71) 21
 - 2.3.10 M.2 2230 E-Key Slot (CN140)..... 22
 - 2.3.11 HDMI Port (CN141) 24
 - 2.3.12 RJ-45 LAN Port 1/Port 2 (CN145)..... 25
 - 2.3.13 USB 3.2 Port 1/Port 2 (CN146) 26
 - 2.3.14 Internal USB 2.0 Connector (CN147) 27
 - 2.3.15 UART Port 2/Port 4 Connector (CN149)..... 28
 - 2.3.16 Boot Selection (SW3)..... 29
- Chapter 3 - Product Setup and Configuration..... 30**
 - 3.1 System Account Management 31
 - 3.1.1 Debug Console..... 31

3.1.2	Log In.....	35
3.2	I/O Control Command and Example.....	35
3.2.1	CANBus	35
3.2.2	Ethernet.....	36
3.2.3	PCIe (M.2 E-Key).....	38
3.2.4	RTC	39
3.2.5	SD Card	39
3.2.6	Serial.....	41
3.2.6.1	RS-232	41
3.2.6.2	RS-422	43
3.2.6.3	RS-485	44
3.2.6.4	UART2	46
3.2.7	TPM.....	47
3.2.8	USB.....	48
3.2.9	Watchdog Timer.....	49
3.3	Wireless Control Command and Example.....	53
3.3.1	4G.....	53
3.3.2	Bluetooth.....	56
3.3.3	Wi-Fi.....	57
3.3.3.1	Wi-Fi Connect	57
3.3.3.2	Wi-Fi AP Mode.....	58
3.4	HDMI.....	61
3.5	OS Installation.....	62
3.5.1	Flash SD Card.....	62
3.5.2	Flash eMMC.....	63
3.5.3	Check Version.....	64

Appendix A – Mating Connectors 65

A.1	List of Mating Connectors and Cables	66
-----	--	----

Chapter 1

Product Specifications

1.1 Specifications

System	
Processor	NXP i.MX8M Plus Quad-Core Arm® Cortex®-A53, up to 1.6 GHz (Default: w/ NPU, Optional: w/o NPU)
Memory	Onboard LPDDR4, up to 4GB (8GB by request)
Storage	eMMC 5.1 16GB/32GB (Optional: 64GB/128GB) Micro SD Card x 1
Real Time Clock	RTC x 1, with 3V CR2032H Lithium Battery
Security	TPM 2.0 (Optional)
Indicator	Programmable LED Control x 3
Cellular	Full-size Mini Card x 1 (USB Signal)
Wireless LAN	M.2 2230 E-Key x 1 (USB, PCIe)
Operating System	Debian 11 (Optional: Yocto 4.0, Android™ 13, Windows® 10 IoT)
Support Protocol	Modbus, MQTT, OPC UA
I/O	
Serial Port	RS-232/422/485 (4-wire) x 2
Ethernet	RJ-45 Gigabit Ethernet x 2 (supports IEEE 1588, TSN, integrated RGMII)
USB	USB 3.0 Gen 1 x 2 (Rear I/O) USB 2.0 x 1 (Pin Header)
ADC	—
Audio	Line Out x 1 (Optional)
DI/DO	—
CANBus	CAN-FD x 2 CH, Phoenix Connector
Display	HDMI 2.0 x 1

I/O

Power Connector	2-Pin 3.81mm Pitch Phoenix Connector
Debug Port	Micro USB x 1
Expansion Slot	M.2 2230 E-Key x 1, support Wi-Fi/BT module Full-size Mini Card x 1, support 4G module
Other	—


Power Supply

Power Requirement	DC 9V ~ 36V (Optional: 12V)
Power Consumption	9.36W (Full Loading)
MTBF	1,699,754 Hours

Environmental

Dimension	4.25" x 3.12" x 1.69" (108mm x 79.5mm x 43mm)
Weight	1.01 lb. (0.46Kg)
Mounting	Wall Mount DIN Rail (Optional)
Operating Temperature	-40°F ~ 176°F (-40°C ~ 80°C)
Storage Temperature	-40°F ~ 176°F (-40°C ~ 80°C)
Operating Humidity	0% ~ 90% relative humidity, non-condensing
Certification	CE/FCC Class A
Shock	Sinusoidal vibration to IEC 60068-2-27 10G peak acceleration (11 m sec. duration), operation 20G peak acceleration (11 m sec. duration), non-operation
Vibration	5-500Hz; 2grms
Drop	ISTA PROJECT 1A

1.2 Block Diagram




Chapter 2


Hardware Information

2.1 Dimensions

System




PCBA




2.2 Jumpers and Connectors

Component Side



Solder Side





2.3 List of Connectors

Please refer to the table below for all of the board's connectors that you can configure for your application

Label	Function
CN4	SPI/I2C/GPIO Connector
CN12	Full-size Mini Card Slot
CN16	Micro SD Slot
CN25	LVDS Port Inverter/Backlight Connector
CN26	LVDS Connector
CN27	Audio Connector
CN30	Debug Port
CN32	RTC Battery Connector
CN38	DC Power
CN70	COM Port 1/Port 2 (RS-232/422/485)
CN71	UART Port 1/Port 3 Connector
CN140	M.2 2230 E-Key Slot
CN141	HDMI Port
CN145	RJ-45 LAN Port 1/Port 2
CN146	USB 3.2 Port 1/Port 2
CN147	Internal USB 2.0 Connector
CN149	UART Port 2/Port 4 Connector
SW3	Boot Selection

Note: Some interfaces are only available via board-level connectors. For more information regarding interfaces specific to the SRG-IMX8PL, please see specifications in chapter 1.



2.3.1 SPI/I2C/GPIO Connector (CN4)



Pin	Pin Name	Signal Type	Signal Level
1	ECSPI_SS0	OUT	+3.3V
2	I2C_SCL	OUT	+3.3V
3	ECSPI_MOSI	OUT	+3.3V
4	I2C_SDA	I/O	+3.3V
5	ECSPI_MISO	IN	+3.3V
6	GPIO_3	I/O	+3.3V
7	ECSPI_SCLK	OUT	+3.3V
8	GPIO_4	I/O	+3.3V

Note: Pitch = 1.27mm.

2.3.2 Full-size Mini Card Slot (CN12)



Pin	Pin Name	Signal Type	Signal Level
1	NC		
2	+3.3VSB	PWR	+3.3V
3	NC		
4	GND	GND	
5	NC		
6	NC		
7	NC		
8	NC		
9	GND	GND	
10	NC		
11	NC		
12	NC		
13	NC		
14	NC		
15	GND	GND	
16	NC		
17	NC		
18	GND	GND	
19	NC		
20	W_DISABLE# (Note 1)	OUT	+3.3V
21	GND	GND	
22	PERST#	OUT	+3.3V
23	NC		

Pin	Pin Name	Signal Type	Signal Level
24	+3.3VSB	PWR	+3.3V
25	NC		
26	GND	GND	
27	GND	GND	
28	NC		
29	GND	GND	
30	SMB_CLK (Note 1)	I/O	+3.3V
31	NC		
32	SMB_DATA (Note 1)	I/O	+3.3V
33	NC		
34	GND	GND	
35	GND	GND	
36	USB_D-	DIFF	
37	GND	GND	
38	USB_D+	DIFF	
39	+3.3VSB	PWR	+3.3V
40	GND	GND	
41	+3.3VSB	PWR	+3.3V
42	NC		
43	NC		
44	NC		
45	NC		
46	NC		
47	NC		
48	NC		
49	NC		
50	GND	GND	
51	NC		
52	+3.3VSB	PWR	+3.3V


Note 1: The function is disabled by unmounted 0ohm jumper.

W_DISABLE#: R333, SMB_CLK: R328, SMB_DATA: R326

Note 2: The driving current supports up to 2A.



Note 3: For 4G full-size mini card.

2.3.3 Micro SD Slot (CN16)





Pin	Pin Name	Signal Type	Signal Level
1	SD_DAT2	I/O	+3.3V
2	SD_DAT3	I/O	+3.3V
3	SD_CMD	OUT	+3.3V
4	SD_VDD	PWR	+3.3V
5	SD_CLK	OUT	+3.3V
6	SD_VSS	GND	
7	SD_DAT0	I/O	+3.3V
8	SD_DAT1	I/O	+3.3V

2.3.4 Audio Port (CN27)



Pin	Pin Name	Signal Type	Signal Level
1	LINE_R_OUT	OUT	+3.3V
2	MIC_R	IN	+3.3V
3	LINE_L_OUT	OUT	+3.3V
4	MIC_L	IN	+3.3V
5	NC		
6	NC		
7	GND_AUDIO	GND	
8	GND_AUDIO	GND	
9	NC		
10	LINE_R_IN	IN	+3.3V
11	+VDD_AUDIO	PWR	+3.3V
12	LINE_L_IN	IN	+3.3V




2.3.5 Debug Port (CN30)



Pin	Pin Name	Signal Type	Signal Level
1	+5VSB	PWR	5V
2	USB0_DN	DIFF	
3	USB0_DP	DIFF	
4	USB0_ID	IN	3.3V
5	GND	GND	

Note 1: USB to UART (XR21V1410) debug port.



2.3.6 RTC Battery Connector (CN32)



+RED
-BLACK

Pin	Pin Name	Signal Type	Signal Level
1	+3.3V	PWR	+3.3V
2	GND	GND	

2.3.7 DC Power (CN38)





Pin	Pin Name	Signal Type	Signal Level
1	DC_IN	PWR	+9~36V / +12V
2	GND	GND	

Note 1: Wide range input voltage from +9V to +36V or +12V for specified version.

Note 2: Please check the input voltage description on product label before inserting power.

2.3.8 RS-232/422/485 COM Port 1, Port 2 (CN70)



Pin	Pin Name	Signal Type	Signal Level
1	TX1	OUT	±9V / ±5V
2	RX1	IN	±9V / ±5V
3	DCD1	IN	±9V / ±5V
4	DTR1	OUT	±9V / ±5V
5	RTS1	OUT	±9V / ±5V
6	CTS1	IN	±9V / ±5V
7	GND	GND	
8	CAN1_H	DIFF	
9	CAN1_L	DIFF	
10	TX2	OUT	±9V / ±5V
11	RX2	IN	±9V / ±5V
12	DCD2	IN	±9V / ±5V
13	DTR2	OUT	±9V / ±5V
14	RTS2	OUT	±9V / ±5V
15	CTS2	IN	±9V / ±5V
16	GND	GND	
17	CAN2_H	DIFF	
18	CAN2_L	DIFF	

COM Port 1 RS-422			
Pin	Pin Name	Signal Type	Signal Level
7	GND	GND	
3	RS422_TX-	OUT	±9V / ±5V

COM Port 1 RS-422			
Pin	Pin Name	Signal Type	Signal Level
2	RS422_TX+	OUT	±9V / ±5V
1	RS422_RX+	IN	±9V / ±5V
4	RS422_RX-	IN	±9V / ±5V

COM Port 1 RS-485			
Pin	Pin Name	Signal Type	Signal Level
7	GND	GND	
3	RS485_D-	I/O	±9V / ±5V
2	RS485_D+	I/O	±9V / ±5V



COM Port 2 RS-422			
Pin	Pin Name	Signal Type	Signal Level
16	GND	GND	
12	RS422_TX-	OUT	±9V / ±5V
11	RS422_TX+	OUT	±9V / ±5V
10	RS422_RX+	IN	±9V / ±5V
13	RS422_RX-	IN	±9V / ±5V

COM Port 2 RS-485			
Pin	Pin Name	Signal Type	Signal Level
16	GND	GND	
12	RS485_D-	I/O	±9V / ±5V
11	RS485_D+	I/O	±9V / ±5V

Note 1: COM 1/2 RS-232/422/485 can be set by setting and the default is RS-232.

Note 2: Set signal level ±9V / ±5V by PSP5/PSP6 short.



2.3.9 UART Port 1/Port 3 Connector (CN71)



Pin	Pin Name	Signal Type	Signal Level
1	UART1_TXD	OUT	+3.3V
2	UART1_RTS	OUT	+3.3V
3	UART1_RXD	IN	+3.3V
4	UART1_CTS	IN	+3.3V
5	GND	GND	
6	UART3_TXD	OUT	+3.3V
7	UART3_RTS	OUT	+3.3V
8	UART3_RXD	IN	+3.3V
9	UART3_CTS	IN	+3.3V

Note 1: UART port and COM port cannot be used simultaneously.

2.3.10 M.2 2230 E-Key Slot (CN140)



Pin	Pin Name	Signal Type	Signal Level
1	GND		
2	+3.3VSB	PWR	+3.3V
3	USB_D+	DIFF	
4	+3.3VSB	PWR	+3.3V
5	USB_D-	DIFF	
6	NC		
7	GND	GND	
8	NC		
9	NC		
10	NC		
11	NC		
12	NC		
13	NC		
14	NC		
15	NC		
16	NC		
17	NC		
18	NC		
19	NC		
20	NC		
21	NC		
22	NC		
23	NC		

Pin	Pin Name	Signal Type	Signal Level
32	NC		
33	GND	GND	
34	NC		
35	PCIE_TX+	DIFF	
36	NC		
37	PCIE_TX-	DIFF	
38	NC		
39	GND	GND	+3.3V
40	NC		
41	PCIE_RX+	DIFF	+3.3V
42	NC		
43	PCIE_RX-	DIFF	
44	NC		
45	GND	GND	
46	NC		
47	PCIE_CLK+	DIFF	
48	NC		
49	PCIE_CLK-	DIFF	
50	NC		
51	GND		
52	PERST#	OUT	+3.3V
53	PCIE_CLK_REQ#	IN	
54	W_DISABLE2# (Note 1)	OUT	+3.3V
55	PCIE_WAKE#	IN	
56	W_DISABLE1# (Note 1)	OUT	+3.3V
57	GND	GND	
58	SMB_SDA (Note 1)	I/O	+3.3V
59	NC		
60	SMB_SCL (Note 1)	OUT	+3.3V
61	NC		
62	NC		
63	GND	GND	
64	TP		
65	NC		
66	NC		
67	NC		
68	NC		
69	GND	GND	
70	NC		

Pin	Pin Name	Signal Type	Signal Level
71	NC		
72	+V3P3A	PWR	+3.3V
73	NC		
74	+V3P3A	PWR	+3.3V
75	GND	GND	


Note 1: The function is disabled by unmounted 0ohm jumper.

W_DISABLE2#: R95, W_DISABLE1#: R94, SMB_SDA: R96, SMB_SCL: R97

Note 2: The driving current supports up to 2A.

Note 3: For Wi-Fi/BT/Hailo-8/Hailo-8L card.


2.3.11 HDMI Port (CN141)



Pin	Pin Name	Signal Type	Signal Level
1	HDMI_TX2+	DIFF	
2	GND	GND	
3	HDMI_TX2-	DIFF	
4	HDMI_TX1+	DIFF	
5	GND	GND	
6	HDMI_TX1-	DIFF	
7	HDMI_TX0+	DIFF	
8	GND	GND	
9	HDMI_TX0-	DIFF	

Pin	Pin Name	Signal Type	Signal Level
10	HDMI_CLK+	DIFF	
11	GND	GND	
12	HDMI_CLK-	DIFF	
13	HDMI_CEC	OUT	+3.3V
14	HDMI_Utility	OUT	+1.8V
15	DDC_CLK	I/O	+5V
16	DDC_DATA	I/O	+5V
17	GND	GND	
18	+V5S	PWR	+5V
19	HDMI_HPD	OUT	+1.8V

2.3.12 RJ-45 LAN Port 1/Port 2 (CN145)





Pin	Pin Name	Signal Type	Signal Level
L_1	LAN1_MDIO_P	DIFF	
L_2	LAN1_MDIO_N	DIFF	
L_3	LAN1_MDIO_P	DIFF	
L_4	LAN1_MDIO_N	DIFF	
L_5	GND	GND	
L_6	GND	GND	
L_7	LAN1_MDIO_P	DIFF	
L_8	LAN1_MDIO_N	DIFF	
L_9	LAN1_MDIO_P	DIFF	
L_10	LAN1_MDIO_N	DIFF	
R_1	LAN2_MDIO_P	DIFF	

Pin	Pin Name	Signal Type	Signal Level
R_2	LAN2_MDI0_N	DIFF	
R_3	LAN2_MDI1_P	DIFF	
R_4	LAN2_MDI1_N	DIFF	
R_5	GND	GND	
R_6	GND	GND	
R_7	LAN2_MDI2_P	DIFF	
R_8	LAN2_MDI2_N	DIFF	
R_9	LAN2_MDI3_P	DIFF	
R_10	LAN2_MDI3_N	DIFF	

Note 1: External ACTIVE/LINK/SPEED LEDs.

2.3.13 USB 3.2 Port 1/Port 2 (CN146)




Pin	Pin Name	Signal Type	Signal Level
1	+5VSB	PWR	+5V
2	USB1_DN	DIFF	
3	USB1_DP	DIFF	
4	GND	GND	
5	USB1_RXN	DIFF	
6	USB1_RXP	DIFF	
7	GND	GND	
8	USB1_TXN	DIFF	
9	USB1_TXP	DIFF	

Pin	Pin Name	Signal Type	Signal Level
10	+5VSB	PWR	+5V
11	USB2_DN	DIFF	
12	USB2_DP	DIFF	
13	GND	GND	
14	USB2_RXN	DIFF	
15	USB2_RXP	DIFF	
16	GND	GND	
17	USB2_TXN	DIFF	
18	USB2_TXP	DIFF	

Note: The driving current supports up to 2A.



2.3.14 Internal USB 2.0 Connector (CN147)



Pin	Pin Name	Signal Type	Signal Level
1	+5VSB	PWR	+5V
2	USB3_DN	DIFF	
3	USB3_DP	DIFF	
4	GND	GND	
5	GND	GND	

Note 1: The driving current supports up to 2A.

2.3.15 UART Port 2/Port 4 Connector (CN149)





Pin	Pin Name	Signal Type	Signal Level
1	UART2_TXD	OUT	+3.3V
2	UART4_TXD	OUT	+3.3V
3	UART2_RXD	IN	+3.3V
4	UART4_RXD	IN	+3.3V
5	UART2_RTS	OUT	+3.3V
6	GND	GND	
7	UART2_CTS	IN	+3.3V
8	NC		

Note 1: UART port and COM port cannot be used simultaneously.

Note 2: Pitch = 1.27mm.

2.3.16 Boot Selection (SW3)



Pin	Pin Name	Signal Type	Signal Level
1	BOOT_MODE3	IN	+1.8V
2	BOOT_MODE2	IN	+1.8V
3	BOOT_MODE1	IN	+1.8V
4	BOOT_MODE0	IN	+1.8V

Boot Mode Table

BOOT_MODE3	BOOT_MODE2	BOOT_MODE1	BOOT_MODE0	Boot Modes
0	0	0	0	Boot from internal fuses
0	0	0	1	USB serial download
0	0	1	0	USDHC3 (eMMC boot only, SD3 8-bit)
0	0	1	1	USDHC2 (SD boot only, SD2)

Note 1: Number side is 1 (HIGH) and ON side is 0 (LOW).

Chapter 3

Product Setup and Configuration


3.1 System Account Management

3.1.1 Debug Console

When connecting a PC or laptop to the SRG-IMX8PL system, it is recommended to use PuTTY with Windows 10. Users can download the software from the PuTTY website.:

Step 1: Download the PuTTY tools: <https://www.putty.org/>.

Step 2: Switch jumper (SW3) to 0010. (Factory default settings).



Switch Pin:



PIN 1, 2, 4: Switch is OFF.


PIN 3: Switch is ON.

Step 3: Connect the gateway via a USB cable. Connect your computer to the SRG-IMX8PL using the Micro USB port.

Step 4: Open Device Manager and locate Multifunction Composite Gadget. Double click on the device. A pop-up should appear, with a notice that the CDC Serial is unrecognized.

Download debug port driver: (usb->uart) :

<https://www.maxlinear.com/product/interface/uarts/usb-uarts/xr21v1410>




←  Update Drivers - XR21V1410 USB UART (COM23)

Windows has successfully updated your drivers

Windows has finished installing the drivers for this device:




XR21V1410 USB UART



Step 5: Setting the putty configuration.

Open the putty and use the settings to log into the system.




```
[ 390.926963] IPv6: ADDRCONF(NETDEV_CHANGE): can1: link becomes ready
```

Step 2: candump CAN0

```
sudo candump can0&
```

```
[ 542.354900] can: controller area network core
[ 542.355112] NET: Registered PF_CAN protocol family
[ 542.370559] can: raw protocol
```

Step 3: candump CAN1

```
candump can1&
```

```
cansend can1 111#8877665544332211
```

```
can0  111  [8]  88 77 66 55 44 33 22 11
```

3.2.2 Ethernet

This section will show you how to check and setup the network settings.

NETWORKPROFILE ->It should be:

Profile	Support Hardware
eth1	LAN 1 
eth0	LAN 2 
Modem	4G LTE Module

Step 1: Connect the cable, and check the Ethernet device.

Command:

```
$ sudo ifconfig
```

```
eth0: flags=4163<UP,BROADCAST,RUNNING,MULTICAST> mtu 1500
      inet 192.168.1.209 netmask 255.255.255.0 broadcast 192.168.1.255
      inet6 fe80::bba8:9997:2486:4a25 prefixlen 64 scopeid 0x20<link>
      ether 00:07:32:a5:a5:88 txqueuelen 1000 (Ethernet)
      RX packets 29 bytes 4058 (3.9 KiB)
      RX errors 0 dropped 8 overruns 0 frame 0
      TX packets 23 bytes 3017 (2.9 KiB)
      TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

eth1: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
      ether 00:07:32:a5:a5:89 txqueuelen 1000 (Ethernet)
      RX packets 0 bytes 0 (0.0 B)
      RX errors 0 dropped 0 overruns 0 frame 0
      TX packets 0 bytes 0 (0.0 B)
      TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
      device interrupt 222

lo: flags=73<UP,LOOPBACK,RUNNING> mtu 65536
      inet 127.0.0.1 netmask 255.0.0.0
      inet6 ::1 prefixlen 128 scopeid 0x10<host>
      loop txqueuelen 1000 (Local Loopback)
      RX packets 10 bytes 1612 (1.5 KiB)
      RX errors 0 dropped 0 overruns 0 frame 0
      TX packets 10 bytes 1612 (1.5 KiB)
      TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

Step 2: Ping test:

```
Ping 8.8.8.8
```

```
PING 8.8.8.8 (8.8.8.8) 56(84) bytes of data.
64 bytes from 8.8.8.8: icmp_seq=1 ttl=55 time=3.71 ms
64 bytes from 8.8.8.8: icmp_seq=2 ttl=55 time=2.88 ms
64 bytes from 8.8.8.8: icmp_seq=3 ttl=55 time=3.55 ms
```

3.2.3 PCIe (M.2 E-Key)

Host pin define:

```
SAI1_TXD6 ➔ Mini1_Reset_EN ➔ GPIO4_IO18  
SAI1_TXD7 ➔ Mini2_Reset_EN ➔ GPIO4_IO19
```

Reset CN12 mini card (USB interface) and CN140 M.2 E-Key (PCIe interface)

```
Set GPIO4_IO18 high.  
Set GPIO4_IO19 high.
```

Command:

```
gpioset 3 18=1 // Reset CN12 mini card  
gpioset 3 19=1 // Reset CN140 M.2 key E
```

You can run command to check when you insert an external card into the M.2 slot (CN140).

Command:

It can use the PCIe protocol to get some information.

```
root@pico-imx8mp:~# lspci  
00:00.0 PCI bridge: Synopsys, Inc. DWC usb3 / PCIe bridge (rev 01)  
01:00.0 Network controller: Realtek Semiconductor Co., Ltd. RTL8822CE 802.11ac PCIe Wireless Network Adapter
```

3.2.4 RTC

Step 1: Read rtc0 name.

```
cat /sys/class/rtc/rtc0/name
```

```
rtc-pcf85063 2-0051
```

PCF85063 is our default RTC .

Step 2: Read rtc1 name.

```
cat /sys/class/rtc/rtc1/name
```

```
snvs_rtc 30370000.snvs:snvs-rtc-lp
```

SNVS_RTC is the built-in RTC of the CPU.

3.2.5 SD Card

Step 1: Select the switch: 0x10 (emmc boot).

Step 2: lsblk

NAME	MAJ:MIN	RM	SIZE	RO	TYPE	MOUNTPOINTS
mmcblk2	179:0	0	29.1G	0	disk	
└─mmcblk2p1	179:1	0	128M	0	part	
└─mmcblk2p2	179:2	0	29G	0	part	/
mmcblk2boot0	179:32	0	4M	1	disk	
mmcblk2boot1	179:64	0	4M	1	disk	
mmcblk1	179:96	0	7.5G	0	disk	
└─mmcblk1p1	179:97	0	208M	0	part	
└─mmcblk1p2	179:98	0	7.1G	0	part	

mmcblk1: SD card

mmcblk2: emmc

Run command to mount SD card:

```
sudo mkdir -p /sd_boot
```

```
sudo mkdir -p /sd_rootfs
```

```
sudo mount /dev/mmcblk1p1 /sd_boot // Link sd_boot folder → sd card partition 1
```

```
sudo mount /dev/mmcblk1p2 /sd_rootfs // Link sd_rootfs folder → sd card partition 2
```

```
lsblk
```

NAME	MAJ:MIN	RM	SIZE	RO	TYPE	MOUNTPOINTS
mmcblk2	179:0	0	29.1G	0	disk	
└─mmcblk2p1	179:1	0	128M	0	part	
└─mmcblk2p2	179:2	0	29G	0	part	/
mmcblk2boot0	179:32	0	4M	1	disk	
mmcblk2boot1	179:64	0	4M	1	disk	
mmcblk1	179:96	0	7.5G	0	disk	
└─mmcblk1p1	179:97	0	208M	0	part	/sd_boot
└─mmcblk1p2	179:98	0	7.1G	0	part	/sd_rootfs

3.2.6 Serial


COM PortA			
/dev/ttymxc0	RS232	RS422	RS485
GPIO1_IO07	0	0	0
GPIO1_IO08	0	0	1
GPIO1_IO012	1	0	1

COM PortB			
/dev/ttymxc2	RS232	RS422	RS485
GPIO1_IO14	0	0	0
GPIO3_IO22	0	0	1
GPIO3_IO021	1	0	1

UART2	/dev/ttymxc1
-------	--------------

3.2.6.1 RS-232

Please refer to the red lines in the picture. Please connect the pin as follows.



Command:

```
gpioset 0 7=0
gpioset 0 8=0
gpioset 0 12=1
gpioset 0 14=0
gpioset 2 22=0
gpioset 2 21=1
stty -F /dev/ttymx0 -echo -onlcr 115200
stty -F /dev/ttymx2 -echo -onlcr 115200
cat /dev/ttymx0 &
cat /dev/ttymx2 &
```

```
echo hello > /dev/ttymx2
// You can see the hello string
```


```
root@pico-imx8mp:~# echo hello > /dev/ttymx2
root@pico-imx8mp:~# hello
```

```
echo hello > /dev/ttymx0
// You can see the hello string
```

```
root@pico-imx8mp:~# echo hello > /dev/ttymx0
root@pico-imx8mp:~# hello
```

3.2.6.2 RS-422

Please refer to the red lines in the picture. Please connect the pin as follows.



Command:

```
gpioset 0 7=0
gpioset 0 8=0
gpioset 0 12=0
gpioset 0 14=0
gpioset 2 22=0
gpioset 2 21=0
```

```
stty -F /dev/ttymx0 -echo -onlcr 115200
stty -F /dev/ttymx2 -echo -onlcr 115200
```

```
cat /dev/ttymx0 &
cat /dev/ttymx2 &
```

```
echo hello > /dev/ttymx2
// You can see the hello string
```


```
root@pico-imx8mp:~# echo hello > /dev/ttymx2
root@pico-imx8mp:~# hello
```

```
echo hello > /dev/ttymx0
// You can see the hello string
```

```
root@pico-imx8mp:~# echo hello > /dev/ttymx0
root@pico-imx8mp:~# hello
```

3.2.6.3 RS-485

Please refer to the red lines in the picture. Please connect the pin as follows.



	RS-485
RTS pin	Low: receiver High: sender
CTS pin	X

RS485 (Mode : 011)	It does'nt include termination resistor.
--------------------	--

Command:

Install python3 package: `apt -get install python3`

Set GPIO to RS485 mode:

`gpioset 0 7=0`

`gpioset 0 8=1`

`gpioset 0 12=1`

`gpioset 0 14=0`

`gpioset 2 22=1`

`gpioset 2 21=1`

Run RS485_test.py (com port A send data to com port B)


python3 RS485_test.py:

```
import serial  
comA = serial.Serial("/dev/ttymx0", 115200, timeout=1)  
comB = serial.Serial("/dev/ttymx2", 115200, timeout=1)  
comA.setRTS(0) #sender  
comB.setRTS(1) #receiver  
data_len = comA.write(b'test string')  
data = comB.read(data_len)  
print(data)  
comA.close()  
comB.close()
```

Result:

```
b'test string'
```

3.2.6.4 UART2



UART Port 2/Port 4 pin define: Please refer to table 2.4.17

Pin 1 and pin 3 are connected.

Pin 5 and pin 7 are connected together

Command:

```
stty -F /dev/ttymxcl crtscts
```

```
stty -F /dev/ttymxcl -echo -onlcr 115200
```

```
cat /dev/ttymxcl &
```

```
echo hello > /dev/ttymxcl
```

```
root@pico-imx8mp:/test# echo hello > /dev/ttymxcl
root@pico-imx8mp:/test# hello
```

3.2.7 TPM

Command:

```
tpm2_selftest
```

```
// Do TPM self-test
```

```
tpm2_getcap properties-fixed
```

```
// Get TPM chip information
```

Result:

```
TPM2_PT_FAMILY_INDICATOR
```

```
raw: 0x322E3000
```

```
value: "2.0" TPM2_PT_LEVEL:
```

```
raw: 0 TPM2_PT_REVISION:
```

```
raw: 0x8A
```

```
value: 138 TPM2_PT_DAY_OF_YEAR:
```

```
raw: 0x12F TPM2_PT_YEAR:
```

```
raw: 0x7E3 TPM2_PT_MANUFACTURER:
```

```
raw: 0x4E544300
```

```
value: "NTC" TPM2_PT_VENDOR_STRING_1:
```

```
raw: 0x4E504354
```

```
value: "NPCT" TPM2_PT_VENDOR_STRING_2:
```

```
raw: 0x37357800
```

```
value: "75x" TPM2_PT_VENDOR_STRING_3:
```

```
raw: 0x22212134
```

```
value: ""!4"
```

3.2.8 USB

Step 1: Run command: lsblk

NAME	MAJ:MIN	RM	SIZE	RO	TYPE	MOUNTPOINTS
mmcblk2	179:0	0	29.1G	0	disk	
└─mmcblk2p1	179:1	0	128M	0	part	
└─mmcblk2p2	179:2	0	29G	0	part	/
mmcblk2boot0	179:32	0	4M	1	disk	
mmcblk2boot1	179:64	0	4M	1	disk	
mmcblk1	179:96	0	7.5G	0	disk	
└─mmcblk1p1	179:97	0	208M	0	part	/sd_boot
└─mmcblk1p2	179:98	0	7.1G	0	part	/sd_rootfs

Step 2: Plug the USB storage into the SRG-IMX8PL.

Step 3: Run command: lsblk

NAME	MAJ:MIN	RM	SIZE	RO	TYPE	MOUNTPOINTS
sda	8:0	1	232.9G	0	disk	
└─sda1	8:1	1	232.9G	0	part	/media/KING
mmcblk2	179:0	0	29.1G	0	disk	
└─mmcblk2p1	179:1	0	128M	0	part	
└─mmcblk2p2	179:2	0	29G	0	part	/
mmcblk2boot0	179:32	0	4M	1	disk	
mmcblk2boot1	179:64	0	4M	1	disk	
mmcblk1	179:96	0	7.5G	0	disk	
└─mmcblk1p1	179:97	0	208M	0	part	/sd_boot
└─mmcblk1p2	179:98	0	7.1G	0	part	/sd_rootfs

USB device name: /dev/sda1

USB mount point: /media/xxxxxx

Ex: /media/KING is my USB storage.

You can run umount command if you want to remove the USB storage.

Ex:

```
sudo umount /media/KING/
```

You can run command as follows if you don't see the mountpoint (/media/KING) .

Ex:

```
sudo mkdir -p /media/KING
```

```
sudo mount /dev/sda1 /media/KING
```

3.2.9 Watchdog Timer

- (1) CPU built-in watchdog:

Run command as follows:

```
sw_wdt <timeout (second)> <sleep (sceond)> < 0 (ioctl) >
```

Ex: `sudo /usr/sbin/sw_wdt 180 60 0`

Every 60 seconds, the watchdog count will restart counting, otherwise watchdog will reset the CPU after 180 second.

sw_wdt source code:

wdt_driver_test.c:

```
#include "test_utils.h"

void help_info(void);

int main(int argc, char * const argv[])
{
    int fd, timeout, sleep_sec, test;
    print_name(argv);
    if (argc < 2) {
        help_info();
        return 1;
    }
    timeout = atoi(argv[1]);
    sleep_sec = atoi(argv[2]);
    if (sleep_sec <= 0) {
        sleep_sec = 1;
        printf("correct 0 or negative sleep time to %d seconds\n",
            sleep_sec);
    }
}
```

```

}

test = atoi(argv[3]);

printf("Starting wdt_driver (timeout: %d, sleep: %d, test: %s)\n",
timeout, sleep_sec, (test == 0) ? "ioctl" : "write");

fd = open("/dev/watchdog", O_WRONLY);

if (fd == -1) {
    perror("watchdog");
    exit(1);
}

printf("Trying to set timeout value=%d seconds\n", timeout);
ioctl(fd, WDIOC_SETTIMEOUT, &timeout);

printf("The actual timeout was set to %d seconds\n", timeout);
ioctl(fd, WDIOC_GETTIMEOUT, &timeout);

printf("Now reading back -- The timeout is %d seconds\n", timeout);

while (1) {
    if (test == 0) {
        ioctl(fd, WDIOC_KEEPAIVE, 0);
    } else {
        write(fd, "\0", 1);
    }

    sleep(sleep_sec);
}

print_result(argv);

return 0;
}

void help_info(void)
{
    printf("Usage: wdt_driver_test <timeout> <sleep> <test>\n");
}

```

```
printf("  timeout: value in seconds to cause wdt timeout/reset\n");
printf("  sleep: value in seconds to service the wdt\n");
printf("  test: 0 - Service wdt with ioctl(), 1 - with write()\n");
}
```

test_utils.h:

```
inline void print_name(char * const argv[])
{
    printf("\n---- Running < %s > test ----\n\n", argv[0]);
}

inline void print_result(char * const argv[])
{
    printf("\n---- Test < %s > ended ----\n\n", argv[0]);
}
```

(2) External watchdog

It uses an external watchdog device on the SRG-IMX8PL board. The CPU will be reset every 70 seconds if the watchdog times out.

WDI pin (GPIO2_IO08): Watchdog input. A falling edge must occur at WDI before the timeout (tWD) expires.

You must toggle the WDT pin high and low for the watchdog to restart counting.

Please refer to `/usr/sbin/watchdog.sh`.

```
#!/bin/bash
gpioset 18=0
while true
do
    gpioset 18=1
```

```
sleep 0.1
```

```
gpioset 1 8=0
```

```
sleep 4.9
```

```
done
```

You have to call `watchdog.sh` when booting.

Please refer to `watchdog.service` . It calls `/usr/sbin/watchdog.sh` when booting.

`watchdog.service`:

```
[Unit]
```

```
Description=WatchDog supervise
```

```
[Service]
```

```
Type=simple
```

```
ExecStart=/usr/sbin/watchdog.sh
```

```
Restart=always
```

```
[Install]
```

```
WantedBy=multi-user.target
```

3.3 Wireless Control Command and Example

3.3.1 4G

Insert the EG25G card (4G module) into the SRG-IMX8PL board (CN12).

GPIO2_IO00: This GPIO controls the 4G module power (CN12).

Commands:

```
gpioset 1 0=1 // This will turn off the 4G module power if GPIO2_IO00 is high.
```

```
gpioset 1 0=0 // This will turn on the 4G module power if GPIO2_IO00 is low.
```

4G wireless network connection.

Command:

```
systemctl enable ModemManager
```

```
systemctl start
```

```
ModemManager
```

```
mmcli --list-modems
```

```
root@pico-imx8mp:~# mmcli --list-modems
/org/freedesktop/ModemManager1/Modem/0 [Quectel] EG25
```

```
mmcli -m 0
```

General	dbus path: /org/freedesktop/ModemManager1/Modem/0 device id: 3d7e973c1d5e95f87075d2ddd20e959ff3fb92f7
Hardware	manufacturer: Quectel model: EG25 firmware revision: EG25GGBR07A07M2G supported: gsm-umts, lte current: gsm-umts, lte equipment id: 867698040211339
System	device: /sys/devices/platform/soc@0/32f10108.usb/38200000.usb/xhci-hcd.2.auto/usb3/3-1/3-1.3 drivers: option1, qmi_wwan_q plugin: quectel primary port: ttyUSB2 ports: ttyUSB0 (qcdm), ttyUSB1 (gps), ttyUSB2 (at), ttyUSB3 (at)
Status	unlock retries: sim-pin (3), sim-puk (10), sim-pin2 (3), sim-puk2 (10) state: registered power state: on access tech: lte signal quality: 100% (recent)
Modes	supported: allowed: 2g, 3g, 4g; preferred: none current: allowed: 2g, 3g, 4g; preferred: none
IP	supported: ipv4, ipv6, ipv4v6
3GPP	imei: 867698040211339 operator id: 46692 operator name: Chunghwa Telecom registration: home
3GPP EPS	ue mode of operation: cspc-2
SIM	dbus path: /org/freedesktop/ModemManager1/SIM/0

```
mmcli -m 0 -e
```

```
root@pico-imx8mp:~# mmcli -m 0 -e
successfully enabled the modem
```

```
nmcli -a
```

```
root@pico-imx8mp:~# nmcli -a
ttyUSB2: disconnected
"Quectel EG25-G"
gsm (option1, qmi_wwan_q), hw
```

```
nmcli c add con-name test type gsm ifname ttyUSB2 apn internet
```

```
Connection 'test' (2e0e655f-fdd3-42ba-bbca-24c15bedf59f) successfully added.
```

```
Command: ifconfig
```

```

root@Essential-BX1:~# ifconfig
eth0: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    ether 00:07:32:a5:a5:88 txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

eth1: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    ether 00:07:32:a5:a5:89 txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
    device interrupt 222

lo: flags=73<UP,LOOPBACK,RUNNING> mtu 65536
    inet 127.0.0.1 netmask 255.0.0.0
    inet6 ::1 prefixlen 128 scopeid 0x10<host>
    loop txqueuelen 1000 (Local Loopback)
    RX packets 10 bytes 1612 (1.5 KiB)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 10 bytes 1612 (1.5 KiB)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

ppp0: flags=4305<UP,POINTOPOINT,RUNNING,NOARP,MULTICAST> mtu 1500
    inet 10.40.215.21 netmask 255.255.255.255 destination 10.64.64.64
    inet6 fe80::fd8f:214d:8ee0:65a7 prefixlen 64 scopeid 0x20<link>
    inet6 fe80::e68d:d31a:48c9:b931 prefixlen 64 scopeid 0x20<link>
    inet6 2001:b400:e251:3309:5aal:6eed:db39:13fd prefixlen 64 scopeid 0x0<global>
    ppp txqueuelen 3 (Point-to-Point Protocol)
    RX packets 26 bytes 1790 (1.7 KiB)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 29 bytes 1600 (1.5 KiB)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

```

ping 8.8.8.8

```

root@pico-imx8mp:~# ping 8.8.8.8
PING 8.8.8.8 (8.8.8.8) 56(84) bytes of data.
64 bytes from 8.8.8.8: icmp_seq=1 ttl=253 time=118 ms
64 bytes from 8.8.8.8: icmp_seq=2 ttl=253 time=34.6 ms
64 bytes from 8.8.8.8: icmp_seq=3 ttl=253 time=110 ms

```

3.3.2 Bluetooth

Command:

```
$ bluetoothctl
# power on
# agent off
# agent NoInputNoOutput
# default-agent
# scan on // Find the K380 mac address
```

```
root@pico-imx8mp:~# bluetoothctl
Agent registered
[CHG] Controller 74:4C:A1:90:E8:F8 Pairable: yes
[bluetooth]# power on
Changing power on succeeded
[bluetooth]# agent off
Agent unregistered
[CHG] Controller 74:4C:A1:90:E8:F8 Pairable: no
[bluetooth]# agent NoInputNoOutput
Agent registered
[CHG] Controller 74:4C:A1:90:E8:F8 Pairable: yes
[bluetooth]# default-agent
Default agent request successful
[bluetooth]# scan on
```

Trust K380 mac address

```
# trust XX:XX:XX:XX:XX:XX
Pair K380 mac address
# pair XX:XX:XX:XX:XX:XX
# connect XX:XX:XX:XX:XX:XX
# info XX:XX:XX:XX:XX:XX
# scan off
```

```
[Keyboard K380]# info F4:73:35:75:CF:7B
Device F4:73:35:75:CF:7B (public)
  Name: Keyboard K380
  Alias: Keyboard K380
  Class: 0x00002540
  Icon: input-keyboard
  Paired: yes
  Trusted: yes
  Blocked: no
  Connected: yes
  WakeAllowed: yes
  LegacyPairing: yes
  UUID: Service Discovery Serve.. (00001000-0000-1000-8000-00805f9b34fb)
  UUID: Human Interface Device... (00001124-0000-1000-8000-00805f9b34fb)
  UUID: PnP Information (00001200-0000-1000-8000-00805f9b34fb)
  Modalias: usb:v046DpB342d4201
```

The Bluetooth device is connected successfully.

3.3.3 Wi-Fi

3.3.3.1 Wi-Fi Connect

Insert an M.2 WIFI module into the SRG-IMX8PL.



Set up your phone to use as a Wi-Fi hotspot.

nmcli radio wifi on

nmcli dev wifi connect 'SSID' password 'XXXXXXXX'

ifconfig

```
wlan0: flags=4163<UP,BROADCAST,RUNNING,MULTICAST> mtu 1500
    inet 192.168.123.208 netmask 255.255.255.0 broadcast 192.168.123.255
    inet6 2001:b400:e2df:7ed3:1899:3369:a373:6fef prefixlen 64 scopeid 0x0<global>
    inet6 fe80::1efe:8f38:33ba:fc47 prefixlen 64 scopeid 0x20<link>
    ether 74:4c:a1:90:e8:f7 txqueuelen 1000 (Ethernet)
    RX packets 52 bytes 6372 (6.2 KiB)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 69 bytes 9975 (9.7 KiB)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

ping 8.8.8.8

```
root@pico-imx8mp:/test# ping 8.8.8.8
PING 8.8.8.8 (8.8.8.8) 56(84) bytes of data.
64 bytes from 8.8.8.8: icmp_seq=1 ttl=54 time=155 ms
64 bytes from 8.8.8.8: icmp_seq=2 ttl=54 time=41.0 ms
64 bytes from 8.8.8.8: icmp_seq=3 ttl=54 time=39.2 ms
64 bytes from 8.8.8.8: icmp_seq=4 ttl=54 time=47.1 ms
64 bytes from 8.8.8.8: icmp_seq=5 ttl=54 time=105 ms
64 bytes from 8.8.8.8: icmp_seq=6 ttl=54 time=91.7 ms
```

3.3.3.2 Wi-Fi AP Mode

Please put these files in the same directory.



Please install hostapd package: `apt-get install hostapd`

Enable Wi-Fi AP mode: `./enable_wifi_ap_mode.sh`

Disable Wi-Fi ap mode: `./disable_wifi_ap_mode.sh`

enable_wifi_ap_mode.sh:

```
#!/bin/sh
```

```
hostapd ./hostapd.conf -B
```

```
ifconfig wlan0 192.168.175.1
```

```
udhcpd ./udhcpd.conf
```

```
echo 1 > /proc/sys/net/ipv4/ip_forward
```

```
iptables -t nat -A POSTROUTING -o eth0 -j MASQUERADE
```

```
iptables -A FORWARD -i eth0 -o wlan0 -m conntrack --ctstate
```

```
RELATED,ESTABLISHED -j ACCEPT
```

```
iptables -A FORWARD -i wlan0 -o eth0 -j ACCEPT
```

disable_wifi_ap_mode.sh:

```
#!/bin/sh
```

```
killall5 -9 hostapd
```

```
killall5 -9 udhcpd
```

hostapd.conf :

```
interface=wlan0
```

```
driver=nl80211
```

```
ssid=aaeon_srg_wifi
```

```
channel=6
```

```
hw_mode=g
```

```
ignore_broadcast_ssid=0
```

```
auth_algs=1
```

```
wpa=3
```

```
wpa_passphrase=11111111  
wpa_key_mgmt=WPA-PSK  
wpa_pairwise=TKIP  
rsn_pairwise=CCMP
```

udhcpd.conf:

```
start 192.168.175.2  
end 192.168.175.254  
interface wlan0  
max_leases 234  
opt router 192.168.175.1
```

Test Wi-Fi ap mode on Windows NB:

```
ping 8.8.8.8 -S 192.168.175.xxx -t
```

3.4 HDMI

Precautions:

The graphics must be initialized at boot time if you want to use the GUI interface software. If you connect the SRG-IMX8PL screen with an HDMI cable after booting, you will miss this initialization opportunity and won't see any GUI patterns on the screen.

If using GUI software, please follow these steps:

1. Connect the SRG-IMX8PL screen using an HDMI cable.
2. Turn on the power.
3. After waiting for some time, you will see the GUI pattern on the screen.

3.5 OS Installation


3.5.1 Flash SD Card

Step 1: Download balenaEtcher tool: <https://www.balena.io/etcher/>


ASSET	OS	ARCH	
ETCHER FOR WINDOWS (X86 X64) (INSTALLER)	WINDOWS	X86 X64	Download
ETCHER FOR WINDOWS (X86 X64) (PORTABLE)	WINDOWS	X86 X64	Download

Step 2: Insert SD card to computer.

Step 3: Flash from file: Select the image you want to flash.



Step 4: Select target: Target is SD card.




Step 5: Press the Flash button. It will flash image to SD card.

3.5.2 Flash eMMC

Step 1: Insert a bootable SD card to the board.

Step 2: Set the switch to 0x11. It will boot from SD card.

Switch: 0011



Step 3: login: root

Password: Pw#12345

Step 4: Run command as follows, and it will flash image from SD card to eMMC.

Command:

```
/usr/sbin/imx8_plus_emmc_flasher.sh
```

Step 5: Turn off power.

Step 6: You can set the switch to 0x10. Turn on power.

It will then boot from eMMC.

Switch: 0010



3.5.3 Check Version

Check SW version on board (2G RAM).

Command:

```
cat /etc/os-release
```

```
root@pico-imx8mp:~# cat /etc/os-release
PRETTY_NAME="Debian GNU/Linux 11 (bullseye)"
NAME="Debian GNU/Linux"
VERSION_ID="11"
VERSION="11 (bullseye)"
VERSION_CODENAME=bullseye
ID=debian
HOME_URL="https://www.debian.org/"
SUPPORT_URL="https://www.debian.org/support"
BUG_REPORT_URL="https://bugs.debian.org/"
PROJECT="pico-imx8mplus"
IMAGE_VERSION="VB10"
HW_INFO="2G RAM MT53E512M32D1"
CREATE_DATE="2024/5/7"
```

Check SW version on board (4G RAM).

Command:

```
cat /etc/os-release
```

```
root@pico-imx8mp:~# cat /etc/os-release
PRETTY_NAME="Debian GNU/Linux 11 (bullseye)"
NAME="Debian GNU/Linux"
VERSION_ID="11"
VERSION="11 (bullseye)"
VERSION_CODENAME=bullseye
ID=debian
HOME_URL="https://www.debian.org/"
SUPPORT_URL="https://www.debian.org/support"
BUG_REPORT_URL="https://bugs.debian.org/"
PROJECT="pico-imx8mplus"
IMAGE_VERSION="VB10"
HW_INFO="4G RAM MT53E1G32D2"
CREATE_DATE="2024/5/7"
```

Appendix A

Mating Connectors

A.1 List of Mating Connectors and Cables

The following table lists mating connectors and available cables.

Conn Label	Function	Mating Connector		Available Cable	Cable P/N
		Vendor	Model No.		
CN4	SPI/I2C/GPIO Connector	PINREX	232-92-04GBEM	N/A	N/A
CN12	4G Full-Size Mini Card Slot	Quectel	Quectel.EG-25G	4G Module Card	9686EG25G0
CN16	Micro SD Slot	Transcend	TS16GUSD300S-A	N/A	N/A
CN25	LVDS Port Inverter/Backlight Connector	JST	PHR-5	N/A	N/A
CN26	LVDS Port	ACES	50247-030H0H0-001	LVDS Cable	1704300030 (LVDS panel: AUO G185XW01)
CN27	Audio Port	ACES	50247-012H0 H0-001	Audio Port Cable	170X000156
CN30	Debug Port	UGREEN	US289	USB 2.0 Micro B Cable	N/A
CN32	RTC Battery Connector	Molex	51021-0200	RTC Battery Cable	175011301K
CN38	DC Power	DINKLE	EC381RM-02P	N/A	N/A
CN70	RS-232/422/485 COM Port 1/Port 2	DINKLE	0156-1718-BK	N/A	N/A
CN71	UART Port 1/Port 3 Connector	PINREX	710-73-09TW01	N/A	N/A
CN140	WIFI/BT/Hailo-8/Hailo-8L M.2 Key E Slot	SparkLAN	WPET-239ACN(BT)	N/A	N/A
CN141	HDMI Port	Molex	88768-9900	HDMI Cable	N/A
CN145	LAN (RJ-45) Port 1, Port 2	Molex	44915-0001	N/A	N/A
CN146	USB 3.2 Port1, Port 2	UGREEN	US128	USB 3.2 Cable	N/A
CN147	Internal USB 2.0 Port	PINREX	712-91-055W60	N/A	N/A
CN149	UART Port 2, Port 4 Connector	PINREX	232-92-04GBEM	N/A	N/A