

BOXER-6451-ADP

Fanless Embedded Box PC

User's Manual 1st Ed

Copyright Notice

This document is copyrighted, 2022. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, AAEON assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

AAEON reserves the right to make changes in the product design without notice to its users.

Acknowledgement

All other product name or trademarks are properties of their respective owners.

- Microsoft Windows® is a registered trademark of Microsoft Corp.
- Windows® 10 IoT Enterprise and Windows® 11 PRO are registered trademarks of Microsoft Corp.
- Intel® and Celeron® are registered trademarks of Intel Corporation
- Intel Core™ is a trademark of Intel Corporation
- Ubuntu is a registered trademark of Canonical.

All other product names or trademarks are properties of their respective owners. The publisher of this document does not assume nor imply ownership of any trademarked product not listed herein.

Packing List

Before setting up your product, please make sure the following items have been shipped:

Item	Quantity
● BOXER-6451-ADP	1
● Wallmount bracket	2
● Screw Package	1
● 84W 12V Power Adapter	1

If any of these items are missing or damaged, please contact your distributor or sales representative immediately.

About this Document

This User's Manual contains all the essential information, such as detailed descriptions and explanations on the product's hardware and software features (if any), its specifications, dimensions, jumper/connector settings/definitions, and driver installation instructions (if any), to facilitate users in setting up their product.

Users may refer to the product page at AAEON.com for the latest version of this document.

Safety Precautions

Please read the following safety instructions carefully. It is advised that you keep this manual for future references

1. All cautions and warnings on the device should be noted.
2. Make sure the power source matches the power rating of the device.
3. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
4. Always completely disconnect the power before working on the system's hardware.
5. No connections should be made when the system is powered as a sudden rush of power may damage sensitive electronic components.
6. If the device is not to be used for a long time, disconnect it from the power supply to avoid damage by transient over-voltage.
7. Always disconnect this device from any power supply before cleaning.
8. While cleaning, use a damp cloth instead of liquid or spray detergents.
9. Make sure the device is installed near a power outlet and is easily accessible.
10. Keep this device away from humidity.
11. Place the device on a solid surface during installation to prevent falls.
12. Do not cover the openings on the device to ensure optimal heat dissipation.
13. Watch out for high temperatures when the system is running.
14. Do not touch the heat sink or heat spreader when the system is running
15. Never pour any liquid into the openings. This could cause fire or electric shock.
16. As most electronic components are sensitive to static electrical charge, be sure to ground yourself to prevent static charge when installing the internal components. Use a grounding wrist strap and contain all electronic components in any static-shielded containers.

17. If any of the following situations arises, please the contact our service personnel:
 - i. Damaged power cord or plug
 - ii. Liquid intrusion to the device
 - iii. Exposure to moisture
 - iv. Device is not working as expected or in a manner as described in this manual
 - v. The device is dropped or damaged
 - vi. Any obvious signs of damage displayed on the device
18. Do not leave this device in an uncontrolled environment with temperatures beyond the device's permitted storage temperatures (see chapter 1) to prevent damage.
19. Do NOT disassemble the motherboard so as not to damage the system or void your warranty.
20. If the thermal pad had been damaged, please contact AAEON's salesperson to purchase a new one. Do NOT use those of other brands.
21. The Hex Cylinder Coppers on the front panel are not removable.
22. Repeatedly assemble and disassemble the system may cause damages to the exterior paint and surface and screw holes.
23. Use the right size screwdriver.
24. Use the screwdriver correctly to remove screws from the system.

FCC Statement

Warning!



This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Caution:

There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.

Attention:

Il y a un risque d'explosion si la batterie est remplacée de façon incorrecte. Ne la remplacer qu'avec le même modèle ou équivalent recommandé par le constructeur. Recycler les batteries usées en accord avec les instructions du fabricant et les directives gouvernementales de recyclage.

China RoHS Requirements (CN)

产品中有毒有害物质或元素名称及含量

AAEON System

QO4-381 Rev.A2

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板 及其电子组件	×	○	○	○	○	○
外部信号 连接器及线材	×	○	○	○	○	○
外壳	○	○	○	○	○	○
中央处理器 与内存	×	○	○	○	○	○
硬盘	×	○	○	○	○	○
液晶模块	×	○	○	○	○	○
光驱	×	○	○	○	○	○
触控模块	×	○	○	○	○	○
电源	×	○	○	○	○	○
电池	×	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。
○：表示该有毒有害物质在该部件所有均质材料中的含量均在 GB/T 26572 标准规定的限量要求以下。
×：表示该有害物质的某一均质材料超出了 GB/T 26572 的限量要求，然而该部件仍符合欧盟指令 2011/65/EU 的规范。
环保使用期限(EFUP (Environmental Friendly Use Period))：10 年
备注：
一、此产品所标示之环保使用期限，系指在一般正常使用状况下。
二、上述部件物质中央处理器、内存、硬盘、光驱、电源为选购品。
三、上述部件物质液晶模块、触控模块仅一体机产品适用。

China RoHS Requirement (EN)

Name and content of hazardous substances in product

AAEON System

QO4-381 Rev.A2

Part Name	Hazardous Substances					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
PCB Assemblies	×	○	○	○	○	○
Connector and Cable	×	○	○	○	○	○
Chassis	○	○	○	○	○	○
CPU and Memory	×	○	○	○	○	○
Hard Disk	×	○	○	○	○	○
LCD Modules	×	○	○	○	○	○
CD-ROM/DVD-ROM	×	○	○	○	○	○
Touch Modules	×	○	○	○	○	○
Power	×	○	○	○	○	○
Battery	×	○	○	○	○	○

The table is prepared in accordance with the provisions of SJ/T 11364.

○ : Indicates that said hazardous substance contained in all of the homogenous materials for this product is below the limit requirement of GB/T 26572.

× : Indicates that said hazardous substance contained in at least one of the homogenous materials used for this part is above the limit requirement of GB/T 26572. But this product still be compliance with 2011/65/EU Directive (allowed with 2011/65/EU Annex III of RoHS exemption with number 6(c),7(a),7(c)-1).

EFUP (Environment Friendly Use Period) value: 10 years.

Notes:

1. This product defined period of use is under normal condition.
2. In above part, CPU/Memory/ Hard Disk/CD-ROM/DVD-ROM/ Power are optional.
3. In above part, LCD Modules/ Touch Modules are for all-in-one product model.

Table of Contents

Chapter 1 - Product Specifications 1

 1.1 Specifications..... 2

Chapter 2 – Hardware Information4

 2.1 Dimensions 5

 2.2 Jumpers and Connectors 6

 2.3 List of Jumpers 8

 2.3.1 Setting Jumpers..... 8

 2.3.2 Auto Power Button Selection (JP4) 9

 2.3.3 Clear CMOS Jumper (JP2)..... 9

 2.4 List of Connectors10

 2.4.1 Audio I/O Port (CN27)12

 2.4.2 Dual HDMI Port (CN3)13

 2.4.3 Dual USB 3.2 Port (CN22)15

 2.4.4 Dual USB 3.2/USB 2.0 Port (CN23)16

 2.4.5 LAN (RJ-45) (CN4, CN5).....17

 2.4.6 M.2 2280 M-Key (CN19)18

 2.4.7 Remote Button Connector (CN48) 20

 2.4.8 M.2 3052 B-Key (CN20)..... 20

 2.4.9 Debug Card Connector (CN37)..... 22

 2.4.10 SATA Connector (CN11)..... 23

 2.4.11 SATA Power Connector (CN42)..... 24

 2.4.12 Digital IO Port (CN45)..... 24

 2.4.13 COM 1/COM 2 Connector RS232/RS422/RS485 (CN40)..... 25

 2.4.14 COM 3/COM 4 Connector RS232/RS422/RS485 (CN41)..... 26

 2.4.15 COM Port (Wafer Box, Optional) (CN52)..... 27

 2.4.16 COM Port (Wafer Box, Optional) (CN53)..... 28

2.4.17	M.2 2230 E-Key (CN51).....	29
2.4.18	USB 2.0 Wafer Box (5P Pitch:1.25mm) (CN46, CN47)	31
2.5	DDR4 SODIMM Installation.....	32
2.6	2.5" SATA Drive Installation.....	33
2.7	M.2 Module Installation	35
Chapter 3 - AMI BIOS Setup.....		36
3.1	System Test and Initialization	37
3.2	AMI BIOS Setup	38
3.3	Setup Submenu: Main.....	39
3.4	Setup Submenu: Advanced	40
3.4.1	CPU Configuration	41
3.4.2	Memory Configuration.....	42
3.4.3	PCH-FW Configuration.....	43
3.4.3.1	Firmware Update Configuration.....	44
3.4.4	Hardware Monitor	45
3.4.4.1	Smart Fan Mode Configuration	46
3.4.5	Power Management.....	51
3.4.6	AAEON BIOS Robot.....	52
3.4.6.1	Device Detecting Configuration	53
3.5	Setup Submenu: System I/O.....	60
3.5.1	Storage Configuration	61
3.5.2	HD Audio Configuration	62
3.5.3	Digital IO Port Configuration	63
3.5.4	Legacy Logical Devices Configuration	65
3.5.4.1	Serial Port 1	66
3.5.4.2	Serial Port 2.....	67
3.5.4.3	Serial Port 3.....	68
3.5.4.4	Serial Port 4.....	69

3.5.5	Serial Port Console Redirection	70
3.5.5.1	Console Redirection Settings (COM0).....	71
3.5.5.2	Out-of-Band Management Settings.....	73
3.6	Setup Submenu: Security	75
3.6.1	Trusted Computing.....	76
3.6.2	Secure Boot.....	78
3.6.2.1	Key Management.....	79
3.7	Setup Submenu: Boot.....	81
3.7.1	UEFI BBS Priorities.....	82
3.8	Setup Submenu: Save & Exit	83
3.9	Setup Submenu: MEBx.....	84
Chapter 4 – Drivers Installation		85
4.1	Drivers Download and Installation.....	86
Appendix A- I/O Information.....		87
A.1	I/O Address Map.....	88
A.2	Memory Address Map	90
A.3	IRQ Mapping Chart	91

Chapter 1

Product Specifications

1.1 Specifications

System

CPU	12th Generation Intel® Core™ Processor SoC Intel® Core™ i7-1265UE Intel® Core™ i5-1245UE Intel® Core™ i3-1215UE Intel® Celeron® 7305E
Chipset	Intel® SoC
System Memory	DDR4 SODIMM x 1, up to 32GB
Display Interface	HDMI 1.4b x 2
Storage Device	2.5" SATA III Drive Bay x 1 M.2 2280 M-Key x 1 (PCIe [x4])
Ethernet	RJ-45 for 2.5GbE LAN i226-LM x 1 RJ-45 for GbE LAN i219-LM x 1
I/O	USB 3.2 Gen 2 x 3 USB 2.0 x 1 DB-9 x 4 (RS-232/422/485) HDMI 1.4b x 2 Power Button x 1 DC Jack 12V Input Antenna x 6
Expansion	M.2 2230 E-Key x 1 (Wi-Fi/Bluetooth) M.2 3052 B-Key x 1 w/ SIM (LTE/5G) M.2 2280 M-Key x 1 (NVMe)
Indicator	Power Button with LED

System

OS Support	Windows® 10 IoT Enterprise LTSC
	Windows® 11 PRO
	Ubuntu 22.04

Power Supply

Power Requirement	12V DC-in x 1 for Lockable DC Jack
-------------------	------------------------------------

Mechanical

Mounting	Wallmount
Dimensions (W x H x D)	7.68" x 4.37" x 2.5" (195mm x 111mm x 63.5mm)
Gross Weight	4.4 lb. (2Kg)
Net Weight	3.3 lb. (1.5Kg)


Environmental

Operating Temperature	-4°F ~ 140°F (-20°C ~ 60°C) IEC68-2 with 0.5 m/s AirFlow with Wide Temperature Memory/Storage Module
Storage Temperature	-40°F ~ 176°F (-40°C ~ 80°C)
Storage Humidity	5 ~ 95% @ 40°C, non-condensing
Anti-Vibration	SSD: Random, 3Grms, 5~500Hz
Anti-Shock	SSD: 50G @ Wallmount, Half-sine, 11ms
Certification	CE/FCC Class A

Chapter 2


Hardware Information

2.1 Dimensions




2.2 Jumpers and Connectors

Component Side



Solder Side



2.3 List of Jumpers


Please refer to the table below for all of the system's jumpers that you can configure for your application.

Label	Function
JP4	Auto-Power Button Selection (ATX/AT)
JP2	CMOS Control Selection

2.3.1 Setting Jumpers

The BOXER-6451-ADP comes with several jumpers which allow you to configure the system by either setting the jumper to "open" or "closed"; or by selecting certain pins. A closed jumper has two pins connected with a jumper clip, while an open jumper has no pins connected.


For jumpers with multiple pins, this guide uses "pins A-B" to notate which pins should be connected by a jumper clip. For example, "pins 1-2" means you should connect pins 1 and 2, while "pins 2-3" means you should connect pins 2 and 3.




A pair of needle-nose pliers may be helpful when working with jumpers.

If you have any questions about how best to configure the system for your application, contact your AAEON representative or visit our website to talk with our support team.

2.3.2 Auto Power Button Selection (JP4)




ATX (Default)




AT

2.3.3 Clear CMOS Jumper (JP2)



Normal (Default)



Clear CMOS


2.4 List of Connectors

Please refer to the table below for all of the system’s connectors that you can configure for your application

Label	Function
CN33	SODIMM Channel A
CN3	Dual HDMI Port
CN4	RJ-45 Connector
CN5	RJ-45 Connector
CN51	M.2 2230 E-Key
CN19	M.2 2280 M-Key
CN20	M.2 3052 B-Key
CN21	SIM Slot (B-Key)
CN48	Remote Button Connector
CN37	Debug Card Connector (ESPI bus)
CN11	SATA Connector
CN42	SATA Power Connector
CN45	DIO Connector
CN40	COM 1/COM 2 RS-232/RS-422/RS-485 Connector
CN41	COM 3/COM 4 RS-232/RS-422/RS-485 Connector
CN52	COM 1 RS-232/RS-422/RS-485 Box Connector
CN53	COM 2 RS-232/RS-422/RS-485 Box Connector
CN22	Dual USB 3.2 Connector
CN23	Dual USB 3.2/USB 2.0
CN46	USB 2.0 Box Connector
CN47	USB 2.0 Box Connector
CN26	Audio Line Out
CN27	Audio

Label	Function
CN34	Power Input
SW1	Power Button w/ LED
BAT1	RTC Connector
CN7	Reset Switch
CN49	PS_ON Connector


2.4.1 Audio I/O Port (CN27)



Pin	Signal	Signal Type	Signal Level
1	LINE_OUT_R	OUT	
2	MIC_R	IN	
3	LINE_OUT_L	OUT	
4	MIC_L	IN	
5	HPOUT-JD	IN	
6	MIC-JD	IN	
7	AUD_GND	GND	
8	AUD_GND	GND	
9	LINE_IN_JD	IN	
10	LINE_IN_R	IN	
11	+VDD_AUD	PWR	+5V
12	LINE_IN_L	IN	
13	AUD_GND	GND	
14	AUD_GND	GND	

2.4.2 Dual HDMI Port (CN3)


Standard Specification.



Pin	Signal	Signal Type	Signal Level
P1	HDMI1_DATA2_P	DIFF	
P2	GND	GND	
P3	HDMI1_DATA2_N	DIFF	
P4	HDMI1_DATA1_P	DIFF	
P5	GND	GND	
P6	HDMI1_DATA1_N	DIFF	
P7	HDMI1_DATA0_P		
P8	GND	GND	
P9	HDMI1_DATA0_n		
P10	HDMI1_CLK_P	DIFF	
P11	GND	GND	
P12	HDMI1_CLK_N	DIFF	
P13	CEC		+3.3V
P14	NC		
P15	HDMI1_SCL		
P16	HDMI1_SDA		
P17	GND	GND	


Pin	Signal	Signal Type	Signal Level
P18	+V5S_HDMI_CON	PWR	+5V
P19	HDMI1_HPD		+5V
P20	HDMI2_DATA2_P		
P21	GND	GND	
P22	HDMI2_DATA2_N		
P23	HDMI2_DATA1_P		
P24	GND	GND	
P25	HDMI2_DATA1_N		
P26	HDMI2_DATA0_P		
P27	GND	GND	
P28	HDMI2_DATA0_N		
P29	HDMI2_CLK_P		
P30	GND	GND	
P31	HDMI2_CLK_N		
P32	CEC		+3.3V
P33	NC		
P34	HDMI2_SCL		
P35	HDMI2_SDA		
P36	GND	GND	
P37	+V5S_HDMI_CON		+5V
P38	HDMI2_HPD		+5V

2.4.3 Dual USB 3.2 Port (CN22)




Pin	Signal	Signal Type	Signal Level
1	+5VSB	PWR	+5V
2	USB_D-	DIFF	
3	USB_D+	DIFF	
4	GND	GND	
5	USB3_RX_N	DIFF	
6	USB3_RX_P	DIFF	
7	GND	GND	
8	USB3_TX_N	DIFF	
9	USB3_TX_P	DIFF	
10	+5VSB	PWR	+5V
11	USB_D-	DIFF	
12	USB_D+	DIFF	
13	GND	GND	
14	USB3_RX_N	DIFF	
15	USB3_RX_P	DIFF	
16	GND	GND	
17	USB3_TX_N	DIFF	
18	USB3_TX_P	DIFF	

2.4.4 Dual USB 3.2/USB 2.0 Port (CN23)




Pin	Signal	Signal Type	Signal Level
1	+5VSB	PWR	+5V
2	USB_D-	DIFF	
3	USB_D+	DIFF	
4	GND	GND	
5	USB3_RX_N	DIFF	
6	USB3_RX_P	DIFF	
7	GND	GND	
8	USB3_TX_N	DIFF	
9	USB3_TX_P	DIFF	
10	+5VSB	PWR	+5V
11	USB_D-	DIFF	
12	USB_D+	DIFF	
13	GND	GND	

2.4.5 LAN (RJ-45) (CN4, CN5)



Pin	Signal	Signal Type
1	MDI0+	DIFF
2	MDI0-	DIFF
3	MDI1+	DIFF
4	MDI2+	DIFF
5	MDI2-	DIFF
6	MDI1-	DIFF
7	MDI3+	DIFF
8	MDI3-	DIFF


2.4.6 M.2 2280 M-Key (CN19)



Pin	Pin Name	Signal Type	Pin	Pin Name	Signal Type	Signal level
1	GND	GND	2	+3.3V	PWR	+3.3V
3	GND	GND	4	+3.3V	PWR	+3.3V
5	PCIE_RXN0	IN	6	CARD_PWR_OFF_N	OUT	+3.3V
7	PCIE_RXP0	IN	8	NC		
9	GND	GND	10	NC		
11	PCIE_TXN0	OUT	12	+3.3V	PWR	+3.3V
13	PCIE_TXP0	OUT	14	+3.3V	PWR	+3.3V
15	GND	PWR	16	+3.3V	PWR	+3.3V
17	PCIE_RXN1	IN	18	+3.3V	PWR	+3.3V
19	PCIE_RXP1	IN	20	NC		
21	GND	PWR	22	NC		
23	PCIE_TXN1	OUT	24	NC		
25	PCIE_TXP1	OUT	26	NC		
27	GND	PWR	28	NC		
29	PCIE_RXN2	IN	30	NC		


Pin	Pin Name	Signal Type	Pin	Pin Name	Signal Type	Signal level
31	PCIE_RXP2	IN	32	NC		
33	GND	GND	34	NC		
35	PCIE_TXN2	OUT	36	NC		
37	PCIE_TXP2	OUT	38	DEVSLP	IN	+3.3V
39	GND	GND	40	SMB_CLK_M2		+1.8V
41	PCIE_RXP3	IN	42	SMB_DATA_M2		+1.8V
43	PCIE_RXN3	IN	44	NC		
45	GND	GND	46	NC		
47	PCIE_TXN3	OUT	48	NC		
49	PCIE_TXP3	OUT	50	RESET#	IN	+3.3V
51	GND	PWR	52	CLKREQ#	OUT	+3.3V
53	PCIE_M.2_CLK#	OUT	54	WAKE#	OUT	+3.3V
55	PCIE_M.2_CLK	OUT	56	NC		
57	GND	GND	58	NC		
67	NC		68	NC		
69	NC		70	+3.3V	PWR	+3.3V
71	GND	GND	72	+3.3V	PWR	+3.3V
73	GND	GND	74	+3.3V	PWR	+3.3V
75	GND	GND				

2.4.7 Remote Button Connector (CN48)



Pin	Signal	Signal Type
1	PWR_BUTTON	IN
2	GND	GND

2.4.8 M.2 3052 B-Key (CN20)




Pin	Pin Name	Signal Type	Signal level	Pin	Pin Name	Signal Type	Signal level
1	NC			2	+3.3V	PWR	+3.3V
3	GND	GND		4	+3.3V	PWR	+3.3V
5	GND	GND		6	CARD_PWR_OFF_N	OUT	+3.3V
7	USB_2.0_P			8	W_DISABLE	IN	+3.3V

Pin	Pin Name	Signal Type	Signal level	Pin	Pin Name	Signal Type	Signal level
9	USB_2.0_N			10	NC		
11	GND	GND		12			
				20	NC		
21	NC			22	NC		
23	NC			24	NC		
25	NC			26	NC		
27	GND	GND		28	NC		
29	USB3_RXN			30	UIM_RST		
31	USB3_RXP			32	UIM_CLK		
33	GND	GND		34	UIM_DATA		
35	USB3_TXN			36	UIM_PWR		
37	USB3_TXP			38	NC		
39	GND	GND		40	NC		
41	PCIE_RXN			42	NC		
43	PCIE_RXP			44	NC		
45	GND	GND		46	NC		
47	PCIE_TXN			48	NC		
49	PCIE_TXP			50	RESET#	IN	+3.3V
51	GND	PWR		52	CLKREQ#	OUT	+3.3V
53	PCIE_M.2_CLK#	OUT		54	WAKE#	OUT	+3.3V
55	PCIE_M.2_CLK	OUT		56	NC		

Pin	Pin Name	Signal Type	Signal level	Pin	Pin Name	Signal Type	Signal level
57	GND	GND		58	NC		
59	NC			60	NC		
61	NC			62	NC		
63	NC			64	NC		
65	NC			66	NC		
67	RESET#			68	SUSCLK		
69	NC			70	+3.3V	PWR	+3.3V
71	GND	GND		72	+3.3V	PWR	+3.3V
73	GND	GND		74	+3.3V	PWR	+3.3V
75	GND	GND					


2.4.9 Debug Card Connector (CN37)



Pin	Signal	Signal Type	Signal Level
1	ESPI_IO_0	I/O	+1.8V
2	ESPI_IO_1	I/O	+1.8V
3	ESPI_IO_2	I/O	+1.8V


Pin	Signal	Signal Type	Signal Level
4	ESPI_IO_3	I/O	+1.8V
5	+3.3V	PWR	+3.3V
6	ESPI_IO_CS#	IN	
7	ESPI_IO_RST#	IN	
8	GND	GND	
9	EPSI_IO_LCLK	IN	
10	SMCLK	IN	
11	SMDAT	I/O	
12	NC		

2.4.10 SATA Connector (CN11)




Pin	Signal	Signal Type
1	GND	GND
2	SATA_TX+	DIFF
3	SATA_TX-	DIFF
4	GND	GND
5	SATA_RX-	DIFF
6	SATA_RX+	DIFF
7	GND	GND

2.4.11 SATA Power Connector (CN42)



Pin	Signal	Signal Type	Signal Level
1	+5VS	PWR	+5V
2	GND	GND	


2.4.12 Digital IO Port (CN45)



Pin	Signal	Signal Type	Signal Level
1	DIO0	I/O	+5V
2	DIO1	I/O	+5V
3	DIO2	I/O	+5V
4	DIO3	I/O	+5V
5	DIO4	I/O	+5V
6	DIO5	I/O	+5V

Pin	Signal	Signal Type	Signal Level
7	DIO6	I/O	+5V
8	DIO7	I/O	+5V
9	+5V	PWR	+5V
10	GND	GND	


2.4.13 COM 1/COM 2 Connector RS232/RS422/RS485 (CN40)



Pin	Pin Name	Signal Type	RS-422	RS-485
1	DCD1	IN	RS422_TX-	RS485_D-
6	DSR1	IN		
2	RX1	IN	RS422_TX+	RS485_D+
7	RTS1	OUT		
3	TX1	OUT	RS422_RX+	
8	CTS1	IN		
4	DTR1	OUT	RS422_RX-	
9	RI1	IN		
5	GND	GND		
10	DCD2	IN	RS422_TX-	RS485_D-
15	DSR2	IN		

Pin	Pin Name	Signal Type	RS-422	RS-485
11	RX2	IN	RS422_TX+	RS485_D+
16	RTS2	OUT		
12	TX2	OUT	RS422_RX+	
17	CTS2	IN		
13	DTR2	OUT	RS422_RX-	
18	RI2	IN		
14	GND	GND		


2.4.14 COM 3/COM 4 Connector RS232/RS422/RS485 (CN41)



Pin	Pin Name	Signal Type	RS-422	RS-485
1	DCD3	IN	RS422_TX-	RS485_D-
6	DSR3	IN		
2	RX3	IN	RS422_TX+	RS485_D+
7	RTS3	OUT		
3	TX3	OUT	RS422_RX+	
8	CTS3	IN		
4	DTR3	OUT	RS422_RX-	

Pin	Pin Name	Signal Type	RS-422	RS-485
9	RI3	IN		
5	GND	GND		
10	DCD4	IN	RS422_TX-	RS485_D-
15	DSR4	IN		
11	RX4	IN	RS422_TX+	RS485_D+
16	RTS4	OUT		
12	TX4	OUT	RS422_RX+	
17	CTS4	IN		
13	DTR4	OUT	RS422_RX-	
18	RI4	IN		
14	GND	GND		


2.4.15 COM Port (Wafer Box, Optional) (CN52)



Pin	Pin Name	Signal Type	RS-422	RS-485
1	DCD1	IN	RS422_TX-	RS485_D-
2	DSR1	IN		
3	RX1	IN	RS422_TX+	RS485_D+
4	RTS1	OUT		


Pin	Pin Name	Signal Type	RS-422	RS-485
5	TX1	OUT	RS422_RX+	
6	CTS1	IN		
7	DTR1	OUT	RS422_RX-	
8	RI1	IN		
9	GND	GND		

2.4.16 COM Port (Wafer Box, Optional) (CN53)



Pin	Pin Name	Signal Type	RS-422	RS-485
1	DCD2	IN	RS422_TX-	RS485_D-
2	DSR2	IN		
3	RX2	IN	RS422_TX+	RS485_D+
4	RTS2	OUT		
5	TX2	OUT	RS422_RX+	
6	CTS2	IN		
7	DTR2	OUT	RS422_RX-	
8	RI2	IN		
9	GND	GND		


2.4.17 M.2 2230 E-Key (CN51)



Pin	Pin Name	Signal Type	Pin	Pin Name	Signal Type	Signal level
1	GND	GND	2	+3.3V	PWR	+3.3V
3	USB_2.0_P	DIFF	4	+3.3V	PWR	+3.3V
5	USB_2.0_N	DIFF	6	NC		
7	GND	GND	8	NC		
9	NC		10	NC		
11	NC		12	NC		
13	NC		14	NC		
15	NC		16	NC		
17	NC		18	GND	GND	
19	NC		20	NC		
21	NC		22	NC		
23	NC					
				32	NC	

Pin	Pin Name	Signal Type	Pin	Pin Name	Signal Type	Signal level
33	GND	GND	34	NC		
35	PCIE_TXP	DIFF	36	NC		
37	PCIE_TXN	DIFF	38	NC		
39	GND	GND	40	NC		
41	PCIE_RXP	DIFF	42	NC		
43	PCIE_RXN	DIFF	44	NC		
45	GND	GND	46	NC		
47	PCIE_CLK	DIFF	48	NC		
49	PCIE_CLK#	DIFF	50	SUSCLK		
51	GND		52	PLT_RESET#		
53	PCIE_CLKREQ#		54	BT_DIS#		
55	PCIE_WAKE#		56	WLAK_DIS#		
57	GND	GND	58	NC		
59	NC		60	NC		
61	NC		62	NC		
63	GND	GND	64	NC		
65	NC		66	NC		
67	NC		68	NC		
69	GND	GND	70	+3.3V	PWR	+3.3V
71	NC		72	+3.3V	PWR	+3.3V
73	NC		74	+3.3V	PWR	+3.3V
75	GND	GND				

2.4.18 USB 2.0 Wafer Box (5P Pitch:1.25mm) (CN46, CN47)




Pin	Signal	Signal Type	Signal Level
1	+5V	GND	+5V
2	USBD-	DIFF	
3	USBD+	DIFF	
4	GND	GND	
5	GND	GND	

2.5 DDR4 SODIMM Installation

Before installing the DDR4 module, ensure the system is powered down and disconnect the power cord from the system. Make sure you have the module ready to install.

Step 1: Remove the four (4) screws from the bottom of the chassis as shown, then remove the bottom panel from the system.

Step 2: Insert the DDR4 module into the slot, followed by a thermal pad both on top of and underneath the DIMM heatsink. Note the diagram below for correct placement of each thermal pad.




2.6 2.5" SATA Drive Installation

Before installing the SATA Drive, ensure the system is powered down and disconnect the power cord from the system. Make sure you have the SATA Drive ready to install.


Step 1: Remove the four (4) screws from the bottom of the chassis to remove the bottom panel from the system.

Step 2: Attach the SATA drive to the HDD Bracket using the screws provided.

Step 3: Attach the HDD Bracket to the bottom panel using four screws as shown in the figure below. Attach the SATA and SATA Power cables to the board and the SATA drive.



Step 4: Use the screws provided to assemble 2.5" SATA drive with the HDD Bracket, being sure to place the four (4) HDD dampers between the screws and HDD bracket.




Step 5: Replace the bottom panel and secure with the four (4) screws you removed in Step 1.

2.7 M.2 Module Installation

The M.2 E-Key (2230), M.2 M-Key (2280), and B-Key (3052) slots are accessible by removing the bottom panel.

Follow standard procedures for expansion card installation, aligning the notch on each M.2 SSD with its respective key slot.



Chapter 3

AMI BIOS Setup

3.1 System Test and Initialization

The system uses certain routines to perform testing and initialization. If an error, fatal or non-fatal, is encountered, a few short beeps or an error message will be outputted. The board can usually continue the boot up sequence with non-fatal errors.

The system configuration verification routines check the current system configuration against the values stored in the CMOS memory. If they do not match, an error message will be outputted, in which case you will need to run the BIOS setup program to set the configuration information in memory.

There are three situations in which you will need to change the CMOS settings:

- You are starting your system for the first time
- You have changed your system's hardware
- The CMOS memory has lost power and the configuration information is erased

The system's CMOS memory uses a backup battery for data retention, which is to be replaced once emptied.

3.2 AMI BIOS Setup

The AMI BIOS ROM has a pre-installed Setup program that allows users to modify basic system configurations, which is stored in the battery-backed CMOS RAM and BIOS NVRAM so that the information is retained when the power is turned off.

To enter BIOS Setup, press or <F2> immediately while your computer is powering up.

The function for each interface can be found below.

Main – Date and time can be set here. Press <Tab> to switch between date elements

Advanced – Enable/ Disable boot option for legacy network devices

System I/O – Enable/ Disable system I/O device

Security – The setup administrator password can be set here

Boot – Enable/ Disable quiet Boot Option

Save & Exit – Save your changes and exit the program

MEBx – Intel® Management Engine BIOS Extension


3.3 Setup Submenu: Main



3.4 Setup Submenu: Advanced




3.4.1 CPU Configuration




Options Summary		
Intel (VMX) Virtualization Technology	Disabled	
	Enabled	Optimal Default, Failsafe Default
When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.		
Hyper-Threading	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable Hyper-Threading Technology.		
Intel® SpeedStep™	Disabled	
	Enabled	Optimal Default, Failsafe Default
Allows more than two frequency ranges to be supported.		
Turbo Mode	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable/Disable processor Turbo Mode (requires EMTTM enabled too). AUTO means enabled.		

Options Summary		
C states	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable/Disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized.		

3.4.2 Memory Configuration




3.4.3 PCH-FW Configuration




Options Summary		
AMT BIOS Features	Enabled	Optimal Default, Failsafe Default
	Disabled	
When disabled AMT BIOS Features are no longer supported and user is no longer able to access MEBx Setup.		
Note: This option does not disable Manageability Features in FW.		

3.4.3.1 Firmware Update Configuration




Options Summary		
Me FW Image Re-Flash	Enabled	
	Disabled	Optimal Default, Failsafe Default
Enabled/ Disable Me FW Image Re-Flash function.		
FW Update	Enabled	
	Disabled	Optimal Default, Failsafe Default
Enabled/ Disable Me FW Update function.		

3.4.4 Hardware Monitor



Options Summary		
Smart Fan	Enabled	Optimal Default, Failsafe Default
	Disabled	
Enable or Disable Smart Fan.		


3.4.4.1 Smart Fan Mode Configuration



Options Summary		
FAN1 Output Mode	Output PWM mode (open drain)	Optimal Default, Failsafe Default
	Linear Fan Application	
	Output PWM mode (push pull)	
Output PWM mode (push pull) to control 4-wire fans. Linear fan application circuit to control 3-wire fan speed by fan's power terminal.		
Output PWM mode (open drain) to control Intel 4-wire fans.		
Fan 1 Smart Fan Control	Manual RPM Mode	
	Manual Duty Mode	
	Auto RPM Mode	
	Auto Duty-Cycle Mode	Optimal Default, Failsafe Default
Smart Fan Mode Select.		

Options Summary		
Temperature Source	CPU Temperature	Optimal Default, Failsafe Default
	System Temperature	
	System Temperature 2	
Select the monitored temperature source for this fan.		
Temperature 1	60	Optimal Default, Failsafe Default
Temperature 2	50	Optimal Default, Failsafe Default
Temperature 3	40	Optimal Default, Failsafe Default
Temperature 4	30	Optimal Default, Failsafe Default
Temperature 5	20	Optimal Default, Failsafe Default
Duty Cycle 1	85	Optimal Default, Failsafe Default
Duty Cycle 2	70	Optimal Default, Failsafe Default
Duty Cycle 3	60	Optimal Default, Failsafe Default
Duty Cycle 4	50	Optimal Default, Failsafe Default
Duty Cycle 5	40	Optimal Default, Failsafe Default
Auto fan speed control. Fan speed will follow different temperature by different duty cycle 1-100		

3.4.4.1.1 Auto RPM Mode




Options Summary		
Fan 1 Smart Fan Control	Auto RPM Mode	
Smart Fan Mode Select.		
Temperature Source	CPU Temperature	Optimal Default, Failsafe Default
	System Temperature	
	System Temperature 2	
Select the monitored temperature source for this fan.		
Temperature 1	60	Optimal Default, Failsafe Default
Temperature 2	50	Optimal Default, Failsafe Default
Temperature 3	40	Optimal Default, Failsafe Default
Temperature 4	30	Optimal Default, Failsafe Default
Temperature 5	20	Optimal Default, Failsafe Default
RPM Percentage 1	85	Optimal Default, Failsafe Default
RPM Percentage 2	70	Optimal Default, Failsafe Default
RPM Percentage 3	60	Optimal Default, Failsafe Default
RPM Percentage 4	50	Optimal Default, Failsafe Default
RPM Percentage 5	40	Optimal Default, Failsafe Default

Options Summary

Auto fan speed control. Fan speed will follow different temperature by different RPM 1-100


3.4.4.1.2 Manual Duty Mode



Options Summary


Fan 1 Smart Fan Control	Manual Duty Mode	
Smart Fan Mode Select.		
Temperature Source	CPU Temperature	Optimal Default, Failsafe Default
	System Temperature	
	System Temperature 2	
Select the monitored temperature source for this fan.		
Manual Duty Mode	60	Optimal Default, Failsafe Default
Manual mode fan control, user can write expected duty cycle (PWM fan type) 1-100		

3.4.4.1.3 Manual RPM Mode



Options Summary		
Fan 1 Smart Fan Control	Manual RPM Mode	
Smart Fan Mode Select.		
Temperature Source	CPU Temperature	Optimal Default, Failsafe Default
	System Temperature	
	System Temperature 2	
Select the monitored temperature source for this fan.		
Manual RPM Mode	3000	Optimal Default, Failsafe Default
Manual mode fan control, user can write expected RPM count 500-10000.		

3.4.5 Power Management



Options Summary		
Power Mode	ATX Type	Optimal Default, Failsafe Default
	AT Type	
Select system power mode		
Restore AC Power Loss	Last State	Optimal Default, Failsafe Default
	Always On	
	Always Off	
Set GPI [3:0] Output as Hi or Low		
System Wake On RTC	Disabled	Optimal Default, Failsafe Default
	By Date	
	By Weekday	
	Bypass	
By Date: System will wake on the day with hr::min::sec specified./n By Weekday: System will wake on the enabled weekday with hr::min::sec specified./n Bypass: BIOS will not control RTC wake function.		


3.4.6 AAEON BIOS Robot



Options Summary		
Sends watch dog before BIOS POST	Disabled	Optimal Default, Failsafe Default
	Enabled	
Enabled – Robot set Watch Dog Timer (WDT) right after power on, before BIOS start POST process. And then Robot will clear WDT on completion of POST. WDT on completion of POST. WDT will reset system automatically if it is not cleared before its timer counts down to zero.		
Sends watch dog before booting OS	Disabled	Optimal Default, Failsafe Default
	Enabled	
Enabled – Robot set Watch Dog Timer (WDT) after POST completion, before BIOS transfer control to OS. WARNING: Before enabling this function, a program in OS must be in responsible for clearing WDT. Also, this function should be disabled if OS I going to update itself.		
Delayed POST (PEI phase)	Disabled	Optimal Default, Failsafe Default
	Enabled	

Options Summary		
Enabled -Robot holds BIOS from starting POST, right after power on. This allows BIOS POST to start with stable power or start after system is physically warmed-up. Note: Robot does this before 'Sends watch dog'.		
Delayed POST (DXE phase)	Disabled	Optimal Default, Failsafe Default
	Enabled	
Enabled -Robot holds BIOS before POST completion. This allows BIOS POST to start with stable power or start after system is physically warmed-up. Note: Robot does this after 'Sends watch dog before BIOS POST'.		


3.4.6.1 Device Detecting Configuration



Options Summary		
Action	Reset System	Optimal Default, Failsafe Default
	Hold System	
Select action that robot should do.		
Soft or hard reset	Soft	Optimal Default, Failsafe Default
	Hard	
Select reset type robot should send on each boot.		


Options Summary		
Retry-Count	3	Optimal Default, Failsafe Default
Fill retry counter here. Robot will reset system at most counter times, and then let system continue its POST.		
At time	After shoe logo	Optimal Default, Failsafe Default
	Before show logo	
Select robot action time: After show logo -Robot will do action after logo is displayed. System devices are almost ready. Before show logo - Robot will do action earlier before logo, but some devices may not be ready.		

3.4.6.1.1 Device #1 Detecting Configuration




Options Summary		
Interface	Disabled	Optimal Default, Failsafe Default
	PCI	
	DIO	
	SMBUS	
	Legacy I/O	
	Super I/O	
	MMIO	
Select interface robot should use to communicate with device.		

3.4.6.1.2 Device #2 Detecting Configuration




Options Summary		
Interface	Disabled	Optimal Default, Failsafe Default
	PCI	
	DIO	
	SMBUS	
	Legacy I/O	
	Super I/O	
	MMIO	
Select interface robot should use to communicate with device.		

3.4.6.1.3 Device #3 Detecting Configuration




Options Summary		
Interface	Disabled	Optimal Default, Failsafe Default
	PCI	
	DIO	
	SMBUS	
	Legacy I/O	
	Super I/O	
	MMIO	
Select interface robot should use to communicate with device		

3.4.6.1.4 Device #4 Detecting Configuration



Options Summary		
Interface	Disabled	Optimal Default, Failsafe Default
	PCI	
	DIO	
	SMBUS	
	Legacy I/O	
	Super I/O	
	MMIO	
Select interface robot should use to communicate with device		

3.4.6.1.5 Device #5 Detecting Configuration




Options Summary		
Interface	Disabled	Optimal Default, Failsafe Default
	PCI	
	DIO	
	SMBUS	
	Legacy I/O	
	Super I/O	
	MMIO	
Select interface robot should use to communicate with device		

3.5 Setup Submenu: System I/O




3.5.1 Storage Configuration



Options Summary		
SATA Controller(s)	Enabled	Optimal Default, Failsafe Default
	Disabled	
Enable/Disable to SATA Device		

3.5.2 HD Audio Configuration



Options Summary		
HD Audio	Disabled	
	Enabled	Optimal Default, Failsafe Default
Control Detection of the HD-Audio device. Disabled = HDA will be unconditionally disabled Enabled = HDA will be unconditionally enabled.		

3.5.3 Digital IO Port Configuration



Options Summary		
DIO1	Input	
	Output	Optimal Default, Failsafe Default
Set DIO as Input or Output.		
Output Level	Low	
	High	Optimal Default, Failsafe Default
Set output level when DIO pin is output.		
DIO2	Input	
	Output	Optimal Default, Failsafe Default
Set DIO as Input or Output.		
Output Level	Low	
	High	Optimal Default, Failsafe Default
Set output level when DIO pin is output.		
DIO3	Input	
	Output	Optimal Default, Failsafe Default
Set DIO as Input or Output.		


Options Summary		
Output Level	Low	
	High	Optimal Default, Failsafe Default
Set output level when DIO pin is output.		
DIO4	Input	
	Output	Optimal Default, Failsafe Default
Set DIO as Input or Output.		
Output Level	Low	
	High	Optimal Default, Failsafe Default
Set output level when DIO pin is output.		
DIO5	Input	Optimal Default, Failsafe Default
	Output	
Set DIO as Input or Output.		
DIO6	Input	Optimal Default, Failsafe Default
	Output	
Set DIO as Input or Output.		
DIO7	Input	Optimal Default, Failsafe Default
	Output	
Set DIO as Input or Output.		
DIO8	Input	Optimal Default, Failsafe Default
	Output	
Set DIO as Input or Output.		

3.5.4 Legacy Logical Devices Configuration




Options Summary		
Use This Device	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable this Logical Device.		
Possible:	Use Automatic Settings	Optimal Default, Failsafe Default
	IO=3F8; IRQ=4;	
	IO=2F8; IRQ=3;	
Allows the user to change the device resource settings. New settings will be reflected on this setup page after system restarts.		
Mode	RS232	Optimal Default, Failsafe Default
	RS422	
	RS485	
UART RS232, 422, 485, selection.		

3.5.4.1 Serial Port 1




Options Summary		
Use This Device	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable this Logical Device.		
Possible:	Use Automatic Settings	Optimal Default, Failsafe Default
	IO=3F8; IRQ=4;	
	IO=2F8; IRQ=3;	
Allows the user to change the device resource settings. New settings will be reflected on this setup page after system restarts.		
Mode	RS232	Optimal Default, Failsafe Default
	RS422	
	RS485	
UART RS232, 422, 485, selection.		

3.5.4.2 Serial Port 2




Options Summary		
Use This Device	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable this Logical Device.		
Possible:	Use Automatic Settings	Optimal Default, Failsafe Default
	IO=2F8; IRQ=3;	
	IO=3F8; IRQ=4;	
Allows the user to change the device resource settings. New settings will be reflected on this setup page after system restarts.		
Mode	RS232	Optimal Default, Failsafe Default
	RS422	
	RS485	
UART RS232, 422, 485, selection.		

3.5.4.3 Serial Port 3




Options Summary		
Use This Device	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable this Logical Device.		
Possible:	Use Automatic Settings	Optimal Default, Failsafe Default
	IO=3E8; IRQ=11;	
	IO=2E8; IRQ=11;	
Allows the user to change the device resource settings. New settings will be reflected on this setup page after system restarts.		
Mode	RS232	Optimal Default, Failsafe Default
	RS422	
	RS485	
UART RS232, 422, 485, selection.		

3.5.4.4 Serial Port 4




Options Summary		
Use This Device	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable this Logical Device		
Possible:	Use Automatic Settings	Optimal Default, Failsafe Default
	IO=2E8; IRQ=11;	
	IO=3E8; IRQ=11;	
Allows the user to change the device resource settings. New settings will be reflected on this setup page after system restarts.		
Mode	RS232	Optimal Default, Failsafe Default
	RS422	
	RS485	
UART RS232, 422, 485, selection		

3.5.5 Serial Port Console Redirection



Options Summary		
Console Redirection	Disabled	Optimal Default, Failsafe Default
	Enabled	
Console Redirection Enable or Disable.		
Console Redirection EMS	Disabled	Optimal Default, Failsafe Default
	Enabled	
Console Redirection Enable or Disable.		


3.5.5.1 Console Redirection Settings (COM0)



Options Summary		
Terminal Type	VT100	
	VT100Plus	
	VT-UTF8	
	ANSI	Optimal Default, Failsafe Default
Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100Plus: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.		
Bits per second	9600	
	19200	
	38400	
	57600	
	115200	Optimal Default, Failsafe Default
Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.		
Data Bits	7	
	8	Optimal Default, Failsafe Default

Options Summary		
Data Bits		
Parity	None	Optimal Default, Failsafe Default
	Even	
	Odd	
	Mark	
	Space	
A parity bit can be sent with the data bits to detect some transmission errors. Even: parity bit is 0 if the num of 1's in the data bits is even. Odd: parity bit is 0 if num of 1's in the data bits is odd. Mark: parity bit is always 1. Space: Parity bit is always 0. Mark and Space Parity do not allow for error detection. They can be used as an additional data bit.		
Stop Bits	1	Optimal Default, Failsafe Default
	2	
Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.		
Flow Control	None	Optimal Default, Failsafe Default
	Hardware RTS/CTS	
Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.		
VT-UTF8 Combo Key Support	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals		
Recorder Mode	Disabled	Optimal Default, Failsafe Default
	Enabled	
With this mode enabled only text will be sent. This is to capture Terminal data.		
Resolution 100x31	Disabled	Optimal Default, Failsafe Default
	Enabled	
Enables or disables extended terminal resolution		
Putty KeyPad	VT100	Optimal Default, Failsafe Default
	LINUX	
	XTERMR6	
	SCO	
	ESCN	
	VT400	
Select FunctionKey and KeyPad on Putty.		

3.5.5.2 Out-of-Band Management Settings



Options Summary		
Out-of-Band Mgmt Port	COM0	Optimal Default, Failsafe Default
	COM1 (Pci Bus0, Dev0, Func0) (Disabled)	
Microsoft Windows Emergency Management Services (EMS) allows for remote management of a Windows Server OS through a serial port.		
Terminal Type EMS	VT100	
	VT100Plus	
	VT-UTF8	Optimal Default, Failsafe Default
	ANSI	
VT-UTF8 is the preferred terminal type for out-of-band management. The next best choice is VT100+ and then VT100. See above, in Console Redirection Settings page, for more Help with Terminal Type/Emulation.		
Bits per second EMS	9600	
	19200	
	57600	
	115200	Optimal Default, Failsafe Default

Options Summary

Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

Flow Control EMS	None	Optimal Default, Failsafe Default
	Hardware RTS/CTS	
	Software Xon/Xoff	

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

3.6 Setup Submenu: Security




Change User/Administrator Password

You can set a User Password once an Administrator Password. The password will be required during boot up, or when the user enters the Setup utility. Please Note that a User Password does not provide access to many of the features in the Setup utility. Select the password you wish to set, press Enter to open a dialog box to enter your password (you can enter no more than six letters or numbers). Press Enter to confirm your entry, after which you will be prompted to retype your password for a final confirmation. Press Enter again after you have retyped it correctly.

Removing the Password

Highlight this item and type in the current password. At the next dialog box press Enter to disable password protection.

3.6.1 Trusted Computing



Options Summary		
Security Device Support	Enable	Optimal Default, Failsafe Default
	Disable	
Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.		
SHA256 PCR Bank	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable SHA256 PCR Bank.		
SHA384 PCR Bank	Disabled	Optimal Default, Failsafe Default
	Enabled	
Enable or Disable SHA384 PCR Bank.		
Pending operation	None	Optimal Default, Failsafe Default
	TPM Clear	
Schedule an Operation for the Security Device. NOTE: Your Computer will reboot during restart in order to change State of Security Device.		
Platform Hierarchy	Disabled	
	Enabled	Optimal Default, Failsafe Default


Options Summary		
Enable or Disable Platform Hierarchy.		
Storage Hierarchy	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable Storage Hierarchy.		
Endorsement Hierarchy	Disabled	
	Enabled	Optimal Default, Failsafe Default
Enable or Disable Endorsement Hierarchy.		
Physical Presence Spec Version	1.2	
	1.3	Optimal Default, Failsafe Default
Select to Tell O.S. to support PPI Spec Version 1.2 or 1.3. Note some HCK tests might not support 1.3.		
Device Select	TPM 1.2	
	TPM 2.0	
	Auto	Optimal Default, Failsafe Default
TPM 1.2 will restrict support to TPM 1.2 devices, TPM 2.0 will restrict support to TPM 2.0 devices, Auto will support both with the default set to TPM 2.0 devices if not found, TPM 1.2 devices will be enumerated.		

3.6.2 Secure Boot



Options Summary		
Secure Boot	Disabled	Optimal Default, Failsafe Default
	Enabled	
Secure Boot feature is Active if Secure Boot is Enabled, Platform Key (PK) is enrolled and the System is in User mode. The mode change requires platform reset.		
Secure Boot Mode	Standard	Optimal Default, Failsafe Default
	Custom	
Secure Boot mode options: Standard or Custom. In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication.		
Restore Factory Keys	Yes	
	No	
Force System to User Mode. Install factory default Secure Boot key databases.		


3.6.2.1 Key Management



Options Summary		
Factory Key Provision	Disabled	Optimal Default, Failsafe Default
	Enabled	
Install factory default Secure Boot keys after the platform reset and while the System is in Setup mode.		
Restore Factory Keys	Yes	
	No	
Force System to User Mode.		
Install factory default Secure Boot key databases.		
Enroll Efi Image		
Allow Efi image to run in Secure Boot mode. Enroll SHA256 Hash certificate of a PE image into Authorized Signature Database (db).		
Platform Key (PK)	Update	
Key Exchange Keys (KEK)	Update	
	Append	
Authorized Signatures (db)	Update	
	Append	


Options Summary		
Forbidden Signatures (dbx)	Update	
	Append	
Authorized TimeStamps (dbt)	Update	
	Append	
OsRecovery Signatures (dbr)	Update	
	Append	
Enroll Factory Defaults or load certificates from a file:		
1. Public Key Certificate:		
a) EFI_SIGNATURE_LIST		
b) EFI_CERT_X509 (DER)		
c) EFI_CERT_RSA2048 (bin)		
d) EFI_CERT_SHAXXX		
2. Authenticated UEFI Variable		
3. EFI PE/COFF Image (SHA256)		
Key Source: Factory, External, Mixed.		

3.7 Setup Submenu: Boot




Options Summary		
Quiet Boot	Disabled	
	Enabled	Default
Enables/disables Quiet Boot option.		
Network Stack	Disabled	Default
	Enabled	
Enable/Disable UEFI Network Stack.		
Boot Option #1	Hard Disk	
Boot Option #2	NVME	
Boot Option #3	USB Device	
Boot Option #4	Network	
Sets the system boot order.		

3.7.1 UEFI BBS Priorities



Options Summary		
Quiet Boot	Disabled	
	Enabled	Default
Enables/disables Quiet Boot option.		
Network Stack	Disabled	Default
	Enabled	
Enable/Disable UEFI Network Stack.		
Boot Option #1	Hard Disk	
Boot Option #2	NVME	
Boot Option #3	USB Device	
Boot Option #4	Network	
Sets the system boot order.		

3.8 Setup Submenu: Save & Exit



3.9 Setup Submenu: MEBx



Chapter 4

Drivers Installation

4.1 Drivers Download and Installation


Drivers for the BOXER-6451-ADP can be downloaded from the product page on the AAEON website by following this link:


<https://www.aaeon.com/en/p/ultra-slim-fanless-box-pc-solutions-boxer-6451-adp>

Appendix A


I/O Information

A.1 I/O Address Map





Appendix A- I/O Information



A.3 IRQ Mapping Chart

