

OS List

| 機種： | | | | | | | | | | | | | | |
|--------------|------------|------------|--------------|------------|-------|--------------|------------|---------------|------------|------------|------|-----|-------|-----------|
| OS \ Driver | Windows 95 | Windows XP | Windows 2000 | Windows 9X | Linux | Windows 2003 | Windows NT | Windows 98 SE | Windows 98 | Windows ME | Unix | DOS | VISTA | WIN XP 64 |
| step1 – INF | | ▲ | ▲ | | | ▲ | | | | | | | ▲ | |
| step2 -- LAN | | ▲ | | | ▲ | | | | ▲ | | | | | ▲ |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |

*註.已上所列為較常用 OS 類別與 Driver 類別，若是有沒適合的選項，請於空白處填寫新的 OS 與 Driver 類別