

Notice

This guide is designed for experienced users to setup the system in the shortest time.

Safety Precautions

Warning!



Always completely disconnect the power cord from your board whenever you are working on it. Do not make connections while the power is on, because a sudden rush of power can damage sensitive electronic components.

Caution!



Always ground yourself to remove any static charge before touching the board. Modern electronic devices are very sensitive to static electric charges. Use a grounding wrist strap at all times. Place all electronic components on a static-dissipative surface or in a static-shielded bag when they are not in the chassis.

A Message to the Customer

First of all, thank you for purchasing RDS-141V Docking Station for Rugged Tablet Computer. This Quick Installation Guide will help you on the process of the installation. Please read it thoroughly before you start to install it. We strongly suggest you to read and refer to the Quick Installation Guide before any installation. You may visit AAeon website for the latest version of the instruction. Please refer to <http://www.aaeon.com/>

Product Warranty

AAEON Customer Services

All products in AAEON are designed as the strictest specifications to ensure that the products will own the reliable performance in the typical industrial environments. Whether your purchase from AAEON is made to the purpose of the laboratory or the factory facility, you can be assured that every purchase in AAEON will provide the reliability and stability of operation.

Your satisfaction is our primary concern. Here is a guide for AAEON's customer services. Ensure you get the full benefits of our services, please follow the instructions below step by step.

Technical Support

We require you to get the maximum performance from your products. If you run into technical difficulties, we'll be here always for you. For the most frequently asked questions, you can easily find solutions in your product documentation. The guide is for your quick and accurate installation so please refer to it first. We strongly suggest you to read it before asking for a customer service over the phone. If you still cannot find the answer, gather all questions you can think of and have the product at hand before giving a call to your dealer. All dealers of AAEON are well-trained and ready to provide you as many supports as we can. Based on the customer service we've encountered until now, most of problems are minor and able to be

easily solved over the phone. In addition, free-charged technical support is available from AAEON engineers in the office time. We are always pleased to give advice regarding to any installation and operation for AAEON products.


Packing List

- Product CD (including Quick Installation Guide)
- RDS-141V Docking Station for Rugged Tablet Computer

Content

A Message to the Customer.....	1-2
Product Warranty	1-3
Ordering Information	1-5
Packing List.....	1-5
I/O Information	1-7
Installation	1-8

I/O Information




1. DC-in spec: DC19V/3.42A. AAEON recommends you to use RTC-1000 default AC adapter for this Docking Station
2. COM port information: It's COM2 device in the RTC-1000's configuration.

Installation

Step 1: Get the Docking Station (RDS-141V) ready



Step 2: Release the lock



Step 3: Pull the lock up



Step 4: Place the Rugged Tablet Computer to the Docking Station



Step 5: Press the lock to lock the Rugged Tablet Computer and finish the installation

