



Note:
 A. CPCI Slot only can use for PICMG_PCI CPU card.
 B. PICMG_PCI CPU card must install on CPCI Slot.

