

AEC-6401

Embedded Controller

Intel® Atom™ N2600 1.6GHz Processor

4 USB2.0, 3 COM, 1 Mini-HDMI

1 mSATA

Copyright Notice

This document is copyrighted, 2013. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, AAEON assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

AAEON reserves the right to make changes in the product design without notice to its users.

Acknowledgments

All other products' name or trademarks are properties of their respective owners.

- AMI is a trademark of American Megatrends, Inc.
- CompactFlash™ is a trademark of the Compact Flash Association.
- Microsoft Windows® is a registered trademark of Microsoft Corp.
- Intel®, Atom™ are trademarks of Intel Corporation.
- PC/AT, PS/2, and VGA are trademarks of International Business Machines Corporation.

All other product names or trademarks are properties of their respective owners.

Packing List

Before you begin operating your PC, please make sure that the following materials are enclosed:

- 1 AEC-6401 Embedded Controller
- 1 Burn-Proof Bracket
- 3 RJ-45 to Dsub cable
- 1 CD-ROM for manual (in PDF format) and drivers
- 1 mini-HDMI to HDMI cable
- 1 Power Adaptor

If any of these items should be missing or damaged, please contact your distributor or sales representative immediately.

Safety & Warranty

1. Read these safety instructions carefully.
2. Keep this user's manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Do not use liquid or spray detergents for cleaning. Use a damp cloth.
4. For pluggable equipment, the power outlet must be installed near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a firm surface during installation. Dropping it or letting it fall could cause damage.
7. The openings on the enclosure are for air convection. Protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient over-voltage.
12. Never pour any liquid into an opening. This could cause fire or electrical shock.
13. Never open the equipment. For safety reasons, only qualified service personnel should open the equipment.
14. If any of the following situations arises, get the equipment checked by service personnel:
 - a. The power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.

- d. The equipment does not work well, or you cannot get it to work according to the user's manual.
 - e. The equipment has been dropped and damaged.
 - f. The equipment has obvious signs of breakage.
15. DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE IS BELOW -20°C (-4°F) OR ABOVE 70°C (158°F). IT MAY DAMAGE THE EQUIPMENT.

FCC

Warning!



This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Caution:

There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.

Below Table for China RoHS Requirements

产品中有毒有害物质或元素名称及含量

AAEON Boxer/ Industrial System

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板 及其电子组件	×	○	○	○	○	○
外部信号 连接器及线材	×	○	○	○	○	○
外壳	×	○	○	○	○	○
中央处理器 与内存	×	○	○	○	○	○
硬盘	×	○	○	○	○	○
电源	×	○	○	○	○	○

O: 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。

X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。

备注:

一、此产品所标示之环保使用期限，系指在一般正常使用状况下。

二、上述部件物质中央处理器、内存、硬盘、电源为选购品。

Chapter 1 General Information

1.1 Introduction.....	1-2
1.2 Features	1-3
1.3 Specifications	1-4

Chapter 2 Hardware Installation

2.1 2.1 Dimension and I/O of AEC-6401	2-2
2.2 Connectors and Jumpers of The Main Board	2-4
2.3 List of Jumpers	2-5
2.4 List of Connectors	2-6
2.5 Clear CMOS Jumper (JP2)	2-7
2.6 LVDS Port 1 Backlight Inverter VCC Selection (JP3).....	2-7
2.7 LVDS Port 1 Operating VDD Selection (JP5)	2-7
2.8 AT/ATX Power Supply Mode Selection (JP6).....	2-8
2.9 Realtek LAN (RJ-45) Port (CN12).....	2-8
2.10 COM1,RJ-45 Port (CN20)	2-9
2.11 COM2,COM3 RS232/422/485 ,RJ-45 Port (CN21,CN22)	2-9
2.12 Buzzer (CN8).....	2-10
2.13 RESET (CN9).....	2-10
2.14 LPC Debug Port (CN10)	2-11
2.15 USB 2.0 Port 5 (CN11).....	2-12
2.16 USB 2.0 Port 4 (CN27).....	2-12
2.17 18-bits LVDS Output (CN15).....	2-13
2.18 HDMI Type C (CN17)	2-14

2.19 Inverter / Backlight Connector (CN18) 2-15

2.20 DDR3 SO-DIMM Slot (DIMM1) 2-16

2.21 Mini-Card Slot (mSATA function only) 2-16

2.22 mSATA Storage Installation 2-19

2.23 DRAM Installation..... 2-20

2.24 Mounting Bracket& burn-Proof bracket installation. 2-21

2.25 DIN-RAIL bracket Installation 2-23

2.26 VESA-Mount bracket Installation (for Display Panels)
..... 2-24

Chapter 3 AMI BIOS Setup

3.1 System Test and Initialization. 3-2

3.2 AMI BIOS Setup 3-3

Chapter 4 Driver Installation

4.1 Installation 4-3

Appendix A Programming The Watchdog Timer

A.1 Watchdog Timer RegistersA-2

A.2 WatchDog Sample ProgramA-3

Appendix B I/O Information

B.1 Electrical Specifications for Digital I/O PortsB-2

B.2 DIO ProgrammingB-2

B.3 Digital I/O RegisterB-3

B.4 Digital I/O Sample ProgramB-4

Appendix C AHCI Setting

C.1 Setting AHCI	C-2
------------------------	-----

Appendix D I/O Information

D.1 I/O Address Map	D-2
D.2 1 st MB Memory Address Map	D-4
D.3 IRQ Mapping Chart	D-5
D.4 DMA Channel Assignments	D-8

Application Note

Chapter

1

**General
Information**

1.1 Introduction

AAEON introduces the slimmest product in the Boxer series, AEC-6401, which utilizes the Intel® Atom™ N2600 processor: this embedded controller expands its graphics performance greatly with the newest generation of Atom™ processors.

So far, there is no other boxer PC can be so tiny and slim like AEC-6401, not even Pico-ITX system. With this tiny dimension form factor, customers can fit it almost everywhere, and it provides quite a lot of I/O ports for basic applications. AEC-6401 adopts fanless design for high reliability to fit in most rugged environment. It also provides wireless communication features and it's really convenient for customers to build up network connection at all locations and markets.

The AEC-6401 is a standalone high performance controller designed for long-life operation and with high reliability. It can replace traditional methods and become the mainstream controller for diversified markets.

1.2 Features

- Intel® Atom™ N2600 1.6 GHz Processor
- Intel® NM10 Express chipset
- Worldwide Slimmest fanless Boxer: Compact design: (system 136 x 79.6 x 20mm)
- Uniform I/O ports: USB & RJ-45
- mini-HDMI connector for HDMI output
- Anti-drop power connector design
- RJ45 for COM port
- Aluminum CNC enclosure
- Fanless System Design

1.3 Specifications

System

- CPU Intel® Atom™ N2600 1.60GHz Processor
- Memory DDR 3 1066 SDRAM SODIMM X 1, Max.2GB
- VGA —
- Ethernet Gigabit Ethernet, RJ-45 x 1
- Hard Disk Storage —
- Solid Storage mSATA x 1
Disk
- Serial Port RJ-45 x 3 (RS-232 x1 ,
RS-232/422/485 x 2)
- USB USB 2.0 x 4
- System Control Power ON/OFF
- LED Indicator —
- Power Supply DC-in 12V
- Power Consumption Intel® Atom™ N2600 1.6GHz,
0.79A@+12V
- OS Support Windows® 7, Linux Ubuntu 12.04 or
Kernel 3.2.0 above, Windows® XP

Mechanical and Environmental

- Construction Aluminum CNC enclosure
- Color Silver
- Mounting Wallmount/Din-rail
- Dimension 4.92" (W) x 3.03" (H) x 0.79" (D) (125
x 77 x 20mm)

- Gross Weight 2.64 lb (1.2 kg)
- Operating Temperature 32°F ~ 104°F (0°C ~ 40°C) w/o Airflow
32°F ~ 131°F (0°C ~ 50°C) w/ Airflow
- Storage Temperature -4°F ~ 158°F (-20°C ~ 70°C)
- Storage Humidity 5%~ 95% @ 40°C, non-condensing
- Vibration 3g rms / 5 ~ 500Hz / operation – CFD
1g rms / 5~ 500Hz / operation – HDD
- Shock 50G peak acceleration (11 msec. duration) – CFD
20G peak acceleration (11 msec. duration) – HDD
- MTBF 50,000
- EMC CE/FCC Class A

Chapter


2

Hardware Installation


After starting the system for the first time, please refer to the chapter 4 Driver Installation, and implement the Step 5- Serial Port Driver.

2.1 Dimension and I/O of AEC-6401


Front Side View




Rear Side View




AEC-6401- Main System



AEC-6401-System with DIN-Rail




AEC-6401-System with VESA mount



2.2 Connectors and Jumpers of The Main Board

Component Side



2.3 List of Jumpers

The board has a number of jumpers that allow you to configure your system to suit your application.

The table below shows the function of each of the board's jumpers:


Label	Function
JP2	Clear CMOS
JP3	LVDS Voltage Selection
JP5	Inverter Power Selection
JP6	AT/ATX MODE SELECT

2.4 List of Connectors


The board has a number of connectors that allow you to configure your system to suit your application. The table below shows the function of each board's connectors:

Label	Function
CN7	RJ-45 Ethernet
CN8	BUZZER
CN9	RESET
CN10	LPC Expansion I/F
CN11	1X5 USB Connector
CN15	1X20 LVDS Connector
CN18	LVDS Inverter/ Backlight Connector
CN20	COM1 RS232
CN21	COM2 RS232/422/485
CN22	COM3 RS232/422/485
CN27	1X6 USB Connector

2.5 Clear CMOS Jumper (JP2)



Normal (Default)




Clear CMOS

JP2	Function
1-2	Normal (Default)
2-3	Clear CMOS

2.6 LVDS Port 1 Backlight Inverter VCC Selection (JP3)



+12V




+5V (Default)

JP3	Function
1-2	+12V
2-3	+5V (Default)

2.7 LVDS Port 1 Operating VDD Selection (JP5)



+5V




+3.3V (Default)

JP5	Function
1-2	+5V
2-3	+3.3V (Default)

2.8 AT/ATX Power Supply Mode Selection (JP6)




AT Mode



ATX Mode(Default)


JP6	Function
1-2	AT Mode
2-3	ATX Mode(Default)

2.9 Realtek LAN (RJ-45) Port (CN12)




Pin	Pin Name	Signal Type	Signal Level
1	MDI0+	DIFF	
2	MDI0-	DIFF	
3	MDI1+	DIFF	
4	MDI2+	DIFF	
5	MDI2-	DIFF	
6	MDI1-	DIFF	
7	MDI3+	DIFF	
8	MDI3-	DIFF	

2.10 COM1,RJ-45 Port (CN20)



Pin	Pin Name	Signal Type	Signal Level
1	DSR	IN	
2	RTS	OUT	
3	GND	GND	
4	TX	OUT	
5	RX	IN	
6	DCD	DIFF	
7	CTS	IN	
8	DTR	OUT	


2.11 COM2,COM3 RS232/422/485 ,RJ-45 Port (CN21,CN22)



Pin	Pin Name	Signal Type	Signal Level
1	DSR		


2	RTS		
3	GND		
4	TX		RX+
5	RX	DATA+	TX+
6	DCD	DATA-	TX-
7	CTS		
8	DTR		RX-

2.12 Buzzer (CN8)



Pin	Pin Name	Signal Type	Signal Level
1	+3.3V	PWR	+3.3V
2	SPK	OUT	


2.13 RESET (CN9)



Pin	Pin Name	Signal Type	Signal Level
1	RESET	IN	+3.3V

2	GND	GND
8	DTR	OUT


2.14 LPC Debug Port (CN10)



Pin	Pin Name	Signal Type	Signal Level
1	LAD0	I/O	+3.3V
2	LAD1	I/O	+3.3V
3	LAD2	I/O	+3.3V
4	LAD3	I/O	+3.3V
5	+3.3V	PWR	+3.3V
6	LFRAME#	IN	
7	LRESET#	OUT	+3.3V
8	GND	GND	

9	LCLK	OUT	
10	LDRQ0	IN	
11	LDRQ1	IN	
12	SERIRQ	I/O	+3.3V

2.15 USB 2.0 Port 5 (CN11)




Pin	Pin Name	Signal Type	Signal Level
1	+5V	PWR	+5V
2	USB5_D-	DIFF	
3	USB5_D+	DIFF	
4	GND	GND	
5	GND	GND	

2.16 USB 2.0 Port 4 (CN27)

Pin	Pin Name	Signal Type	Signal Level
1	+5V	PWR	+5V
2	USB4_D-	DIFF	
3	USB4_D+	DIFF	
4	GND	GND	

5	GND	GND
6	WIR_DIS	SINGLE


2.17 18-bits LVDS Output (CN15)



Pin	Pin Name	Signal Type	Signal Level
1	BKL_ENABLE	OUT	
3	LCD_PWR		+3.3V/+5V
5	LVDS_A_CLK-	DIFF	
7	LVDS_A_CLK+	DIFF	
9	LCD_PWR	DIFF	+3.3V/+5V
11	LVDS_DA0+	DIFF	
13	LVDS_DA0-	DIFF	
15	GND	GND	
17	LVDS_DA1+	DIFF	
19	LVDS_DA1-	DIFF	

2	BKL_CONTROL	OUT	
4	LCD_PWR	PWR	+3.3V/+5V
6	LVDS_DA2+	DIFF	
8	LVDS_DA2-	DIFF	
10	GND	GND	
12	LVDS_DA3+	DIFF	
14	LVDS_DA3-	DIFF	
16	GND	GND	
18	DDC_DATA	I/O	+3.3V
20	DDC_CLK	I/O	+3.3V


2.18 HDMI Type C (CN17)



Pin	Pin Name	Signal Type	Signal Level
1	GND	GND	
3	HDMI_TX2-	DIFF	
5	HDMI_TX1+	DIFF	
7	GND	GND	
9	HDMI_TX0-	DIFF	

11	HDMI_CLK+	DIFF	
13	GND	GND	
15	HDMI_DDC_CLK	I/O	+5V
17	NC	NC	
19	DPD_PWR	PWR	+5V
2	HDMI_TX2+	DIFF	
4	GND	GND	
6	HDMI_TX1-	DIFF	
8	HDMI_TX0+	DIFF	
10	GND	GND	
12	HDMI_CLK-	DIFF	
14	NC	NC	
16	HDMI_DDC_DATA	I/O	+5V
18	DPD_HPD	IN	

2.19 Inverter / Backlight Connector (CN18)



Pin	Pin Name	Signal Type	Signal Level
1	BKL_PWR	PWR	+5V / +12V

2	BKL_CONTROL	OUT	
3	GND	GND	
4	GND	GND	
5	BKL_ENABLE	OUT	+5V

2.20 DDR3 SODIMM Slot (DIMM1)

Standard specification

2.21 Mini-Card Slot (mSATA function only)

Pin	Pin Name	Signal Type	Signal Level
1	NC		
3	NC		
5	NC		
7	NC		
9	GND	GND	
11	NC		
13	NC		
15	GND	GND	
17	NC		
19	NC		
21	GND	GND	
23	mSATA_RX+	DIFF	
25	mSATA_RX-	DIFF	

27	GND	GND	
29	GND	GND	
31	mSATA_TX-	DIFF	
33	mSATA_TX+	DIFF	
35	GND	GND	
37	GND	GND	
39	+3.3V	PWR	+3.3V
41	+3.3V	PWR	+3.3V
43	NC		
45	NC		
47	NC		
49	NC		
51	NC		
2	+3.3V	PWR	+3.3V
4	GND	GND	
6	+1.5V	PWR	+1.5V
8	NC		
9	NC		
10	NC		
12	NC		


14	NC		
18	GND	GND	
20	NC		
22	NC		
24	+3.3V	PWR	+3.3V
26	GND	GND	
28	+1.5V	PWR	+1.5V
30	SMB_CLK	I/O	+3.3V
32	SMB_DATA	I/O	+3.3V
34	GND	GND	
36	NC		
38	NC		
40	GND	GND	
42	NC		
44	NC		
46	NC		
48	+1.5V	PWR	+1.5V
50	GND	GND	
52	+3.3V	PWR	+3.3V

2.22 mSATA Storage Installation

Step 1: Remove the 4pcs M2*4 screws in the bottom case.



Step 2: Install the mSATA module (screw in 2 pcs M2 x 3).




Step 3: Fasten the M4 x 4 screws in the bottom case.

2.23 DRAM Installation

Step 1: Remove the 4pcs M2*4 screws in the bottom case.



Step 2: Install the DRAM module.



Step 3: Fasten the M4 x 4 screws in the bottom case.


2.24 Mounting Bracket & Burn-Proof Bracket Installation

- Mounting bracket is the middle device for DIN-RAIL & VESA-Mount.
- Burn-Proof bracket is crucial for protective use. It's recommended to install for safety.


Step 1: Remove the 4pcs M2*4 screws in the bottom case.



Step 2: Use the longer M2*8 screws in the accessory pack to replace the M2*4 screws.



Step 3: Then fasten the screws and install both the Mounting Bracket and Burn-Proof bracket as the following graphics show.




Step 4: The installation complete photo is shown below.



2.25 DIN-RAIL Bracket Installation

Step 1: First, please install the Mounting Bracket and Burn-proof bracket as the above section 2.4 shows. Then fasten the 3 pcs M3*6 screws to install DIN-RAIL bracket.




Step 2: The side-view of the installation complete photo is shown below.



2.26 VESA-Mount Bracket Installation (for Display Panels)

Step 1: First, please install the Mounting Bracket and Burn-proof bracket as the above section 2.4 shows. Then start to install the VESA-Mount bracket for Display Panels.



Step 2: Align the AEC-6401 with the VESA-Mount bracket through the rail. Then smoothly push the AEC-6401 to fit in the bracket.



Step 3: The installation complete photos are shown below.



Bottom View



Top View

Chapter

3

AMI

BIOS Setup

3.1 System Test and Initialization

These routines test and initialize board hardware. If the routines encounter an error during the tests, you will either hear a few short beeps or see an error message on the screen. There are two kinds of errors: fatal and non-fatal. The system can usually continue the boot up sequence with non-fatal errors.

System configuration verification

These routines check the current system configuration stored in the CMOS memory and BIOS NVRAM. If system configuration is not found or system configuration data error is detected, system will load optimized default and re-boot with this default system configuration automatically.

There are four situations in which you will need to setup system configuration:

1. You are starting your system for the first time
2. You have changed the hardware attached to your system
3. The system configuration is reset by Clear-CMOS jumper
4. The CMOS memory has lost power and the configuration information has been erased.

The AEC-6401 CMOS memory has an integral lithium battery backup for data retention. However, you will need to replace the

complete unit when it finally runs down.

3.2 AMI BIOS Setup

AMI BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM and BIOS NVRAM so that it retains the Setup information when the power is turned off.

Entering Setup

Power on the computer and press or <F2> immediately. This will allow you to enter Setup.

Main

Set the date, use tab to switch between date elements.

Advanced

Enable/disable boot option for legacy network devices.

Chipset

Host bridge parameters.

Boot

Enables/disables quiet boot option.

Security


Set setup administrator password.

Save & Exit

Exit system setup after saving the changes.

Setup Menu


Setup submenu: Main



Options summary: (**default setting**)

System Date	Day MM:DD:YYYY	
Change the month, year and century. The 'Day' is changed automatically.		
System Time	HH : MM : SS	
Change the clock of the system.		

Setup submenu: Advanced



Options summary: (**default setting**)

ACPI Settings		
System ACPI Parameters		
CPU Configuration		
CPU Configuration Parameters		
IDE Configuration		
IDE Device Options Settings		
USB Configuration		
USB Configuration Parameters		
F81801 Super IO Configuration		
System Super IO Parameters		
F81216 Second Super IO Configuration		
System Second Super IO Parameters		
Digital IO Port Configuration		
DIO configuration		
H/W Monitor		
Monitor hardware status		

ACPI Settings

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.

Advanced

<p>ACPI Settings</p> <p>Enable Hibernation [Enabled]</p> <p>ACPI Sleep State [AUTO]</p> <p>Wake on Ring [Enabled]</p> <p>▶ RTC Wake Settings</p>	<p>Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.</p> <hr/> <p> ⇐: Select Screen ↑: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit </p>
--	--

Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Options summary: (*default setting*)

Enable Hibernation	Enabled	
	Disabled	
Enabled or disabled hibernate (OS/S4 Sleep State).		
ACPI Sleep State	Suspend Disabled	
	S1 only(CPU Stop Clock)	
	S3 only(Suspend to RAM)	
	AUTO	
Select the ACPI state used for System Suspend		
Wake on Ring	Enabled	
	Disabled	
Enabled or disabled wake on ring function.		
RTC Wake Settings		
Enable system to wake from S5 using RTC alarm.		

RTC Wake Settings

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.

Advanced

Wake system with Fixed Time	[Enabled]	Enable or disable System wake on alarm event. When enabled, System will wake on the hr::min::sec specified
Wake up day	0	
Wake up hour	0	
Wake up minute	0	
Wake up second	0	
Wake system with Dynamic Time	[Disabled]	
Wake up minute increase	1	

++: Select Screen
 ↑: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 ESC: Exit

Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Options summary: *(default setting)*

Wake system with Fixed Time	Disabled	
	Enabled	
Enable or disable System wake on alarm event. Wake up time is setting by following settings.		
Wake up day	0-31	
Select 0 for daily system wake up 1-31 for which day of the month that you would like the system to wake up		
Wake up hour	0-23	
Wake up minute	0-59	
Wake up second	0-59	
Wake system with Dynamic Time	Disabled	
	Enabled	
Enable or disable System wake on alarm event. Wake up time is current time + Increase minutes.		
Wake up minute increase	1-5	

CPU Configuration

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.

Advanced

CPU Configuration		Enabled for Windows XP and Linux (OS optimized for Hyper-Threading Technology) and Disabled for other OS (OS not optimized for Hyper-Threading Technology).
Processor Type	Intel(R) Atom(TM) CPU N2	
EMT64	Not Supported	
Processor Speed	1600 MHz	
System Bus Speed	400 MHz	
Ratio Status	16	
Actual Ratio	16	
System Bus Speed	400 MHz	
Processor Stepping	30661	
Microcode Revision	269	
L1 Cache RAM	2x56 k	
L2 Cache RAM	2x512 k	
Processor Core	Dual	
Hyper-Threading	Supported	
Hyper-Threading	[Enabled]	
Execute Disable Bit	[Enabled]	
Limit CPUID Maximum	[Disabled]	
CPU Smart Thermal Control	[Disabled]	


←: Select Screen
 ↑↓: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 ESC: Exit

Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Options summary: (*default setting*)

Hyper-Threading	Disabled	
	Enabled	
En/Disable CPU Hyper-Threading function		
Execute Disable Bit	Disabled	
	Enabled	
En/Disable XD bit for supporting OS		
Limit CPUID Maximum	Disabled	
	Enabled	
Disabled for Windows XP		
CPU Smart Thermal Control	Disabled	
	55	
	60	
	65	
	70	
CPU will reduce frequency automatically when CPU temperature higher than the setting value.		

IDE Configuration



Options summary: (default setting)

SATA Controller(s)	Disabled	
	Enabled	
En/Disable SATA controller		
Configure SATA as	IDE	
	AHCI	
Configure SATA controller operating as IDE/AHCI mode.		

USB Configuration

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.	
Advanced	
USB Configuration USB Devices: 1 Drive, 1 Keyboard, 1 Mouse Legacy USB Support [Enabled] Mass Storage Devices: USB Device ModelName [Auto]	Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications. <hr/> ** : Select Screen Tl : Select Item Enter : Select +/- : Change Opt. F1 : General Help F2 : Previous Values F3 : Optimized Defaults F4 : Save & Exit ESC : Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.	

Options summary: **(default setting)**

Legacy USB Support	Enabled	
	Disabled	
	Auto	
<p>Enables BIOS Support for Legacy USB Support. When enabled, USB can be functional in legacy environment like DOS. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI application</p>		
Device Name (Emulation Type)	Auto	
	Floppy	
	Forced FDD	
	Hard Disk	
	CD-ROM	
<p>If Auto. USB devices less than 530MB will be emulated as Floppy and remaining as Floppy and remaining as hard drive. Forced FDD option can be used to force a HDD formatted drive to boot as FDD(Ex. ZIP drive)</p>		

F81801 Super IO Configuration



Options summary: (**default setting**)

Serial Port 1/2 Configuration		
Set Parameters of Serial Port 1/2		

Serial Port 1 Configuration

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.

Advanced

Serial Port 1 Configuration	Enable or Disable Serial Port (COM)
Serial Port [Enabled]	
Device Settings IO=3F8h; IRQ=4;	
Change Settings [Auto]	
	++: Select Screen !: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Options summary: *(default setting)*

Serial Port	Disabled	
	Enabled	
En/Disable specified serial port.		
Change Settings	Auto	
	IO=3F8h; IRQ=4;	
	IO=3F8h; IRQ=3,4,5,7,10,11,12;	
	IO=2F8h; IRQ=3,4,5,7,10,11,12;	
	IO=3E8h; IRQ=3,4,5,7,10,11,12;	
	IO=2E8h; IRQ=3,4,5,7,10,11,12;	
Select a resource setting for Super IO device.		

Serial Port 2 Configuration

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.

Advanced

<p>Serial Port 2 Configuration</p> <p>Serial Port [Enabled]</p> <p>Device Settings IO=2F8h; IRQ=3;</p> <p>Change Settings [Auto]</p> <p>Device Type [RS232]</p>	<p>Enable or Disable Serial Port (COM)</p> <hr/> <p> ** : Select Screen Tl : Select Item Enter : Select +/- : Change Opt. F1 : General Help F2 : Previous Values F3 : Optimized Defaults F4 : Save & Exit ESC : Exit </p>
---	---

Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Options summary: (*default setting*)

Serial Port	Disabled	
	Enabled	
En/Disable specified serial port.		
Change Settings	Auto	
	IO=2F8h; IRQ=3;	
	IO=3F8h; IRQ=3,4,5,7,10,11,12;	
	IO=2F8h; IRQ=3,4,5,7,10,11,12;	
	IO=3E8h; IRQ=3,4,5,7,10,11,12;	
	IO=2E8h; IRQ=3,4,5,7,10,11,12;	
Select a resource setting for Super IO device.		
Device Type	RS232	
	RS422	
	RS485	
Configure COM2 operated as RS232, RS422 or RS485.		

F81216 Second Super IO Configuration



Options summary: (**default setting**)

Serial Port 3 Configuration		
Set Parameters of Serial Port 3		

Serial Port 3 Configuration

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.

Advanced

Serial Port 3 Configuration		Enable or Disable Serial Port (COM)
Serial Port	[Enabled]	
Device Settings	IO=200h; IRQ=5;	
Change Settings	[Auto]	
Device Type	[RS232]	

←: Select Screen
 ↑↓: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 ESC: Exit

Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Options summary: *(default setting)*

Serial Port	Disabled	
	Enabled	
En/Disable specified serial port.		
Change Settings	Auto	
	IO=2C0h; IRQ=5;	
	IO=2C0h; IRQ=3,4,5,9,10,11;	
	IO=2C8h; IRQ=3,4,5,9,10,11;	
	IO=2B0h; IRQ=3,4,5,9,10,11;	
	IO=2B8h; IRQ=3,4,5,9,10,11;	
Select a resource setting for Super IO device.		
Device Type	RS232	
	RS422	
	RS485	
Configure COM2 operated as RS232, RS422 or RS485.		

H/W Monitor

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.


Advanced

Pc Health Status	
CPU temperature	: +35 C
System temperature	: +35 C
CPU_VCORE	: +1.088 V
VCC_DIMM	: +1.512 V
3.3V	: +3.328 V
3VSB	: +3.360 V
VBAT	: +3.216 V

⇧⇧: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.


Setup submenu: Chipset



Options summary: **(default setting)**

Host Bridge		
Host Bridge Parameters		
South Bridge		
South Bridge Parameters		


Host Bridge



Options summary: (*default setting*)

Fixed Graphics Memory	128MB	
Size	256MB	
Configure Fixed Graphics Memory Size		


South Bridge



Options summary: (*default setting*)

Onboard Devices		
Onboard devices parameters configurations		
High Precision Timer	Enabled	
	Disabled	
Enable or Disable the High Precision Event Timer		
Power Mode	ATX Type	
	AT Type	
Select the power type used on the system		
SLP_S4 Assertion Width	1-2 Seconds	
	2-3 Seconds	
	3-4 Seconds	
	4-5 Seconds	
Select a minimum assertion width of the SLP_S4# signal		
Restore AC Power Loss	Power On	
	Power Off	
	Last State	
Select AC power state when power is re-applied after a power failure.		


Onboard Devices



Options summary: (**default setting**)

LAN Controller	Disabled	
	Enabled	
Enable or disable Realtek R8111E PCIE Lan Device		
SMBus Controller	Disabled	
	Enabled	
Enable or Disable OnChip SMBus Controller		


Setup submenu: Boot



Options summary: (default setting)

Quiet Boot	Disabled	
	Enabled	
En/Disable showing boot logo.		
Launch LAN PXE OpROM	Disabled	
	Enabled	
En/Disable PXE boot for RTL8111E LAN		
Boot Option #X/		
XXXX Drive BBS Priorities		
The order of boot priorities.		

BBS Priorities



Options summary: **(default setting)**

Boot Option #x	Disabled	
	Device name	
Sets the system boot order		

Setup submenu: Security



Options summary: *(default setting)*

Administrator Password/	Not set	
User Password		
<p>You can install a Supervisor password, and if you install a supervisor password, you can then install a user password. A user password does not provide access to many of the features in the Setup utility.</p> <p><i>Install the Password:</i></p> <p>Press Enter on this item, a dialog box appears which lets you enter a password. You can enter no more than six letters or numbers. Press Enter after you have typed in the password. A second dialog box asks you to retype the password for confirmation. Press Enter after you have retyped it correctly. The password is required at boot time, or when the user enters the Setup utility.</p> <p><i>Removing the Password:</i></p> <p>Highlight this item and type in the current password. At the next dialog box press Enter to disable password protection.</p>		

HDD Security

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.

Security


<p>HDD Password Description :</p> <p>Allows Access to Set, Modify and Clear HardDisk User and Master Passwords. User Password need to be installed for Enabling Security. Master Password can be Modified only when successfully unlocked with Master Password in POST.</p> <p>HDD PASSWORD CONFIGURATION:</p> <p>Security Supported : Yes</p> <p>Security Enabled : No</p> <p>Security Locked : No</p> <p>Security Frozen : No</p> <p>HDD User Pwd Status : NOT INSTALLED</p> <p>HDD Master Pwd Status : INSTALLED</p> <p>Set User Password</p> <p>Set Master Password</p>		<p>←→: Select Screen</p> <p>↑↓: Select Item</p> <p>Enter: Select</p> <p>+/-: Change Opt.</p> <p>F1: General Help</p> <p>F2: Previous Values</p> <p>F3: Optimized Defaults</p> <p>F4: Save & Exit</p> <p>ESC: Exit</p>
---	--	---

Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Options summary: *(default setting)*

Set User Password/	Not set	
Set Master Password		
<p>You can install a Master and User password. Before booting to OS, HDD will be set to frozen state. On S3 resume HDD will be unlocked using the HDD Password we entered while system booting.</p> <p><i>Install the Password:</i></p> <p>Press Enter on this item, a dialog box appears which lets you enter a password. You can enter no more than six letters or numbers. Press Enter after you have typed in the password. A second dialog box asks you to retype the password for confirmation. Press Enter after you have retyped it correctly. The password is required at boot time, or when the user enters the Setup utility.</p> <p><i>Removing the Password:</i></p> <p>Highlight this item and type in the current password. At the next dialog box press Enter to disable password protection.</p>		

Setup submenu: Exit



Options summary: *(default setting)*

Save Changes and Reset		
Reset the system after saving the changes		
Discard Changes and Reset		
Reset system setup without saving any changes		
Restore Defaults		
Restore/Load Default values for all the setup options.		
Save as User Defaults		
Save the changes done so far as User Defaults		
Restore User Defaults		
Restore the User Defaults to all the setup options		

Chapter

4

**Driver
Installation**

The AEC-6401 comes with an AutoRun CD-ROM that contains all drivers and utilities that can help you to install the driver automatically.

Insert the driver CD, the driver CD-title will auto start and show the installation guide. If not, please follow the sequence below to install the drivers.

Follow the sequence below to install the drivers:

Step 1 – Install Chipset Driver

Step 2 – Install VGA Driver

Step 3 – Install LAN Driver

Step 4 – Install AHCI Driver

Step 5 – Install Serial Port Driver (Optional)

Step 6 – Install Wireless Driver (Optional)

Please read instructions below for further detailed installations.

4.1 Installation:

Insert the AEC-6401 CD-ROM into the CD-ROM drive. And install the drivers from Step 1 to Step 6 in order.

Step 1 – Install Chipset Driver

1. Click on the **STEP1-CHIPSET** folder and select the OS folder your system is
2. Double click on the **infinst_autol_1034.exe** file located in each OS folder
3. Follow the instructions that the window shows
4. The system will help you install the driver automatically

Step 2 – Install VGA Driver

For Windows® 7



1. Click on the **STEP2-VGA** folder and select the folder of **WIN7_32**
2. Double click on the **Setup.exe** file
3. Follow the instructions that the window shows
4. The system will help you install the driver automatically


For Windows® XP

1. Install Framework 3.5
 - Double click on the **dotnetfx35.exe**
 - Follow the instructions that the window shows
 - The system will help you install the driver automatically

2. Install IEMGD

- Double click on the **WindowsDriverSETUP.exe**
- Select the configuration
- Follow the instructions that the window shows
- The system will help you install the driver automatically






If you want to update driver, please uninstall driver first.

Uninstall IEMGD

1. Double click on the **WindowsDriverSETUP.exe**
2. Follow the instructions that the window shows
3. The system will help you uninstall the driver automatically



Step 3 – Install LAN Driver

1. Click on the **STEP3-LAN** folder and select the OS folder your system is
2. Double click on the **setup.exe** file located in each OS folder
3. Follow the instructions that the window shows
4. The system will help you install the driver automatically

Step 4 – Install AHCI Driver

Please refer to the Appendix C AHCI Settings


Step 5 – Serial Port Driver (Optional)

For Windows® XP:


1. Click on the **STEP5-Serial Port Driver (Optional)** and select the folder of **WINXP_32**
2. Double click on **patch.bat** file
3. Follow the instructions that the window shows
4. The system will help you install the driver automatically

For Windows® 7:


1. Create a password for Administrator account.




2. Change User Account Control Settings to [Never notify]



3. Reboot and Administrator login.



4. To run patch.bat with [Run as administrator].



Step 6 – Install Wireless Driver (Optional)

1. Click on the **STEP6-Wireless (Optional)** folder and select the OS folder your system is.
2. Double click on the **.exe** located in each OS folder
3. Follow the instructions that the window shows
4. The system will help you install the driver automatically

Appendix

A

Programming the Watchdog Timer

A.1 Watchdog Timer Registers

Table 1 : Watch dog relative IO address		
	Default Value	Note
I/O Base Address	0xA00	I/O Base address for Watchdog operation. This address is assigned by SIO LDN7, register 0x60-0x61.

Table 2 : Watchdog relative register table				
Register	Offset	BitNum	Value	Note
Watchdog WDTRST# Enable	0x00	7	1	Enable/Disable time out output via WDTRST# 0: Disable 1: Enable
Pulse Width	0x05	0:1	01	Width of Pulse signal 00: 1ms (do not use) 01: 25ms 10: 125ms 11: 5s Pulse width is must longer then 16ms.
Signal Polarity	0x05	2	0	0: low active 1: high active Must set this bit to 0
Counting Unit	0x05	3	0	Select time unit. 0: second 1: minute
Output Signal Type	0x05	4	1	0: Level 1: Pulse Must set this bit to 1
Watchdog Timer Enable	0x05	5	1	0: Disable 1: Enable
Timeout Status	0x05	6	1	1: timeout occurred. Write a 1 to clear timeout status
Timer Counter	0x06			Time of watchdog timer (0~255)

A.2 WatchDog Sample Program

```

*****
****
// WDT I/O operation relative definition (Please reference to Table 1)
#define WDTAddr      0xA00 // WDT I/O base address
Void WDTWriteByte(byte Register, byte Value);
byte WDTReadByte(byte Register);
Void WDTSetReg(byte Register, byte Bit, byte Val);
// Watch Dog relative definition (Please reference to Table 2)
#define DevReg       0x00 // Device configuration register
    #define WDRstBit  0x80 // Watchdog WDRST# (Bit7)
    #define WDRstVal  0x80 // Enabled WDRST#
#define TimerReg     0x05 // Timer register
    #define PSWidthBit 0x00 // WDRST# Pulse width (Bit0:1)
    #define PSWidthVal 0x01 // 25ms for WDRST# pulse
    #define PolarityBit 0x02 // WDRST# Signal polarity (Bit2)
    #define PolarityVal 0x00 // Low active for WDRST#
    #define UnitBit     0x03 // Unit for timer (Bit3)
    #define ModeBit     0x04 // WDRST# mode (Bit4)
    #define ModeVal     0x01 // 0: level 1: pulse
    #define EnableBit   0x05 // WDT timer enable (Bit5)
    #define EnableVal   0x01 // 1: enable
    #define StatusBit   0x06 // WDT timer status (Bit6)
#define CounterReg   0x06 // Timer counter register
*****
****

*****
****
VOID Main(){
    // Procedure : AeonWDTConfig
    // (byte)Timer : Counter of WDT timer.(0x00~0xFF)
    // (boolean)Unit : Select time unit(0: second, 1: minute).
    AeonWDTConfig(Counter, Unit);
}

```

```

    // Procedure : AaeonWDTEnable
    // This procedure will enable the WDT counting.
    AaeonWDTEnable();
}
*****
*****

// Procedure : AaeonWDTEnable
VOID AaeonWDTEnable (){
    WDTEnableDisable(1);
}

// Procedure : AaeonWDTConfig
VOID AaeonWDTConfig (byte Counter, BOOLEAN Unit){
    // Disable WDT counting
    WDTEnableDisable(0);
    // Clear Watchdog Timeout Status
    WDTClearTimeoutStatus();
    // WDT relative parameter setting
    WDTParameterSetting(Timer, Unit);
}

VOID WDTEnableDisable(byte Value){
    If (Value == 1)
        WDTSetBit(TimerReg, EnableBit, 1);
    else
        WDTSetBit(TimerReg, EnableBit, 0);
}

VOID WDTParameterSetting(byte Counter, BOOLEAN Unit){
    // Watchdog Timer counter setting
    WDTWriteByte(CounterReg, Counter);
    // WDT counting unit setting
    WDTSetBit(TimerReg, UnitBit, Unit);
}

```

```

// WDT output mode set to pulse
WDTSetBit(TimerReg, ModeBit, ModeVal);
// WDT output mode set to active low
WDTSetBit(TimerReg, PolarityBit, PolarityVal);
// WDT output pulse width is 25ms
WDTSetBit(TimerReg, PSWidthBit, PSWidthVal);
// Watchdog WDRST# Enable
WDTSetBit(DevReg, WDRstBit, WDRstVal);
}

VOID WDTClearTimeoutStatus(){
    WDTSetBit(TimerReg, StatusBit, 1);
}

*****

*****

VOID WDTWriteByte(byte Register, byte Value){
    IOWriteByte(WDTAddr+Register, Value);
}

byte WDTReadByte(byte Register){
    return IOReadByte(WDTAddr+Register);
}

VOID WDTSetBit(byte Register, byte Bit, byte Val){
    byte TmpValue;

    TmpValue = WDTReadByte(Register);
    TmpValue &= ~(1 << Bit);
    TmpValue |= Val << Bit;
    WDTWriteByte(Register, TmpValue);
}

*****

*****

```


Appendix

B

Digital I/O Ports

B.1 Electrical Specifications for Digital I/O Ports

Table 1 : Digital Input/Output Pin Electrical Specification						
Pin	Type	Input Threshold Voltage		Output Voltage		Note
		Low	High	Low	High	
DIO1	I/O	0.8	2.0	0	3.3	
DIO2	I/O	0.8	2.0	0	3.3	
DIO3	I/O	0.8	2.0	0	3.3	
DIO4	I/O	0.8	2.0	0	3.3	

Note: All DIO pins are 5V tolerance in input mode.

B.2 DIO Programming

AEC-6401 utilizes FINTEK F81801U chipset as its Digital I/O controller. Below are the procedures to complete its configuration and the AAeon initial DIO program is also attached based on which you can develop customized program to fit your application. There are three steps to complete the configuration setup: (1) Enter the MB PnP Mode; (2) Modify the data of configuration registers; (3) Exit the MB PnP Mode. Undesired result may occur if the MB PnP Mode is not exited normally.

B.3 Digital I/O Register

	Default Value	Note
Index	0x2E	SIO MB PnP Mode Index Register 0x2E or 0x4E
Data	0x2F)	SIO MB PnP Mode Data Register 0x2F or 0x4F

	LDN	Register	BitNum	Note
GPIO1 Direction	0x06	0xD0	0	0:input, 1: output
GPIO2 Direction	0x06	0xD0	1	
GPIO3 Direction	0x06	0xD0	2	
GPIO4 Direction	0x06	0xD0	3	
GPIO1 Output Level	0x06	0xD1	0	0:low, 1: high
GPIO2 Output Level	0x06	0xD1	1	
GPIO3 Output Level	0x06	0xD1	2	
GPIO4 Output Level	0x06	0xD1	3	
GPIO1 Status	0x06	0xD2	0	0:low, 1: high
GPIO2 Status	0x06	0xD2	1	
GPIO3 Status	0x06	0xD2	2	
GPIO4 Status	0x06	0xD2	3	

B.4 Digital I/O Sample Program

```

*****
// SuperIO relative definition (Please reference to Table 2)
#define SI0Index 0x2E
#define SI0Data 0x2F
#define DI0LDN 0x06
IOWriteByte(byte IOPort, byte Value);
IOReadByte(byte IOPort);
// DI0 relative definition (Please reference to Table 3)
#define DirReg 0xD0 // 0: input, 1: output
    #define InputPin 0x00
    #define OutputPin 0x01
#define OutputReg 0xD1 // 0: low, 1: high
#define StatusReg 0xD2 // 0: low, 1: high
    #define PinLow 0x00
    #define PinHigh 0x01
#define Pin1Bit 0x00
#define Pin2Bit 0x01
#define Pin3Bit 0x02
#define Pin4Bit 0x03
*****

*****
VOID Main(){
    Boolean PinStatus ;

    // Procedure : AeonReadPinStatus
    // Input :
    // Example, Read Digital I/O Pin 3 status
    // Output :
    // InputStatus :
    // 0: Digital I/O Pin level is low
    // 1: Digital I/O Pin level is High
    PinStatus = AeonReadPinStatus(Pin3Bit);
}

```



```

// Procedure : AaeonSetOutputLevel
// Input :
// Example, Set Digital I/O Pin 2 to high level
AaeonSetOutputLevel(Pin2Bit, PinHigh);
}
*****

*****
Boolean AaeonReadPinStatus(byte PinBit){
    Boolean PinStatus ;

    PinStatus = SIOBitRead(DIOLDN, StatusReg, PinBit);
    Return PinStatus ;
}
VOID AaeonSetOutputLevel(byte PinBit, byte Value){
    ConfigDioMode(PinBit, OutputPin);
    SIOBitSet(DIOLDN, OutputReg, PinBit, Value);
}
*****
*****

*****VOID SIOEnterMBPnPMode(){
    IOWriteByte(SIOIndex, 0x87);
    IOWriteByte(SIOIndex, 0x87);
}

VOID SIOExitMBPnPMode(){
    IOWriteByte(SIOIndex, 0xAA);
}

VOID SIOSelectLDN(byte LDN){
    IOWriteByte(SIOIndex, 0x07); // SIO LDN Register Offset = 0x07
    IOWriteByte(SIOData, LDN);
}

VOID SIOBitSet(byte LDN, byte Register, byte BitNum, byte Value){

```

```
Byte TmpValue;

SIOEnterMBPnPMode();
SIOSelectLDN(LDN);
IOWriteByte(SIOIndex, Register);
TmpValue = IOReadByte(SIOData);
TmpValue &= ~(1 << BitNum);
TmpValue |= (Value << BitNum);
IOWriteByte(SIOData, TmpValue);
SIOExitMBPnPMode();
}

VOID SIOByteSet(byte LDN, byte Register, byte Value){
    SIOEnterMBPnPMode();
    SIOSelectLDN(LDN);
    IOWriteByte(SIOIndex, Register);
    IOWriteByte(SIOData, Value);
    SIOExitMBPnPMode();
}
*****
*****
```

Boolean **SIOBitRead**(byte LDN, byte Register, byte BitNum){

Byte TmpValue;

SIOEnterMBPnPMode();

SIOSelectLDN(LDN);

IOWriteByte(SIOIndex, Register);

TmpValue = IOReadByte(SIOData);

TmpValue &= (1 << BitNum);

SIOExitMBPnPMode();

If(TmpValue == 0)

Return 0;

Return 1;

}

VOID **ConfigDioMode**(byte PinBit, byte Mode){

Byte TmpValue;

SIOEnterMBPnPMode();

SIOSelectLDN(DIOLDN);

IOWriteByte(SIOIndex, DirReg);

TmpValue = IOReadByte(SIOData);

TmpValue |= (Mode << PinBit);

IOWriteByte(SIOData, DirReg);

SIOExitMBPnPMode();

}

Appendix

C

AHCI Setting

C.1 Setting AHCI


OS installation to setup AHCI Mode.

Step 1: Copy the files below from “Driver CD -> STEP5-AHCI\WIN7_32\F6

Install Floppy Create for 32 and 64 bit Windows” to Disk




Step 2: Setup OS



Step 3: Press "F6"



Step 4: Choose "S"




Step 5: Choose "Intel® NM10 Express Chipset"



Step 6: It will show the model number you select and then press "ENTER"

Step 7: Setup is loading files



Appendix

D

I/O Information

D.1 I/O Address Map

Input/output (IO)	
[00000000 - 0000001F]	Direct memory access controller
[00000000 - 00000CF7]	PCI bus
[00000010 - 0000001F]	Motherboard resources
[00000020 - 00000021]	Programmable interrupt controller
[00000022 - 0000003F]	Motherboard resources
[00000024 - 00000025]	Programmable interrupt controller
[00000028 - 00000029]	Programmable interrupt controller
[0000002C - 0000002D]	Programmable interrupt controller
[0000002E - 0000002F]	Motherboard resources
[00000030 - 00000031]	Programmable interrupt controller
[00000034 - 00000035]	Programmable interrupt controller
[00000038 - 00000039]	Programmable interrupt controller
[0000003C - 0000003D]	Programmable interrupt controller
[00000040 - 00000043]	System timer
[00000044 - 0000005F]	Motherboard resources
[0000004E - 0000004F]	Motherboard resources
[00000050 - 00000053]	System timer
[00000061 - 00000061]	Motherboard resources
[00000062 - 00000063]	Motherboard resources
[00000063 - 00000063]	Motherboard resources
[00000063 - 00000063]	Motherboard resources
[00000065 - 00000065]	Motherboard resources
[00000065 - 0000006F]	Motherboard resources
[00000067 - 00000067]	Motherboard resources
[00000070 - 00000070]	Motherboard resources
[00000070 - 00000077]	System CMOS/real time clock
[00000072 - 0000007F]	Motherboard resources
[00000080 - 00000080]	Motherboard resources
[00000080 - 00000080]	Motherboard resources
[00000081 - 00000091]	Direct memory access controller
[00000084 - 00000086]	Motherboard resources
[00000088 - 00000088]	Motherboard resources
[0000008C - 0000008E]	Motherboard resources
[00000090 - 0000009F]	Motherboard resources
[00000092 - 00000092]	Motherboard resources
[00000093 - 0000009F]	Direct memory access controller
[000000A0 - 000000A1]	Programmable interrupt controller
[000000A2 - 000000BF]	Motherboard resources
[000000A4 - 000000A5]	Programmable interrupt controller
[000000A8 - 000000A9]	Programmable interrupt controller
[000000AC - 000000AD]	Programmable interrupt controller
[000000B0 - 000000B1]	Programmable interrupt controller
[000000B2 - 000000B3]	Motherboard resources
[000000B4 - 000000B5]	Programmable interrupt controller
[000000B8 - 000000B9]	Programmable interrupt controller
[000000BC - 000000BD]	Programmable interrupt controller
[000000C0 - 000000DF]	Direct memory access controller
[000000E0 - 000000EF]	Motherboard resources
[000000F0 - 000000F0]	Numeric data processor


















































[000000A0 - 000000A1]	Programmable interrupt controller
[000000A2 - 000000BF]	Motherboard resources
[000000A4 - 000000A5]	Programmable interrupt controller
[000000A8 - 000000A9]	Programmable interrupt controller
[000000AC - 000000AD]	Programmable interrupt controller
[000000B0 - 000000B1]	Programmable interrupt controller
[000000B2 - 000000B3]	Motherboard resources
[000000B4 - 000000B5]	Programmable interrupt controller
[000000B8 - 000000B9]	Programmable interrupt controller
[000000BC - 000000BD]	Programmable interrupt controller
[000000C0 - 000000DF]	Direct memory access controller
[000000E0 - 000000EF]	Motherboard resources
[000000F0 - 000000F0]	Numeric data processor
[000002C0 - 000002C7]	Communications Port (COM3)
[000002F8 - 000002FF]	Communications Port (COM2)
[000003B0 - 000003BB]	Intel(R) Graphics Media Accelerator 3600 Series
[000003C0 - 000003DF]	Intel(R) Graphics Media Accelerator 3600 Series
[000003F8 - 000003FF]	Communications Port (COM1)
[00000400 - 0000047F]	Motherboard resources
[00000400 - 0000047F]	Motherboard resources
[000004D0 - 000004D1]	Motherboard resources
[000004D0 - 000004D1]	Programmable interrupt controller
[00000500 - 0000053F]	Motherboard resources
[00000500 - 0000057F]	Motherboard resources
[00000600 - 0000061F]	Motherboard resources
[00000680 - 0000069F]	Motherboard resources
[000006A0 - 000006AF]	Motherboard resources
[000006B0 - 000006EF]	Motherboard resources
[00000A00 - 00000A0F]	Motherboard resources
[00000A10 - 00000A1F]	Motherboard resources
[00000D00 - 0000FFFF]	PCI bus
[00001000 - 0000100F]	Motherboard resources
[0000E000 - 0000E0FF]	Realtek PCIe GBE Family Controller
[0000E000 - 0000EFFF]	Intel(R) N10/ICH7 Family PCI Express Root Port - 27D0
[0000F000 - 0000F01F]	Intel(R) N10/ICH7 Family SMBus Controller - 27DA
[0000F020 - 0000F03F]	Intel(R) N10/ICH7 Family USB Universal Host Controller - 27CB
[0000F040 - 0000F05F]	Intel(R) N10/ICH7 Family USB Universal Host Controller - 27CA
[0000F060 - 0000F07F]	Intel(R) N10/ICH7 Family USB Universal Host Controller - 27C9
[0000F080 - 0000F09F]	Intel(R) N10/ICH7 Family USB Universal Host Controller - 27C8
[0000F0A0 - 0000F0AF]	Intel(R) N10/ICH7 Family Serial ATA Storage Controller - 27C0
[0000F0B0 - 0000F0BF]	Intel(R) N10/ICH7 Family Serial ATA Storage Controller - 27C0
[0000F0C0 - 0000F0CF]	Intel(R) N10/ICH7 Family Serial ATA Storage Controller - 27C0
[0000F0D0 - 0000F0D3]	Intel(R) N10/ICH7 Family Serial ATA Storage Controller - 27C0
[0000F0E0 - 0000F0E7]	Intel(R) N10/ICH7 Family Serial ATA Storage Controller - 27C0
[0000F0F0 - 0000F0F7]	Intel(R) Graphics Media Accelerator 3600 Series
[0000FFFF - 0000FFFF]	Motherboard resources
[0000FFFF - 0000FFFF]	Motherboard resources













































D.2 1st MB Memory Address Map

Address Range	Hardware Component
[00000000 - 00000FFF]	Motherboard resources
[00000000 - 00000FFF]	Motherboard resources
[00000000 - 00003FFF]	Motherboard resources
[000A0000 - 000BFFFF]	Intel(R) Graphics Media Accelerator 3600 Series
[000A0000 - 000BFFFF]	PCI bus
[000C0000 - 000DFFFF]	PCI bus
[000E0000 - 000EFFFF]	PCI bus
[000F0000 - 000FFFFFF]	PCI bus
[3F800000 - 3FFFFFFF]	PCI bus
[40000000 - FEBFFFFFF]	PCI bus
[DFD00000 - DFDFFFFFF]	Intel(R) Graphics Media Accelerator 3600 Series
[DFE00000 - DFE03FFF]	Realtek PCIe GBE Family Controller
[DFE00000 - DFEFFFFFF]	Intel(R) N10/ICH7 Family PCI Express Root Port - 27D0
[DFE04000 - DFE04FFF]	Realtek PCIe GBE Family Controller
[DFF00000 - DFF003FF]	Intel(R) N10/ICH7 Family Serial ATA Storage Controller - 27C0
[DFF01000 - DFF013FF]	Intel(R) N10/ICH7 Family USB2 Enhanced Host Controller - 27CC
[E0000000 - EFFFFFFF]	System board
[FEC00000 - FEC00FFF]	Motherboard resources
[FED00000 - FED003FF]	High precision event timer
[FED14000 - FED19FFF]	System board
[FED1C000 - FED1FFFF]	Motherboard resources
[FED1C000 - FED1FFFF]	Motherboard resources
[FED20000 - FED8FFFF]	Motherboard resources
[FED45000 - FED8FFFF]	Motherboard resources
[FEE00000 - FEE00FFF]	Motherboard resources
[FF000000 - FFFFFFFF]	Intel(R) 82802 Firmware Hub Device
[FF000000 - FFFFFFFF]	Intel(R) 82802 Firmware Hub Device
[FFC00000 - FFFFFFFF]	Motherboard resources


D.3 IRQ Mapping Chart

Interrupt request (IRQ)	
(ISA) 0x00000000 (00)	System timer
(ISA) 0x00000003 (03)	Communications Port (COM2)
(ISA) 0x00000004 (04)	Communications Port (COM1)
(ISA) 0x00000005 (05)	Communications Port (COM3)
(ISA) 0x00000008 (08)	System CMOS/real time clock
(ISA) 0x0000000D (13)	Numeric data processor
(ISA) 0x00000051 (81)	Microsoft ACPI-Compliant System
(ISA) 0x00000052 (82)	Microsoft ACPI-Compliant System
(ISA) 0x00000053 (83)	Microsoft ACPI-Compliant System
(ISA) 0x00000054 (84)	Microsoft ACPI-Compliant System
(ISA) 0x00000055 (85)	Microsoft ACPI-Compliant System
(ISA) 0x00000056 (86)	Microsoft ACPI-Compliant System
(ISA) 0x00000057 (87)	Microsoft ACPI-Compliant System
(ISA) 0x00000058 (88)	Microsoft ACPI-Compliant System
(ISA) 0x00000059 (89)	Microsoft ACPI-Compliant System
(ISA) 0x0000005A (90)	Microsoft ACPI-Compliant System
(ISA) 0x0000005B (91)	Microsoft ACPI-Compliant System
(ISA) 0x0000005C (92)	Microsoft ACPI-Compliant System
(ISA) 0x0000005D (93)	Microsoft ACPI-Compliant System
(ISA) 0x0000005E (94)	Microsoft ACPI-Compliant System
(ISA) 0x0000005F (95)	Microsoft ACPI-Compliant System
(ISA) 0x00000060 (96)	Microsoft ACPI-Compliant System
(ISA) 0x00000061 (97)	Microsoft ACPI-Compliant System
(ISA) 0x00000062 (98)	Microsoft ACPI-Compliant System
(ISA) 0x00000063 (99)	Microsoft ACPI-Compliant System
(ISA) 0x00000064 (100)	Microsoft ACPI-Compliant System
(ISA) 0x00000065 (101)	Microsoft ACPI-Compliant System
(ISA) 0x00000066 (102)	Microsoft ACPI-Compliant System
(ISA) 0x00000067 (103)	Microsoft ACPI-Compliant System
(ISA) 0x00000068 (104)	Microsoft ACPI-Compliant System
(ISA) 0x00000069 (105)	Microsoft ACPI-Compliant System
(ISA) 0x0000006A (106)	Microsoft ACPI-Compliant System
(ISA) 0x0000006B (107)	Microsoft ACPI-Compliant System
(ISA) 0x0000006C (108)	Microsoft ACPI-Compliant System
(ISA) 0x0000006D (109)	Microsoft ACPI-Compliant System
(ISA) 0x0000006E (110)	Microsoft ACPI-Compliant System
(ISA) 0x0000006F (111)	Microsoft ACPI-Compliant System
(ISA) 0x00000070 (112)	Microsoft ACPI-Compliant System
(ISA) 0x00000071 (113)	Microsoft ACPI-Compliant System
(ISA) 0x00000072 (114)	Microsoft ACPI-Compliant System
(ISA) 0x00000073 (115)	Microsoft ACPI-Compliant System
(ISA) 0x00000074 (116)	Microsoft ACPI-Compliant System
(ISA) 0x00000075 (117)	Microsoft ACPI-Compliant System
(ISA) 0x00000076 (118)	Microsoft ACPI-Compliant System
(ISA) 0x00000077 (119)	Microsoft ACPI-Compliant System
(ISA) 0x00000078 (120)	Microsoft ACPI-Compliant System
(ISA) 0x00000079 (121)	Microsoft ACPI-Compliant System
(ISA) 0x0000007A (122)	Microsoft ACPI-Compliant System

	(ISA) 0x0000007A (122)	Microsoft ACPI-Compliant System
	(ISA) 0x0000007B (123)	Microsoft ACPI-Compliant System
	(ISA) 0x0000007C (124)	Microsoft ACPI-Compliant System
	(ISA) 0x0000007D (125)	Microsoft ACPI-Compliant System
	(ISA) 0x0000007E (126)	Microsoft ACPI-Compliant System
	(ISA) 0x0000007F (127)	Microsoft ACPI-Compliant System
	(ISA) 0x00000080 (128)	Microsoft ACPI-Compliant System
	(ISA) 0x00000081 (129)	Microsoft ACPI-Compliant System
	(ISA) 0x00000082 (130)	Microsoft ACPI-Compliant System
	(ISA) 0x00000083 (131)	Microsoft ACPI-Compliant System
	(ISA) 0x00000084 (132)	Microsoft ACPI-Compliant System
	(ISA) 0x00000085 (133)	Microsoft ACPI-Compliant System
	(ISA) 0x00000086 (134)	Microsoft ACPI-Compliant System
	(ISA) 0x00000087 (135)	Microsoft ACPI-Compliant System
	(ISA) 0x00000088 (136)	Microsoft ACPI-Compliant System
	(ISA) 0x00000089 (137)	Microsoft ACPI-Compliant System
	(ISA) 0x0000008A (138)	Microsoft ACPI-Compliant System
	(ISA) 0x0000008B (139)	Microsoft ACPI-Compliant System
	(ISA) 0x0000008C (140)	Microsoft ACPI-Compliant System
	(ISA) 0x0000008D (141)	Microsoft ACPI-Compliant System
	(ISA) 0x0000008E (142)	Microsoft ACPI-Compliant System
	(ISA) 0x0000008F (143)	Microsoft ACPI-Compliant System
	(ISA) 0x00000090 (144)	Microsoft ACPI-Compliant System
	(ISA) 0x00000091 (145)	Microsoft ACPI-Compliant System
	(ISA) 0x00000092 (146)	Microsoft ACPI-Compliant System
	(ISA) 0x00000093 (147)	Microsoft ACPI-Compliant System
	(ISA) 0x00000094 (148)	Microsoft ACPI-Compliant System
	(ISA) 0x00000095 (149)	Microsoft ACPI-Compliant System
	(ISA) 0x00000096 (150)	Microsoft ACPI-Compliant System
	(ISA) 0x00000097 (151)	Microsoft ACPI-Compliant System
	(ISA) 0x00000098 (152)	Microsoft ACPI-Compliant System
	(ISA) 0x00000099 (153)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009A (154)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009B (155)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009C (156)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009D (157)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009E (158)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009F (159)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A0 (160)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A1 (161)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A2 (162)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A3 (163)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A4 (164)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A5 (165)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A6 (166)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A7 (167)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A8 (168)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A9 (169)	Microsoft ACPI-Compliant System
	(ISA) 0x000000AA (170)	Microsoft ACPI-Compliant System

	(ISA) 0x00000099 (153)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009A (154)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009B (155)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009C (156)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009D (157)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009E (158)	Microsoft ACPI-Compliant System
	(ISA) 0x0000009F (159)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A0 (160)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A1 (161)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A2 (162)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A3 (163)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A4 (164)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A5 (165)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A6 (166)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A7 (167)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A8 (168)	Microsoft ACPI-Compliant System
	(ISA) 0x000000A9 (169)	Microsoft ACPI-Compliant System
	(ISA) 0x000000AA (170)	Microsoft ACPI-Compliant System
	(ISA) 0x000000AB (171)	Microsoft ACPI-Compliant System
	(ISA) 0x000000AC (172)	Microsoft ACPI-Compliant System
	(ISA) 0x000000AD (173)	Microsoft ACPI-Compliant System
	(ISA) 0x000000AE (174)	Microsoft ACPI-Compliant System
	(ISA) 0x000000AF (175)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B0 (176)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B1 (177)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B2 (178)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B3 (179)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B4 (180)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B5 (181)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B6 (182)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B7 (183)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B8 (184)	Microsoft ACPI-Compliant System
	(ISA) 0x000000B9 (185)	Microsoft ACPI-Compliant System
	(ISA) 0x000000BA (186)	Microsoft ACPI-Compliant System
	(ISA) 0x000000BB (187)	Microsoft ACPI-Compliant System
	(ISA) 0x000000BC (188)	Microsoft ACPI-Compliant System
	(ISA) 0x000000BD (189)	Microsoft ACPI-Compliant System
	(ISA) 0x000000BE (190)	Microsoft ACPI-Compliant System
	(PCI) 0x00000007 (07)	Intel(R) N10/ICH7 Family SMBus Controller - 27DA
	(PCI) 0x00000010 (16)	Intel(R) N10/ICH7 Family PCI Express Root Port - 27D0
	(PCI) 0x00000010 (16)	Intel(R) N10/ICH7 Family USB Universal Host Controller - 27CB
	(PCI) 0x00000012 (18)	Intel(R) N10/ICH7 Family USB Universal Host Controller - 27CA
	(PCI) 0x00000013 (19)	Intel(R) N10/ICH7 Family Serial ATA Storage Controller - 27C0
	(PCI) 0x00000013 (19)	Intel(R) N10/ICH7 Family USB Universal Host Controller - 27C9
	(PCI) 0x00000017 (23)	Intel(R) N10/ICH7 Family USB Universal Host Controller - 27C8
	(PCI) 0x00000017 (23)	Intel(R) N10/ICH7 Family USB2 Enhanced Host Controller - 27CC
	(PCI) 0xFFFFFFF3 (-3)	Realtek PCIe GBE Family Controller
	(PCI) 0xFFFFFFFF (-2)	Intel(R) Graphics Media Accelerator 3600 Series

D.4 DMA Channel Assignments



Application Note

If customer use MLC mSATA for long distance communication, file to file transfer & receive, Please check if icon “CRC” for cross-check verification.

