#### PER-C35L

Intel<sup>®</sup> 82599 SFP/SFP + Fiber LAN Compatible PCI-Express 10 Gigabit Ethernet Acceleration Module

> PER-C35L Manual Rev.A 1st Ed. February 2010

# **Copyright Notice**

This document is copyrighted, 2010. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, AAEON assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

AAEON reserves the right to make changes in the product design without notice to its users.

## Packing List

Before you begin installing your card, please make sure that the following materials have been shipped:

- 1 PER-C35L Ethernet Module
- 1 CD-ROM for manual (in PDF format) and drivers

If any of these items should be missing or damaged, please contact your distributor or sales representative immediately.

### Contents

#### **Chapter 1 General Information**

1.1 Features	1-2
1.2 Specifications	1-2

#### Chapter 2 Quick Installation Guide

2.1 Safety Precautions	. 2-2
2.2 Location of Connectors and Jumpers	. 2-3
2.3 Mechanical Drawing	. 2-4
2.4 LAN Module Installation	. 2-5

#### Chapter 3 Driver Installation

3.1 Installation	-2
------------------	----

# Chapter

# General Information

Chapter 1 General Information 1 - 1

#### 1.1 Features

- PCI-Express Host Interfaces
- 10Gigabit Ethernet SFP+ Fiber LAN x 2

#### **1.2 Specifications**

•	Form Factor:	LAN module
•	Chipset	Intel 82599 PCI-Express
		10Gigabit Ethernet controller
•	Expansion Interface	SFP/SFP+ Fiber LAN
		compatible
•	PCI-Express	From host PCI-Express
		connector
•	Serial Port	Formal certification CE/FCC
		Class A
•	Power Requirement	From PCI-Express connector
•	Operating Temperature	∋ 32°F~104°F (0°C~40°C)
•	EMC	CE/FCC Class A



# Quick Installation Guide

Chapter 2 Quick Installation Guide 2-1

#### **2.1 Safety Precautions**




Always completely disconnect the power cord from your board whenever you are working on it. Do not make connections while the power is on, because a sudden rush of power can damage sensitive electronic components.


Caution!



Always ground yourself to remove any static charge before touching the board. Modern electronic devices are very sensitive to static electric charges. Use a grounding wrist strap at all times. Place all electronic components on a static-dissipative surface or in a static-shielded bag when they are not in the chassis


#### 2.2 Location of Connectors and Jumpers









#### Solder Side



#### 2.3 Mechanical Drawing





#### 2.4 LAN Module Installation

Step1: Loosen the screws on the bottom of chassis




Step 2: Remove the null Module cover or existing LAN module



Chapter 2 Quick Installation Guide 2-5

Step 3: Insert the LAN Module and fasten the screws





#### **Ethernet Module**

#### P E R - C 3 5 L

#### Below Table for China RoHS Requirements 产品中有毒有害物质或元素名称及含量

#### AAEON Main Board/ Daughter Board/ Backplane

	有毒有害物质或元素							
部件名称	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚		
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)		
印刷电路板	×	0	0	0	0	0		
及其电子组件	^	0	0	0	0	U		
外部信号	x	0	0	0	0	0		
连接器及线材		0	0	0	0	0		
O:表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006标准规定的限量要求以下。								
X:表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。								

备注:此产品所标示之环保使用期限,系指在一般正常使用状况下。

# Chapter 3

# Driver Installation

Chapter 3 Driver Installation 3-1

#### 3.1 Installation:

Insert the PER-C35L CD-ROM into the CD-ROM Drive. And follow the instructions to install the driver. You can activate the installation items through Autorun program, which will install each driver directly.

- 1. Select the OS your server is and double click on the **.exe** file locates in each OS folder
- 2. Follow the instructions that the window shows
- 3. The system will help you install the driver automatically

If your system do not support Autorun program or you cannot install drivers successfully, please read instructions below for further detailed installations.

- 1. Go to *My Computer* and click on the right of mouse, select *Properties*
- 2. Select Hardware
- 3. Enter Device Management
- 4. Select your LAN card and click on the right of mouse
- 5. Select *Update your driver* and follow the instructions that the window show
- 6. Select to install from CD-ROM
- 7. Click on the *PER-C35L* (depends on the chip your card supports) folder
- 8. Choose the OS your system is
- 9. The system will help you install the driver automatically
- 10. Please re-start your computer