ACP-5187

Environment Test Report

Report NO:13P020006

	▼ Pass
	□ Fail
Summary	Note: There is/are defect(s) not list in the report, please check it in the DTS Website.
	□ Pass with Deviation
	Comment:

Issue date	Approval	Test Engineer
2013-04-12	Tom Lin	Andy Chen

Test item list

<i>1</i> .	Test item list	2
<i>2</i> .	Configuration of EUT	3
<i>2</i> .	Temperature rise test	4
<i>3</i> .	Temperature cycle operation test	8
<i>4</i> .	High temperature storage test	9
<i>5</i> .	Low temperature storage test	<i>10</i>
<i>6</i> .	Humidity test	11
	Cold start and hot start test	<i>12</i>

Testing Result

Num	Test item list	Result	Remark
1	Temperature rise test	Pass	
2	Temperature cycle operation test	Pass	
3	High temperature storage test	Pass	
4	Low temperature storage test	Pass	
5	Humidity test	Pass	
6	Cold start and hot start test	Pass	

Configuration of EUT

Item	Device Information	
SYSTEM PC Model / Ver.	GENE-QM77 A1.0	
CPU	Intel Core i7-3610QE 3.3GHz	
BIOS / Version	ACP-5187 R0.1 (A587AM01)(03/05/2013)	
South Bridge	Intel QM77	
Industry Memory Type	DLS DDR3-1333 8GB ELPIDA J4208BBBG-GN-F	
Industry HDD	TOSHIBA MK1676GSC 2.5" 160G	
Operating System	Windows 7 Professional English 64 Bit	
Adapter	FSP-120-AAB 19V/6.32A	

System picture:





Test Date: 04-10-2013

Test Product: ACP-5217

Test Site: AAEON QE Dept.

Test Standard: Refer to EN 61131-2(94), UL508 (94)

Temperature Measurement:

40 Channel Thermal Recorder:

YOKOGAWA Inc,

Model: DA100-13-1D

Date of Calibration: 10/08/2012 Serial Number: 12A323190

Test Condition:


Ambient temperature: 40°C


Continuous running till thermal stable (within less than 1° C)

Test Software:

Windows 7 / Run PassMark Burn In Test 7.0 Pro

Terminal Recorder:









Thermal profile data:

Point Temp.	G	25	40	NI
$Stage(^{\circ}C)$	Spec	25	40	Note
CPU - Intel core i7-3610QE	105	51.0	66.0	
02. U31 - (TF)Chipset PCH.INTEL.BD82QM77	108	66.6	81.6	
03. U42 - (TF)PWR.SMD.SO-8P.P-Channel MOSFET.APEC.AP6679GM-HF	125	55.6	70.6	
04. Memory - DLS DDR3-1333 8GB	95	41.3	56.3	
05. U47-(TF)IC.SMD.QFN 48P.PCI-express.Gigabit Ethernet	90	53.5	68.5	
06. HDD - TOSHIBA MK1676GSC 2.5" 160G	85	52.5	67.5	
07. L5 - (TF)COIL.0.36uH.Irms=34A.20%.Panasonic.ETQP4LR36AFC	130	58.5	66.9	
08. U11 - (TF)High Definition.Audio Codec.REALTEK.ALC892-GR	100.5	58.5	73.5	
09. Internal Air	N/A	44.7	59.7	
10. Rear heatsink	N/A	43.3	58.3	
11. Chamber Temperature	N/A	25	40	

Note(*):

- 1. "Tc" indicates the component's case maximum temperature value specified in its datasheet.
- 2. "Tm" indicates the measured Tc value under working environmental temperature within product specification.
- 3. Judgment Criteria:
 - Fail : Tm > Tc; The measured value is over specification plus margin.
 - Margin : $Tc > Tm > Tc-5^{\circ}C$; The measured value is within specification with margin.

For FANLESS system application, it is strongly recommended to add thermal dissipation design for better reliability.

- **Pass** : $Tm < Tc-5^{\circ}C$; The measured value is with safety margin.

Sample Configuration & Quantity Under Test:

Quantity: 1 (ACP-5187)

Test Result:

No issues were found during the temperature rise operation test.

Temperature cycle test

Test Date: 03-29~30-2013

Test Product: ACP-5187

Test Site: AAEON QE Dept.

Test Standard: Refer to IEC68-2-14 Testing procedures

Test N: Change of temperature Test

Test Equipment:

Programmable Temperature & Humidity Chamber(K.SON. INS. TECH. CORP.)

Model: THS-D75-100+LN2 Date of Calibration: 06/20/2012

Serial Number: 6487KT

Test Condition:

1. Test Low Temperature: 0° C (1~3 cycles)

-5°C (4th cycle)

2. Test High Temperature: 40° C (1~3 cycles)


45°C (4th cycle)

3. Test dwell time: 6Hrs

4. Temperature slope: 2°C/min

5. Test cycle: 4 cycles

6. Test Environment Curve:



Sample Configuration & Quantity Under Test:

Quantity: 1 (ACP-5187)

Test Result:

High temperature storage test

Test Date: 04-5~7-2013

Test Product: ACP-5187

Test Site: AAEON QE Dept.

Test Standard: Refer to IEC 68-2-2 Testing procedures

Test Bb: Dry Heat Test (Non-operation)

Test Equipment:

Programmable Temperature & Humidity Chamber(K.SON. INS. TECH. CORP.)

Model: THS-D75-100+LN2 Date of Calibration: 06/20/2012 Serial Number: 6487KT


Testing Item:

1. Test Temperature: 70°C

2. Test Times: 48Hrs

3. Test Software: Windows 7 / Run PassMark Burn In Test 7.0 Pro

4. Test Environment Curve:



Sample Configuration & Quantity Under Test:

Quantity: 1 (ACP-5187)

Test Result:

No issues were found after the high temperature storage test.

Low temperature storage test

Test Date: 04-8~9-2013

Test Product: ACP-5187

Test Site: AAEON QE Dept.

Test Standard: Refer to IEC 68-2-1 Testing procedures

Test Ab: Cold Test (Non-operation)

Test Equipment:

Programmable Temperature & Humidity Chamber(K.SON. INS. TECH. CORP.)

Model: THS-D75-100+LN2
Date of Calibration: 06/20/2012

Serial Number: 6487KT


Testing Item:

1. Test Temperature: -20°C

2. Test Times: 48Hrs

3. Test Software: Windows 7 / Run PassMark Burn In Test 7.0 Pro

4. Test Environment Curve:



Sample Configuration & Quantity Under Test:

Quantity: 1 (ACP-5187)

Test Result:

No issues were found after the low temperature storage test.

Humidity test

Test Date: 04-9~10-2013

Test Product: ACP-5187

Test Site: AAEON QE Dept.

Test Standard: Refer to IEC 68-2-3 Testing procedures

Test Ca: Damp heat, steady state (Non-operation)

Test Equipment:

Programmable Temperature & Humidity Chamber(K.SON. INS. TECH. CORP.)

Model: THS-D75-100+LN2 Date of Calibration: 06/20/2012 Serial Number: 6487KT

Testing Item:


Test Temperature: 40°C
 Test Humidity: 90%RH

3. Test Times: 48Hrs

4. Test Software: Windows 7 / Run PassMark Burn In Test 7.0 Pro

5. Test Environment Curve:

Humidity %



Sample Configuration & Quantity Under Test:

Quantity: 1 (ACP-5187)

Test Result:

No issues were found after the humidity storage test.

Cold start and hot start test

Test Date: 04-11~12-2013

Test Product: ACP-5187

Test Site: AAEON QE Dept.

Test Standard: Refer to IEC 68-2-14 Testing procedures


Test N: Change of temperature Test

Test Equipment:

Programmable Temperature & Humidity Chamber(K.SON. INS. TECH. CORP.)

Model: THS-D75-100+LN2 Date of Calibration: 06/20/2012 Serial Number: 6487KT

Test Condition:



Parameters	Description
T1	-5°C
T2	45°C
t1	4 hrs
t2, t6	2 hrs
t4, t5	1hrs
t, t3	2°C/min
n (Cycle)	1

 $t = temprature \ slope$

t, t1, t6: Power Off

t2: Power on/off test 10 times (on 2 min / off 5min)

t3, t4: Run Burn In Test 7.0 Pro

t5: Win 7 Software restart test 3 times

Test Software: Windows 7

Test Result:

- a. No issues were found during the cold start test.
- b. No issues were found during the hot start test.